ASSEMBLY INSTRUCTIONS
Quadro Wood A
2P Run workstation

Sizes: 1200, 1400, 1600, 1800 mm

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

Tools Required: Power screwdriver; Allen key set (provided)

👤👤 2 persons required for installation

Quadro Wood A 2P Run workstation

Sizes: 1200, 1400, 1600, 1800 mm

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

COMPONENTS

A   Table top x2

B   Leg Quadro A x2

C   Connector frame x1

D   Beam x2 *

E   Plastic bracket x8

SCREWS

F   M8x20MM CSK x4

G   M8x20MM Socket head x4

H   M6x20MM Socket head x8

I   M6x30MM Socket head x8

J   M6x30mm Mushroom head screw x4

K   Allen key x2

* Colour of the beam is always black, regardless desk frame colour.

ASSEMBLY INSTRUCTIONS
Quadro Wood A 2P Run workstation

Sizes: 1200, 1400, 1600, 1800 mm

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

STEP 01

Plastic bracket holes facing to the other side.

You will notice two colored stickers located on each leg.

Both legs must have the colour sticker facing away from where the plastic brackets are inserted.

STEP 02

J

Insert the bottom of the legs as shown in the illustration. Using Allen Key provided, attach Mushroom Head Screw **(J)** - for all legs.

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

STEP 03

H

Using Allen Key provided, attach 2 plastic brackets per leg **(E)** (as per picture above) using M6x20MM **(H)** Socket head screw. Do the same with Connector frame **(C)**.

STEP 04

G

Using Allen Key provided, attach M8x20MM Socket head **(G)**-screw socket half way into leg for both legs **(B)** and into Connector frame **(C)**.

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

STEP 05

Adjust extendable beam **(D)** to desired length using markers and secure beam at that length using screws provided

2000
1900
1800
1700
1600
1500
1400
1300
1200

50   50

Sizes: 1200, 1400, 1600, 1800 mm

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

STEP 06

TOP VIEW

Attach beam **(D)** to legs **(B)** and Connector frame **(C)**
using nut insert in legs. See point attached

STEP 07

Frame looks like this. Using Allen Key, attach beam **(D)** with Socket **(F)**

Quadro Wood A
2P Run workstation

Sizes: 1200, 1400, 1600, 1800 mm

www.jasonl.com.au

Need help!
Call us on
1300 527 665

**jason.l**
your office furniture mate

STEP 08

I

TABLE TOP
BOTTOM VIEW

Place desktops ontop of frame - with cutout at the back of the desk.
Nut inserts in top will align with plastic joiner brackets using M6x30MM
(I) sockets attached tops to frame.

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

TABLE TOPS
BOTTOM VIEW

The following nut inserts should be used for this specific desk / workstation

nut insert

nut insert

nut insert

nut insert