


# WIRELESS WEATHER STATION

## QUICK START GUIDE




MODEL: 308-1711BLV2  
DC: 030119

Find your full manual and product information here: [bit.ly/laxtech\\_support](http://bit.ly/laxtech_support)

### POWER UP

1. Insert 2-AA batteries into your Outdoor Sensor.
2. Insert 2-AA batteries into your Weather Station.
3. Once the Outdoor Sensor is reading to your station, place it outside in a shaded location to protect from the sun's heat.

Watch sensor mounting video: [bit.ly/TH\\_SensorMounting](http://bit.ly/TH_SensorMounting)



### SETTINGS

1. Hold the TIME/DATE button to enter the Settings Menu.
2. Use the ARROW buttons to adjust values.
3. Press the TIME/DATE button to confirm and move to the next item in the Settings Menu.

#### Settings Menu Order:

- Year • Month • Date • 12/24 Hour Time • Hour • Minutes
- Fahrenheit/Celsius

**Note:** Weekday will set automatically when Year, Month and Date are set.

### TEMPERATURE ALERTS

#### Set Alerts:

1. Hold the TEMP ALERTS button to enter Alert Settings.
2. Use the ARROW buttons to adjust, and the TEMP ALERTS button to confirm and move to the next alert.

#### Arm/Disarm Alerts:

- Press the TEMP ALERTS button to select an alert.
- Press the UP ARROW button to arm temperature alerts.
- Press the DOWN ARROW button to disarm temperature alerts.

#### Sounding Alerts:

- When a temperature enters an alert range, the corresponding Alert Icon **HI** **LO** will flash, and the station will ring for five seconds every minute, until the temperature moves out of the alert range.
- Press any button to stop the sounding alert. The Alert Icon will continue to flash.

### MOON PHASE

The Moon Phase is based on the lunar calendar, and therefore is controlled by the time and date set on your weather station.



New Moon



Small Waxing Crescent



Large Waxing Crescent



First Quarter



Small Waxing Gibbous



Large Waxing Gibbous



Full Moon



Large Waning Gibbous



Small Waning Gibbous



Last Quarter



Large Waning Crescent



Small Waning Crescent

## BUTTON FUNCTIONS

HEAT / DEW SENSOR	Press to view Heat Index and Dew Point Temperature. Hold to search for Outdoor Sensor.
TIME / DATE SETTINGS	Hold to enter Settings. Press to confirm Settings.
MIN	Press to view Minimum Temperature Records. In Temp Alerts, press to disarm an alert. In Settings, press to decrease setting values.
TEMP ALERTS	Hold to enter Alert Settings. Press to toggle HI and LO Alerts.
MAX	Press to view Maximum Temperature Records. In Temp Alerts, press to arm an alert. In Settings, press to increase setting values.
TIME ALARM	Hold to enter Alarm Settings. Press to view alarm time briefly, press again to activate/deactivate Time Alarm. When alarm sounds, press to snooze the alarm for 10 minutes.

## MIN/MAX TEMPERATURE

- All MIN/MAX temperature/humidity records will reset automatically at 12:00 (midnight).
- Press the DOWN ARROW to view minimum temperature readings.
- Press the UP ARROW to view maximum temperature readings.

## SENSOR WEATHER SHIELD\*

- The Sensor Weather Shield is designed to protect your outdoor sensor from rain and snow.
- This shield will offer limited protection from the sun's heat.
- Optional purchase at: [bit.ly/925-1418](http://bit.ly/925-1418)



\*Not included

## WE'RE HERE TO HELP!

If you require additional support, get in touch with our friendly customer support team based out of La Crosse, WI.

Phone: 1-608-782-1610

Online: [bit.ly/contact\\_techsupport](http://bit.ly/contact_techsupport)

Our knowledgeable customer support team is available:  
Monday-Friday, 8am-6pm CST.

## JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



## SPECIFICATIONS

**Indoor Temperature Range:** 32°F to 122°F (0°C to 50°C)

**Indoor Humidity Range:** 10%-99% RH

**Outdoor Temperature Range:** -40°F to 140°F (-40°C to 60°C)

**Outdoor Humidity Range:** 10%-99% RH

**Transmission Range:** 330 feet (100 meters)

### Power Requirements:

**308-1711BLv2 Station:** 2 AA batteries (not included)

**TX141TH-Bv3 Sensor:** 2 AA batteries (not included)

### Battery Life:

**308-1711BLv2 Station:** Over 24 months

**TX141TH-Bv3 Sensor:** Over 24 months

### Dimensions

**308-1711BLv2 Station:** 5.40" L x 1.68" W x 4.40" H

(3.72 cm L x 4.28 cm W x 11.18 cm H)

**TX141TH-Bv3 Sensor:** 1.57" L x 0.79" W x 5.12" H (4.0 cm L x 2.0 cm W x 13.0 cm H)

## WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

La Crosse Technology, Ltd

2830 S. 26th St.

La Crosse, WI 54601

For Full Warranty Details, Visit: [www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

## CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not be used for an extended period.
- Promptly remove expired batteries.

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

## CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

**WARNING:** This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)