


LA CROSSE®
TECHNOLOGY

WIRELESS WEATHER STATION




SET UP GUIDE

MODEL: 308-1711BLv2

POWER UP

1. Insert 2-AA batteries into your Outdoor Sensor.
2. Insert 2-AA batteries Into your Weather Station
3. Enter the Settings Menu to adjust your time and date.
4. Once the sensor is reading to your clock, place the sensor outside in a shaded location. View our sensor mounting video here: bit.ly/th_sensor_mounting



SETTINGS MENU

1. Hold the **SETTINGS** button to enter the Settings Menu.
2. Use the **-/LOW** or **+/HIGH** button to adjust values.
3. Press the **SETTINGS** button to confirm and move to the next item in the Settings Menu.

Settings Menu Order:


- Year
 - Month
 - Date
 - 12/24 Hour Time
 - Hour
 - Minutes
 - Fahrenheit/Celsius
-
- **Weekday:** Your weekday display will adjust automatically once you have your Year, Month, and Date settings set correctly.

TIME ALARM


Setting and activating time alarms are separate actions.

Set Alarm:


1. Hold the **TIME ALARM** button until the the display changes to Alarm Settings.
2. Press and release **-/LOW** or **+ /HIGH** button to adjust the values. Hold to adjust quickly.
3. Press and release the **TIME ALARM** button to confirm and move to the next item or exit.



ACTIVATE/DEACTIVATE ALARM

- Press the **TIME ALARM** button once to view alarm time.
- Press the **TIME ALARM** button again to activate the alarm. Once activated, the Alarm Icon  appears.
- Press the **TIME ALARM** button again to deactivate the alarm. The Alarm Icon will disappear.

SNOOZE ALARM


- When alarm sounds, press the **SNOOZE** button to silence the alarm for 10 minutes. The Alarm Icon  will flash.
- In snooze mode, press any button except SNOOZE to stop alarm for one day.

Note: The alarm will sound with increasing frequency for two minutes, then shut off automatically if not silenced.

TEMPERATURE ALERTS

Set Alerts:

1. Hold the **TEMP ALERTS** button to enter Alert Settings.
2. Use the **-/LOW** or **+ /HIGH** button to adjust, and the **TEMP ALERTS** button to confirm and move to the next alert.



Arm/Disarm Alerts:

- Press the **TEMP ALERTS** button to select an alert.
- Press the **+ / HIGH** button to arm temperature alerts.
- Press the **- / LOW** button to disarm temperature alerts.

Sounding Alerts:

- When a temperature enters an alert range, the corresponding Alert Icon **HI** **LO** will flash, and the station will ring for five seconds every minute, until the temperature moves out of the alert range.
- Press any button to stop the sounding alert. The Alert Icon will continue to flash.

MIN/MAX (HIGH/LOW) TEMPERATURE RECORDS

All MIN/MAX temperature/humidity records will reset automatically at 12:00 (midnight).

- Press and release the **- / LOW** button to view indoor/outdoor minimum readings.
- Press and release the **+ / HIGH** button to view indoor/outdoor maximum readings.

TEMPERATURE TREND ARROWS

Both the Indoor and Outdoor Temperature values have Trend Arrows to indicate changes (2°F/1°C or more) over the past one hour period.



Temperature has risen over the past hour.



Temperature has been steady over the past hour.



Temperature has fallen over the past hour.

HEAT INDEX / DEW POINT

- Press the **HEAT/DEW** button once to view remote Heat Index.
- Press the **HEAT/DEW** button twice to view remote Dew Point.

MOON PHASE

The Moon Phase is based on the lunar calendar, and therefore is controlled by the time and date set on your weather station.



New Moon



Small Waxing
Crescent



Large Waxing
Crescent



First Quarter



Small Waxing
Gibbous



Large Waxing
Gibbous



Full Moon



Large Waning
Gibbous



Small Waning
Gibbous



Last Quarter



Large Waning
Crescent



Small Waning
Crescent


SENSOR WEATHER SHIELD

- The Sensor Weather Shield (sold separately) is designed to protect your outdoor sensor from rain and snow.
- This shield will offer limited protection from the sun's heat.
- Optional purchase at: bit.ly/925-1418



SEARCH FOR OUTDOOR SENSOR

If you are seeing dashes for your outdoor readings, please try the following steps:

1. Hold the **SEARCH** button to search for your outdoor sensor. The Reception Indicator  will begin to animate.
2. If after 3 minutes the sensor still isn't connected, bring the sensor inside next to the display and remove power from both the sensor and clock.
3. Press any button on the clock 20 times and leave the parts sit for a few moments with the power off.
4. Install a new set of alkaline batteries into the sensor, then into your clock. For additional help visit: bit.ly/basic_restart
5. If your outdoor data is still not appearing after these steps, please contact our support staff via the links below.

WE'RE HERE TO HELP

Still have questions? Use the links below to find additional resources or reach out to our staff directly.

Self-Help: bit.ly/308-1711blv2_support

Online Support: bit.ly/contact_techsupport

Phone: 608-782-1610

Our friendly support team based in La Crosse, WI is available Mon-Fri, 9am-6pm CST.

SCAN HERE
*Additional Info.
and Support* ✓



STAY IN TOUCH!

Ask questions, watch setup videos, and provide feedback on our social media outlets. Follow La Crosse Technology on YouTube, Twitter, Facebook and Instagram.



WARRANTY & PATENTS

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

La Crosse Technology, Ltd,
2830 S. 26th St.
La Crosse, WI 54601

For Full Warranty Details, Visit: www.lacrossetechnology.com/pages/warranty
Patents: www.lacrossetechnology.com/pages/patent

SPECIFICATIONS

Weather Station (308-1711BLv2)

- **Temperature Range:**
32°F to 122°F (0°C to 50°C)
- **Humidity Range:**
10% to 99% RH
- **Power Requirements:**
2-AA, IEC, LR6 batteries (not included)
- **Dimensions:** 5.40" L x 1.68" W x 4.40" H
(3.72 cm L x 4.28 cm W x 11.18 cm H)

Outdoor Sensor (TX141TH-Bv3)

- **Temperature Range:**
-40°F to 140°F (-40°C to 60°C)
- **Humidity Range:**
10% to 99% RH
- **Transmission Range:**
Over 330 ft. open air
(100 meters) RF 433MHz
- **Update Interval:**
About every 51 seconds
- **Power:**
2-AA, IEC, LR6 batteries (not included)
- **Battery Life:**
Over 12 months
- **Dimensions:** 1.57" L x 0.79" W x 5.12" H
(4.0cm L x 2.0cm W x 13.0 H cm)

CARE AND MAINTENANCE

When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from product during periods of non-use. Battery leakage can cause corrosion and damage to this product.
- Remove used batteries promptly.
- For recycling and disposal of batteries, and to protect the environment, please check the internet or your local phone directory for local recycling centers and/or follow local government regulations.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CALIFORNIA RESIDENTS



CA WARNING:

This product can expose you to chemicals including acrylonitrile, butadiene, and styrene, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to: www.P65Warnings.ca.gov

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.