

OWNERS OPERATING INSTRUCTIONS

INTRODUCTION

For satisfactory performance of your Braemar gas wall furnace, please read these instructions carefully. The operation of the heater is controlled by the gas control knob and fan switch located behind the access door on the front cover.

FAN OPERATION

The fan will start automatically in both AUTO and BOOST positions when the unit is warm enough after the burner is turned on, and stop automatically when the unit has cooled sufficiently after the burner turns off. With AUTO selected the unit will automatically select between "low" and "normal" (and "boost" on 40MJ models) fan speeds based on the heated air temperature - no further user adjustment is necessary. When BOOST is selected the fan will run only on its boost speed. It is recommended that the manual fan switch be set to AUTO for normal operation, or BOOST for rapid heat-up.

GAS CONTROL

To light the heater:

- Turn the gas control knob anti-clockwise from the "O" position to the  position.
- Depress knob fully and hold down.
- Press the igniter button located next to the gas control knob 3-4 times.
- Observe the pilot meter to indicate operation of the pilot.
- Wait 20 seconds then release the knob and check that the pilot status indicator stays on.
- If not, repeat the ignition process.

Heat setting:

- Turn gas control knob anti-clockwise to desired heat setting between "1" and "7". The heater will automatically adjust the gas flow rate to maintain the room temperature corresponding to the selected setting.

To increase heat setting:

- Turn gas control knob anti-clockwise towards "7".

To reduce heat setting:

- Turn gas control knob clockwise towards "1".

To turn off main burner (when heat is not required):

- Turn gas control knob clockwise to the "PILOT" position. It is recommended that the pilot be left in operation for the duration of the heating season.

To turn off completely (end of heating season):

- Turn gas control knob clockwise to the "O" position.

WARNING

Do not place articles on or against this appliance.
Do not use or store flammable materials near this appliance.
Do not spray aerosols in the vicinity of this appliance while it is in operation.

TEAR AWAY HERE AND MAIL TODAY

**GAS WALL FURNACE
BRAEMAR WF2000 SERIES
WARRANTY REGISTRATION CARD**

Name of Purchaser _____
 Address _____
 _____ Phone: (____) _____
 Purchased From _____
 Address _____
 Installation Date _____ Serial Number WF _____

This unit is installed in - New Home Existing Home Hall / Passageway Bedroom
 Lounge / Dinning area Kitchen / family room Other

CARE INSTRUCTIONS

External surfaces should be cleaned with warm water and detergent with the heater turned off. Do not use abrasive cleaners, as scratching of the surface will occur.

RECOMMENDED MAINTENANCE SCHEDULE

Periodic maintenance of your Braemar wall furnace will ensure a long and satisfactory service life with the heater delivering optimum performance. It is recommended that you contact your authorised Braemar service agent to arrange a routine maintenance check before the start of each heating season.

Service and maintenance work must only be carried out by Authorised personnel

WARRANTY

The manufacturer, Seeley International Pty. Ltd. (Seeley), warrants that the product is free from defects in the material and factory workmanship. Subject to these terms of warranty, Seeley will repair or replace at its option, the product or any part thereof, which examination shows to be defective, for a period of two (2) years from the date of purchase when the unit is used for personal, domestic household purposes, and for one (1) year for non-domestic heating applications.

A ten (10) year warranty applies for the heat exchanger and main burner.

This warranty applies to all components which form part of the original *Braemar Gas Wall Furnace*, but excludes other related installation components.

During the period to which any expressed warranty applies, all defective part(s) shall be replaced or repaired (at the discretion of Seeley) without charge for either parts or labour, during normal working hours. Travel charges apply for units located more than 35 kms from an authorised *Braemar Service Agent*.


No other person, company or corporation is authorised to offer, or give on our behalf, any other warranty. Nothing in this warranty shall

be construed as affecting any rights you may have under all the relevant laws, or Commonwealth or state Legislation which give you rights which cannot be modified or excluded by agreement. The benefits conferred are in favour of the original Retail Purchaser and any person deriving title to the *Braemar Gas Wall Furnace* whilst in its original place of installation.

This warranty does not apply to any consequential loss suffered through, or resulting from, the non-operation, or ineffective operation of the gas heater.

This warranty does not cover damage to the gas *Wall Furnace* or other loss from acts of God. This warranty is conditional on the unit being installed, operated and maintained in accordance with the instructions provided. The warranty does not apply to damage or adjustment due to misuse of the unit or faulty installation or commissioning, or where non-*Braemar* components have been used.

Note: The Manufacturer and its Agents reserve the right to refuse service unless safety and accessibility to the unit can be guaranteed. The cost of any extra equipment required to provide access to the unit for servicing is the responsibility of the owner. If a service call reveals no fault found with the gas *Wall Furnace*, a charge will be made for the call.



A.C.N. 054 687 035

Manufactured by:
Seeley International Pty. Ltd.
77 North Street
Albury NSW 2640
Service & Warranty: 1300 650 644

612195/c

TEAR AWAY HERE AND MAIL TODAY

No postage stamp required
if posted in Australia



Business Reply Post No. 10
Seeley International Pty. Ltd.
P.O. Box 140
Melrose Park
South Australia 5039