



PHONE: 845-647-8400
1-800-pogostick
(1-800-764-6784)
WEBSITE: Flybar.com

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING YOUR MASTER POGO STICK.
KEEP THESE INSTRUCTIONS IN SAFE PLACE FOR FUTURE REFERENCE.


ALWAYS ADHERE TO THE FOLLOWING AGE AND WEIGHT RESTRICTIONS: MASTER POGO: FOR AGES 9 AND UP, 80 TO 160 LBS.

Satisfaction Guaranteed

If any parts are missing, do not return pogo to the place of purchase. We will rush you any missing parts at no charge. The rubber tip on your pogo is installed at the factory. Should the tip become lost or damaged, replace it immediately. NEVER use your pogo without the tip properly in place.

TIPS FOR PROPER USE OF YOU POGO:

- ★ Always wear protective gear: Helmet, knee pads, elbow pads, wrist guards and athletic shoes.
- ★ Always use your Pogo on a hard surface. NEVER use your Pogo on grass or dirt.
- ★ Have an adult check your Pogo before first use and on a regular basis.
- ★ NEVER use your Pogo with bare feet. Always wear athletic shoes.
- ★ Do not push the Pogo away from you. You cannot balance this way and you could damage the Pogo.
- ★ Hold the Pogo vertically, and develop balance by pulling the Pogo up with you.
- ★ Do not use your Pogo without the rubber tip properly in place.
- ★ Make sure all of your friends are instructed on the proper way to use your Pogo.
- ★ Follow the lubrication instructions below.
- ★ Store the pogo in a dry and sheltered place.
- ★ Never used the pogo on a uneven, sloping and wet surface.



LUBRICATION INSTRUCTIONS:

Your Pogo Stick has been lubricated at the factory but will require additional lubrication on a regular basis. Proper lubrication can be maintained with silicone spray, do not use oil or grease. During heavy use your pogo should be cleaned and lubricated every few days. Lubricate the chrome plated center shaft where it passes through the bracket above the spring. Turn the pogo stick upside down and lubricate the center shaft where it enters the foot rest.

**FOR REPLACEMENT PARTS
VISIT: FLYBAR.COM
OR EMAIL PARTS REQUESTS TO:
PARTS@FLYBAR.COM
OR CALL 845-647-8400**



IMPORTANT - PLEASE NOTE:

The Master pogo stick is designed for user weights 80 to 160 lbs.

1. The spring is not adjustable.
2. Spring is deliberately "tight" in all new Master Pogo Sticks.
3. It takes several successive bounces to gain the momentum necessary to compress the spring.
4. Do not worry if the spring initially feels "tight". It takes some "jumping time" for it to set.
5. The spring cannot be compressed by pushing down on the pogo with your hands or one foot. If the user is not able to balance well enough to achieve several successive jumps, have a helper act as a spotter. The spotter should stand behind the jumper, wrapping his/her hands around the jumper. The spotter's hands should go over the jumpers on the handlebars. When the jumper bounces the spotter should pull up steadying the jumper. Allow gravity to bring the jumper back down. With a little practice the spring will compress and the spotter will no longer be needed.