

Day Only DayClock Setting Instructions

Before starting insert a quality battery like Duracell or Energizer.

Be sure the positive end of the battery is pointed to the right.


Locate the two dials on the movement above the battery compartment.

Step 1

Gently pull out the smaller dial at the top center of the movement and turn it to rotate the day hand to the approximate time of the correct day.


Push the dial back in until it clicks.

If the dial is not pushed all the way in, the hand will not advance.



Step 2

Turn the large dial at the lower right of the movement to make fine adjustments to the day hand. For precision, we suggest calibrating the fine adjustment at noon or midnight.



DayClocks Troubleshooting Guide

Even a broken DayClock is right once a week...but let's fix this.

DayClocks typically run for many years without fail. If your DayClock does not advance properly after inserting a fresh battery, please take the steps below. Any frustrations, don't hesitate to contact us — we'll get your DayClock ticking again.

- 1) Check the small time setting dial in the upper center of the movement. If the dial is not pushed in all the way, the clock will not advance. Pull the dial out, then push it back in and you should feel a click; continue pushing and GENTLY try to twist the knob right and left. It will not turn but you might get a second click as the gears fully engage.
- 2) Let the clock sit for a few hours, the day hand moves slowly!

➔ **If your clock still does not advance properly, please contact us. We will need your DayClock model, approximate purchase date, and your shipping address.**

**For additional assistance please contact DayClocks Customer Service:
info@dayclocks.com or 1-866-DAY-CLOC (329-2562).**