

Time&Day Clock Setting Instructions


Before starting insert a quality battery like Duracell or Energizer.

Be sure the positive end of the battery is pointed to the right.

Locate the two dials on the movement above the battery compartment.

Step 1


Rotate the large dial to align both the hour and the minute hands to 12.



Step 2


Gently pull out and turn the small dial. If the current time is before noon, rotate the day hand to the line next to yesterday and if it's after noon select the line next to tomorrow. Push the small dial back in until it clicks.

If the dial is not pushed all the way in, the hand will not advance.



Step 3

Rotate the large dial so the hands move clockwise for AM settings or counter clockwise for PM settings to the current time.



DayClocks Troubleshooting Guide

Even a broken DayClock is right once a week...but let's fix this.

DayClocks typically run for many years without fail. If your DayClock does not advance properly after inserting a fresh battery, please take the steps below. Any frustrations, don't hesitate to contact us — we'll get your DayClock ticking again.

- 1) Check the small time setting dial in the upper center of the movement. If the dial is not pushed in all the way, the clock will not advance. Pull the dial out, then push it back in and you should feel a click; continue pushing and GENTLY try to twist the knob right and left. It will not turn but you might get a second click as the gears fully engage.
- 2) Let the clock sit for a few hours, the day hand moves slowly!

➔ **If your clock still does not advance properly, please contact us. We will need your DayClock model, approximate purchase date, and your shipping address.**

**For additional assistance please contact DayClocks Customer Service:
info@dayclocks.com or 1-866-DAY-CLOC (329-2562).**