

METHODE
BRIGITTE
KETTNER

Brigitte Kettner

MICRO-
DERMABRASION

English Only


Microdermabrasion

Thank you for choosing the MBK Microdermabrasion.

Please carefully read the following safety precautions and keep them for future reference.

Contents:

- Microdermabrasion device with sensitive tip (Grit 180)
- Normal tip (Grit 150)
- AC adapter
- User guide



IMPORTANT SAFETY PRECAUTIONS:

READ ALL INSTRUCTIONS BEFORE USING

When using electrical appliances, basic safety precautions should be followed, including the following:

- Do not place or store the device near water, such as a sink or tub.
- Do not charge this device with any other charger, Only use the charger that was supplied.
- This device should be kept out of the reach of children.
- Keep the AC adapter and device dry.
- **Do not operate the device while plugged in to charger.**
- Never operate this device if it has a damaged cord or plug.
- Do not wrap the cord around the appliance.
- Use this device only for its intended use as described in this manual.

DO NOT USE THIS APPLIANCE IF:

- You have recently tanned or sun-bathed.
- You have warts, because they may spread.
- You have recently used any type of products containing facial peeling ingredients.
- You have any type of skin irritation. i.e. rash, infection, burn, inflammation, active acne breakouts, rosacea, eczema, etc.
- You are recovering from a cosmetic procedure.
- You have had any type of hair removal procedure, such as waxing, electrolysis, or topical depilatories within the past 3 days.
- You are using skin-thinning medications and/or topicals such as, but not limited to: Accutane, Tretinoine, and/or steroids.

USAGE GUIDE:

1. **Charge your Microdermabrasion device for 3 hours before using it for the first time.**
2. Select your treatment tip.
 - a. **Normal (150 grit):** for all skin types, except sensitive. Good especially for thick and/or rough, dry skin.
 - b. **Sensitive (180 grit):** more suitable for acneic, thin, or sensitive skin.
3. Turn on by holding down the button until the blue light does not flash.
4. Select your suction strength by pressing the blue button **ONCE FOR LOW** and **TWICE FOR HIGH**.
5. Follow facial diagram to make long, slow passes over the entire face in an upward/outward direction. **Make sure your face is clean and dry.** You may make more than one pass (max recommended is 5) but if the skin becomes red or irritated, stop treatment in that area. **It is very important that you maintain full contact between the skin and the exfoliation tip to ensure steady suction. Do not stay in one place, you must keep the device moving across the skin at all times.**
CAUTION: DO NOT PRESS TOO HARD ONTO THE SKIN.

6. Once finished, cleanse the skin to remove any dead skin that remains. Then hydrate the exfoliated area with serum or moisturizer. If used during the day, always finish by applying sunscreen.



INSIDER TIPS/GUIDELINES FOR BEST RESULTS:

-Use your Microdermabrasion device once a week only, more often may result in skin irritation.

-Avoid hair removal procedures for at least 3 days after your Microdermabrasion treatment.

-Avoid all other forms of exfoliation (mechanical and chemical) for at least 3 days after your Microdermabrasion treatment.

-Do not treat the skin within the orbital eye socket, which is the area below and above the eyes.

CHARGING:

Make sure you charge your device for 3 hours before you use it for the first time.

Insert the AC adapter into the charging socket (refer to diagram on page 2 and plug into a wall socket. The blue light will flash to indicate the battery is charging. When fully charged, the blue light will no longer flash. Once charged, unplug the cable; **do not keep the charging cable connected to a power source when not charging the device.** Once the battery begins to run low again, the blue light will flash repeatedly to alert you it is time for a re-charge.

****NEVER OPERATE THE DEVICE WHILE IT IS PLUGGED IN.***

CHANGING TIPS:

To change between the NORMAL TIP and the SENSITIVE TIP simply remove the tip head by twisting and pulling upward. Insert the desired tip by firmly pressing it downward onto the device handle.

CLEANING:

NEVER IMMERSE THE DEVICE IN WATER. Remove the tip head by twisting and pulling upward. Use a small brush with soap and warm water to clean the surface of the treatment tip. Next, fully immerse the treatment tip in a Barbacide/Cavacide type solution and follow cleanser instructions for time and dilution guidelines. **(If you are using this strictly for home-use, you may simply soak the treatment tip in a disinfectant soap/water solution for at least 15 minutes.)**

Rinse well. Use a dry cloth to then dry the treatment tip. You may wipe down the device handle with a damp cloth or Barbacide type wipe.

DO NOT GET THE DEVICE HANDLE WET.

(IF USING FOR PROFESSIONAL TREATMENT, YOU MUST FOLLOW YOUR INDIVIDUAL STATE REQUIREMENTS FOR SANITATION AND DISINFECTION GUIDELINES)