


# THE ADJUSTED DEVICE SHOULD ALWAYS REST AT OR BELOW YOUR BELT LINE ON YOUR WAIST!

**THROW AWAY  
DOGS GEAR**  
throwawaydogsgear.com

## TACH1 Adjusting Instructions

Locate the end the of strap under the top or bottom heavy metal d-ring double adjust slide lock located here.



After adjustment is made you can cut the strap and use a match or a lighter to singe the material to prevent fraying. If you don't want to cut the strap so you can adjust it back later follow diagram C. and feed the extra material back through the double slide locks.

Diagram A.

Expanded TAGH1


**THE MOST COMMON NEED IS TO EXPAND YOUR TACH1.**



UNADJUSTED (STOCK) TACH1



Shortened TACH1



Pull on both the top and bottom straps evenly to keep the buckle centered and the d-rings at the top and bottom of your TACH1. It helps to unbuckle the device to feed the strap through both the buckle and the double slide locks.

**THE MOST IMPORTANT STEP OF THE ADJUSTMENT PROCESS IS TO MAKE SURE WHEN YOU ARE FINISHED THAT THE FRONT AND THE BACK ARE THE SAME LENGTH. THE HEAVY METAL D-RINGS SHOULD BE AT THE TOP AND BOTTOM WITH THE MAIN RELEASE BUCKLE IN THE CENTER OF THE DEVICE. YOUR FINISHED STRAP SHOULD ALWAYS LOOK LIKE THE DIAGRAM.**

Diagram B.

**TACH1** After strap is tucked under the two double slide locks.




Diagram C.