

outdoor **Smart**[©]utlets^{*}

Model: RCWFIO

Each Box Contains 1 SmartOutlet

Rated for Indoor and Outdoor use



1 Instruction Manual

Required tools: Screwdriver (not included)



SmartOutlet features:

Strain Relief: See mounting instructions

Manual Override button:

Push this button if you do not have your smartphone and need to turn the device ON or OFF

Indicator Light Color Key:

Red = Outlets are powered **Blue** = Device is connected Flashing Blue = Device is ready to connect via Wi-Fi or Bluetooth

2 Grounded Outlets: Both outlets operate in unison **Congratulations** on your purchase of PRIME **SmartOutlets**! After a fast and free download, the Prime Wire and Cable, Inc. App will walk you through the complete setup process for vour new **Smart**Outlets.

Download the Prime Wire and Cable, Inc. App on your smartphone or tablet

Scan the QR code to get the App, or search Prime Wire and Cable. Inc. in the App Store or Google Play Store





and follow the on-screen auide to add devices, set schedules, and control devices from anywhere







SAFETY INFORMATION & SPECIFICATIONS

THIS TIMER IS A "GROUNDED" DEVICE

The male plug contains a ground pin and is only intended for use with a three-pronged grounded outlet.

THIS TIMER IS FOR USE WITH A 125VAC POWER SOURCE.

 \cap

125VAC / 60Hz

DO NOT ATTACH A DEVICE THAT EXCEEDS THE UNIT RATINGS:

15A / 1875W Resistive 8A Tungsten 1/3 HP

Do not plug heaters or heat producing devices such as coffee makers, toasters, clothes irons, etc. into the SmartOutlets.

LIMITED 1 YEAR WARRANTY

Prime warrants this product to be free from manufacturing defects for a period of one year from the original date of purchase ("warranty period"). This warranty is limited to the repair or replacement of this product only and Prime is not liable for any consequential or incidental damage to other products that may be used with this unit. This warranty is effective only if such unit is returned to Prime not later than thirty (30) days after the expiration of the warranty period. Warranty is void if damage is due to neglect, misuse, alteration, modification, improper installation, or repair by other than Prime. This warranty is in lieu of all other warranties express or implied. Some provinces do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

It is our experience that a product that fails prematurely due to a manufacturing defect in materials or workmanship, will generally do so very early in the product's life cycle, often the first or second time the product is used. Products that are returned for warranty inspection after months or years of continuous reliable service are usually the result of normal wear and tear, which is not considered a defect in materials or workmanship and therefore is not covered by the warranty.

This warranty gives you specific rights, and you may also have other rights which vary from province to province. If unit should prove defective within the warranty period, return within the time period set forth above prepaid with the original purchase receipt to:

Prime Wire & Cable, Inc. ATTN: Timer Warranty 1330 Valley Vista Drive Diamond Bar, CA 91765 Service - (888) 445-9955 • www.primewirecable.com

FCC REGULATORY STATEMENT

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

 This device must accept any interference received, including interference that may cause undesired operation.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.

2. Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.

IC REGULATORY STATEMENT

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

INSTALLATION INSTRUCTIONS:

1. Install **Smart**Outlet to a vertical flat surface close to a properly installed, outdoor rated, and grounded receptacle.

2. Using a screw or hook (not included), secure the mounting tab at the top of the **smart**Outlet to a wall or post.

FAQ

- How do I turn SmartOutlet On/Off if I do not have my smartphone?
 - Press the button on the front of the SmartOutlet for manual On/Off control.
- The indicator light on the front of the SmartOutlet is not blinking rapidly. How do I make it blink rapidly, so I can connect the device?
 - Press and hold the button on the front of the SmartOutlet for 5 seconds. The indicator light in the button will begin blinking rapidly, and is ready to connect.
- What if I am unable to connect my SmartOutlet outside?
 - Bring your SmartOutlet inside and plug it in close to your router. Set up and program your SmartOutlet. Once setup is complete unplug the SmartOutlet, and take it outside for use.

· How do I add a new device?

- · Confirm device is powered on.
- Confirm device is waiting for network configuration. (indicator light on device is rapidly blinking)
- Confirm the device smartphone/tablet, and router are as close to each other as possible.
- Ensure the networks of the wireless router and smartphone/tablet are unblocked.
- · Confirm the network password is entered correctly.
- Confirm the wireless router is using a 2.4Ghz Wi-Fi Channel. Ensure the wireless router is broadcasting and the Wi-Fi signal is not hidden.
- Confirm the wireless router's encryption method is WPA2-PSK and authentication type is AES, or confirm that both are setup as automatic.
- If router enables MAC address filter, please remove the device from the MAC filter list and ensure the wireless router is allowing devices to be connected.
- For additional FAQ's please see the FAQ section in the Prime Wire and Cable, Inc. App
 - Profile -> FAQ

©2019 Prime Wire & Cable, Inc. Diamond Bar, CA 91765 Service (888) 445-9955 PST, 7am - 5pm www.primewirecable.com rev. 04-03082021 PO