



USER MANUAL

Tread Heated Socks



SAFETY INFORMATION


- If you feel heat tingling sensations or if the skin turns red, there is a risk of burns. Turn off the device immediately and stop using it. Consult a physician if you think you have a burn.
- Infants; children; persons requiring close supervision; or anyone sensitive to heat, should not use this product.
- Always check the device and it's accessories for damage before use. Do not use a damaged device. A damaged, punctured or swollen battery should NOT be charged. If you notice strange smells, sounds, smoke, liquids, stop using the device immediately.
- Do not disassemble, modify or repair your device. Use Manufacturer approved batteries, chargers, accessories and supplies.

- Do not submerge the device in water when it is connected to the battery. The device is weather resistant, not water proof. Do NOT submerge the charger.
- Avoid temperatures above 180 °F (80 °C). The batteries can explode in high temperature and fire environment. Dispose used batteries in accordance with local laws and regulations.
- The device may interfere with other electronic devices such as pacemakers and more. Do not use if you have impaired temperature sensitivity. Consult with your doctor before use.
- Keep the product out of the reach of small children, as it contains small parts which could be swallowed.
- Always turn off the device and disconnect the batteries when it is not in use or under supervision.

TREAD

HEATED SOCKS

1. Charge the USB power bank of the heated socks until the 4 blue LEDlights stop flashing. The charging time of an empty battery usually is 4-6 hours.
2. Carefully connect the fully charged power bank to the heated socks.
3. Activate the USB power bank of the heated socks by pressing the ON/OFF button 1x time quickly. Deavtivate it by pressing the ON/OFF button for 5 seconds.
4. Set a suitable heat level with the remote control. OR press the “ON/OFF” button for 3 seconds to change the temperature. The 3 Red LED-lights (L M H) indicate the heating level that is set. 3-lights (High), 2-lights (Medium), 1-light (Low).
5. You can check the battery level of the USB power bank during operation by pressing the ON/OFF button 1x time quickly. 1-light (0-25%), 2-lights (26-50%), 3-lights (51-75%), 4-lights (76-100%).



CAUTION! If you feel uncomfortable tingling heat or if the skin turns red, there is a risk of burns. Turn off the device immediately and stop use immediately. Read the safety information carefully before first use.

GENERAL ADVICE

- Tread works better when activated before feet become freezing cold. The energy that is needed to heat up cold feet will be greater making the heated socks less effective than if you activate them prior to entering cold environments.
- If you are not sure if the socks work well, turn off ONE of the two socks. Monitor the difference after 10-15 minutes.
- Avoid sweating in the shoe, moisture can cool your feet.

If the socks are NOT responding to the remote controller:

1. Press the “ON/OFF” button of the USB power bank for 5 seconds until the 3 red LED-lights start flashing.
2. Press the lowest button of the remote control to program the remote to the USB power bank.



GobiHeat.com

For any questions, comments or concerns please
email us at customerservice@gobiheat.com or
call us at (307) 840-WARM