

User Manual 6" Eyeball Gimbal Selectable Downlight SKU: DL_SG6-2750K



support@sunco.com (844) 334-9938



Whats in the Box?



Safety Information

To reduce the risk of fire, electric shock, or physical injury:

- · Turn off circuit breaker before installing this fixture.
- This product should be installed by a person familiar with the construction and operation of the product the hazards involved. Safety eyeglasses and gloves are recommended.
- · Abide by related regional and local laws or regulations.
- · Proper grounding is required to ensure safety.
- · Do not alter, relocate, or remove wiring during installation.
- Do not make or alter any open holes in wiring enclosure or electrical components during installation.
- Check for shipping damage before installing. If the product is damaged, do not use it.
- · Keep fixture away from corrosive substances.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1.) This device may not cause harmful interference.

- Suitable for damp locations at temperature ranging from 4°F to 113°F. Not for use where directly exposed to water.
- Clean the fixture regularly to ensure proper operation. Do not clean with harsh solvents.
- Use safety precautions and abide by regional and local laws or regulations.
- · This product is not compatible with 3rd party sensors.
- · This product is not compatible with photo controls.
- · This product is not compatible with occupancy sensors.
- · This product is not compatible with timing devices.

Cancer & Reproductive Harm- www.P65Warnings.ca.gov

2.) This device must accept any interference that may cause undesired operation. Please review all instructions carefully prior to installation.

Quickstart Guide



Step 1 Use template to cut hole.



Step 2 Connect supply & junction wires.



Step 3 Attach fixture to junction box.



Step 4 Insert fixture into ceiling.

Installation Guide



STEP 1

a. Turn off circuit breaker before installation.

b. Cut out 6.33" housing size on Installation Template, then tape onto ceiling in desired location.

c. Cut ceiling hole using Installation Template as a guide.



STEP 2

a. Open junction box and remove appropriate knockout.



STEP 3

a. Thread cable connector through knockout, secure wires with screws, attach cable connector nut on opposite side, & connect supply & junction wires with wire nuts.

-Black to Black (Live) ; White to White (Neutral)

b. Tuck connected wires inside junction box and close the cover.

Installation Guide (Cont.)



STEP 4

Note: This step applies exclusively to the Selectable Slims. Slide the CCT Switch to choose from 5 color temperatures. Insert junction box through ceiling hole. New Construction: Secure to studs, joists, or similar fixed structural units.

Remodel: Do not require to secure to stude, joiste, or similar fixed and the data difference.



STEP 5

a. Attach fixture to junction box using connector as shown on image (1).

b. Tighten connector by hand (2).



STEP 6

a. Adjust flexible optic position to aim light beam where needed. Gimbal rotates 360° and tilts 35°.

b. Raise spring clips to insert the luminaire in the ceiling opening. Turn on circuit breaker & test the light.

Recommended Dimmers

Scan for 4
Scan for the full
compatible dimmer list!
ust!

Brand	Model
LUTRON	P-PKG1WB-WH
LUTRON	MACL-153M-WH
LUTRON	PD-6WCL-WH
LUTRON	AYCL-153P-WH
LUTRON	DVCL-153P-WH
LEVITON	D26HD-2RW
KASA SMART	HS220
KASA SMART	HS220P3



Specifications

Voltage	120V	Average Lifetime	50000 hrs
Wattage	12W	Lumens	1350lm
Frequency	60Hz	Moisture Rating	Damp
Beam Angle	90°	CRI	90+
Weight	0.7lbs	Usage	Indoor
Housing Material	Aluminium+Plastic	IC Rated	Yes
Dimmable	Yes	Warranty	7 Years

Common Troubleshooting

Feeling in the dark about an issue with your product? No worries! Our troubleshooting section is here to shed some light and provide you with easy-to-follow solutions for any problem.

If you still need some assistance, please feel free to contact us with any questions. Our team of lighting experts are happy to help brighten your day.

Installation	
Light isn't turning on.	Double check if fixture is properly connected and circuit breaker hasn't been tripped.
Light unexpectedly fails.	For further assistance, contact our customer support.
Light not dimming to lowest setting.	Ensure minimum dimmer load requirement is met.
Light not dimming smoothly.	Verify dimmer compatibility with fixture.
Light not compatible with dimmer switch.	Check light-dimmer compatibility. Consider purchasing compatible switch if necessary.
Light is flickering when turning on.	Check that fixture wiring connections are secure.
Light flickering with other lights on the same circuit.	Check that the lights on the same circuit are not overloading the circuit.
Light flickering when turned on.	Verify fixture compatibility.
Light flickering when dimmed.	Verify dimmer switch compatibility.
Fixture buzzing with power outages.	Verify light is connected to surge protector securely.
Fixture buzzing with appliances or electronic devices.	Look for nearby interferences that can cause buzzing. Such as televisions, radios, computers, etc.
Fixture buzzing when dimmed.	Verify dimmer switch compatibility.

Light Distribution Angle



Lighting distribution angle refers to the spread of light emitted from a light source. It is an important factor to consider when selecting a fixture or bulb, as it affects the way it will illuminate an area. There are two main types of lighting distribution angles:

A symmetric lighting distribution emits light evenly in all directions, creating a cone-shaped pattern that provides a pool of light. This type of lighting is ideal for general lighting and illuminating large areas. Common applications for symmetric lighting include general area illumination, security lighting, and perimeter lighting. Symmetric lighting is also used to a certain degree in up-lighting. An asymmetric lighting distribution angle, also known as beam angle, creates a pattern that focuses light in a specific direction. This type of lighting is ideal for task lighting as it reduces glare and light spill in other areas. Common applications include task lighting in spaces such as landscape settings, retail stores, museums, and much more.

It is important to note that the lighting distribution angle can also be affected by other factors such as the reflector design of the light source, the type of lens used, and the distance between the light source and the surface being illuminated.

Warranty Policy

This product is covered by our industry leading 7 year warranty.

It gets even better - scan the QR code for 2 extra years of protection!



30 Day Return Policy

At Sunco we value our customers and stand by the quality and performance of our products.

If you are not completely satisfied with your purchase, we accept returns within 30 days of your purchase date.

Customer Service

Our Los Angeles team of lighting experts is here to assist you with all your needs! Contact us at:

Email: support@sunco.com

Call or Text: (844) 334-9938



support@sunco.com (844) 334-9938

