

# ALIGN WATCH BAND ADJUSTMENT

## STEP 1: RELEASE THE BUCKLE

- Locate a small metal tool with a pointed end, such as a glasses screwdriver or a bobby pin.
- Insert the pointed end into the opening of the watch buckle.
- Gently apply downward pressure to pop open the inner part of the buckle, allowing it to slide freely along the mesh strap.

## STEP 2: ADJUST TO FIT

- Slide the movable buckle to your preferred position on the strap. Remember: bringing the buckle closer to the watch case will make the strap tighter on your wrist.

Position the buckle to 'align' with the grooves on the back of the strap.

## STEP 3: LOCK THE BUCKLE

- Place the adjusted strap on a flat surface.
- Firmly press down on the released portion of the buckle using your finger. For a gentler touch, you can use the eraser end of a pencil or another soft object, ensuring no scratches on the buckle.
- Press until the buckle snaps back into its original locked position.

Finally, try the watch on to check for comfort. If it doesn't feel just right, simply repeat the steps until you achieve the perfect fit.