

Installation and Operation Instructions Stick-A-LED™ Self Adhesive <u>LED Warning Lights</u>

Stick-A-LED™ warning lights are compact, high intensity auxiliary LEDs designed to provide a powerful warning signal with fast and easy installation. The Stick-A-LED™ requires only a single (wiring) hole and simple two wire connection to install, no fasteners are needed. The self-adhesive, peel and stick backing allows placement on any flat surface. Available in 3 shapes; Oval (3 LEDs), Triangle (3 LEDs) and Rectangle (6 LEDs), each model features a tough polycarbonate base and lens with integrated optics that provide enhanced light dispersion.



IMPORTANT! Read all instructions before installing and using. Installer: This manual must be delivered to the end user.



WARNING!

Failure to install or use this product according to manufacturers recommendations may result in property damage, serious injury, and/or death to those you are seeking to protect!



Do not install and/or operate this safety product unless you have read and understand the safety information contained

- Proper installation combined with operator training in the use, care, and maintenance of emergency warning devices are essential to ensure
 the safety of you and those you are seeking to protect.
- 2. Exercise caution when working with live electrical connections.
- This product must be properly grounded. Inadequate grounding and/or shorting of electrical connections can cause high current arcing, which can cause personal injury and/or severe vehicle damage, including fire.
- 4. Proper placement and installation are vital to the performance of this warning device. Install this product so that output performance of the system is maximized and the controls are placed within convenient reach of the operator so that s/he can operate the system without losing eye contact with the roadway.
- 5. Do not install this product or route any wires in the deployment area of an air bag. Equipment mounted or located in an air bag deployment area may reduce the effectiveness of the air bag or become a projectile that could cause serious personal injury or death. Refer to the vehicle owner's manual for the air bag deployment area. It is the responsibility of the user/operator to determine a suitable mounting location ensuring the safety of all passengers inside the vehicle particularly avoiding areas of potential head impact.
- It is the responsibility of the vehicle operator to ensure during use that all features of this product work correctly. In use, the vehicle operator should ensure the projection of the warning signal is not blocked by vehicle components (i.e., open trunks or compartment doors), people, vehicles or other obstructions.
- 7. The use of this or any other warning device does not ensure all drivers can or will observe or react to a warning signal. Never take the right-of-way for granted. It is your responsibility to be sure you can proceed safely before entering an intersection, driving against traffic, responding at a high rate of speed, or walking on or around traffic lanes.
- 8. This equipment is intended for use by authorized personnel only. The user is responsible for understanding and obeying all laws regarding warning signal devices. Therefore, the user should check all applicable city, state, and federal laws and regulations. The manufacturer assumes no liability for any loss resulting from the use of this warning device.

Specifications:

\text{Voltage:} 12-24 VDC
Current: Rectangular: 0.90 Amps
CovalTriangle: 0.45 Amps
1 oz.
Lumens: OvalTriangle: \text{Yellow/Red} 120
White 180
Blue 45
Rectangle: \text{Yellow/Red} 240
White 380
Blue 45
Rectangle: \text{Yellow/Red} 240
White 980
Rectangle: 091
R

Installation:

Before installation, examine the LED heads for transit damage. Do not use damaged or broken parts. Drill 1/4" dia. hole for wire exit. Remove sticky backing, apply to surface and press firmly. For best results, mount LED head to a flat surface.

Wiring Instructions:

Black Wire: Ground

Red Wire: Connect to fused power for quad flash Size fuse according to the number of heads in the system.