

# 308-1412 FAQs

The links below will work in most PDF viewers and link to the topic area by clicking the link. We recommend Adobe Reader version 10 or greater available at: <http://get.adobe.com/reader>

## CONTENTS

|   |   |
|---|---|
| <b>308-1412 FAQs</b> .....                                    | 1 |
| <b>AC Power</b> .....   | 2 |
| <b>Batteries</b> .....  | 2 |
| <b>Forecast Station Factory Restart</b> .....                 | 2 |
| <b>Outdoor Temperature Sensor</b> .....                       | 3 |
| Compatible Outdoor Sensors .....                              | 3 |
| Quick Connect.....  | 3 |
| Outdoor Temperature Signal Strength .....                     | 3 |
| Dashes show for Outdoor Temperature.....                      | 3 |
| Power Requirements .....                                      | 3 |
| Inaccurate Outdoor Temperature Reading .....                  | 3 |
| Intermittent Outdoor Temperature/Humidity.....                | 4 |
| Outdoor Temperature is stuck or HH.H, LL.L.....               | 4 |
| Outdoor sensor drains batteries quickly.....                  | 4 |
| Outdoor sensor fell. The sensor no longer works.....          | 4 |
| Temperature Trend Arrows.....                                 | 5 |
| MIN/MAX Temperature readings .....                            | 5 |
| Heat Index/Dew Point temperature.....                         | 5 |
| Mounting/Positioning Outdoor sensor.....                      | 6 |
| Position Forecast station .....                               | 6 |
| Distance/Resistance/Interference .....                        | 6 |
| <b>Temperature Alerts</b> .....                               | 7 |
| <b>Forecast Station</b> .....                                 | 8 |
| How tall are the time numbers? .....                          | 8 |
| Power Requirements .....                                      | 8 |
| 12-Hour or 24-Hour time format.....                           | 8 |
| Fahrenheit/Celsius.....                                       | 8 |
| Backlight.....  | 8 |
| Dashes, HH.H, LL.L or stuck Indoor Temperature/Humidity ..... | 8 |
| Inaccurate Indoor Temperature Reading .....                   | 8 |
| Set Time Alarm.....   | 9 |
| Activate/Deactivate time alarm .....                          | 9 |

|  |    |
|--|----|
| Snooze Alarm.....  | 9  |
| Time is off by hours .....   | 9  |
| Manually Set Time/Date: Program Menu .....                           | 9  |
| USB Charge Port.....   | 9  |
| Forecast Icons Inaccurate .....                                      | 10 |
| Forecast Trend Arrows .....  | 10 |
| Forecast station is dim.....   | 10 |
| Forecast station has distorted or frozen display.....                | 10 |
| Forecast station is blank: No letters, numbers or dashed lines ..... | 10 |
| Forecast station drains batteries quickly .....                      | 11 |
| Forecast station has missing segments .....                          | 11 |

## AC Power

- ✓ The design of this forecast station is to use AC power (5-volt) as primary power source.
- ✓ When operating with the AC power cord, the [backlight](#) can be on continually.
- ✓ When operating on AC power, batteries are optional and are not required in the forecast station.
- ✓ The [backlight](#) will turn off or operate at high or low intensity at your discretion.

## Batteries

**Explanation:** Many problems are resolved with fresh batteries of the appropriate voltage. Many items sent in under warranty work when tested with fresh batteries. Batteries manufactured this year will have an expiration date 10 years (or more) in the future. Battery technology has improved and batteries will maintain voltage longer in storage. However, the environment the batteries reside in for the 10 years can deplete the power.

- ✓ We suggest name brand Alkaline batteries for **indoor displays**.
- ✓ Use Alkaline or Lithium batteries in the **outdoor sensors**.
- ✓ A minimum voltage of 1.48V for each battery is necessary for proper performance.
- ✓ Use batteries dated at least six years in advance of the current year. Batteries dated earlier than six years from now may still work, but may be unstable in performance.
- ✓ Good name brand batteries make less noise, which reduces the chance of RF (radio frequency) interference from the battery compartment.

## Forecast Station Factory Restart

**Explanation:** The factory restart returns the forecast station and outdoor sensor to an “out-of-the-box” state and often resolves an issue.

### Factory Restart:

1. Remove all power (batteries and AC) from outdoor sensor and forecast station.
2. Press one of the buttons on the forecast station at least 20 times to clear all memory.
3. Verify that the forecast station is blank before proceeding (there are some painted lines that will not disappear).
4. **Leave both units without power for 15 minutes** (very important).
5. Insert the AC power cord into the wall outlet then into the forecast station.
6. Insert fresh batteries into the outdoor sensor.
7. Press the TX button on the outdoor sensor to transmit RF signal.
8. Keep the outdoor sensor 5-10 feet from the forecast station.
9. When RF connection is established, the temperature will appear on the station. Allow the outdoor sensor and forecast station to sit together for 15 minutes to establish a strong connection.
10. Do not press buttons for 15 minutes.

- ✓ For optimum 433MHz transmission, place the outdoor sensor no more than 200 feet (60 meters, open air) from the forecast station.
- ✓ See the section on [mounting](#) and [distance/resistance/interference](#) for details on mounting the outdoor sensor.

## Outdoor Temperature Sensor

### Compatible Outdoor Sensors

- ✓ The TX141TH-B outdoor sensor comes packaged with this forecast station.
- ✓ The TX141TH-A and TX141TH-B (433MHz) outdoor sensors are compatible with this forecast station.

### Quick Connect

**Explanation:** Use the quick connect for a forecast station and outdoor sensor that have been working but lost connection due to interference or low batteries. This is not the same as a thorough factory reset.

1. Bring the outdoor sensor, forecast station together inside, and place the units 5-10 feet apart with nothing between them.
  2. Hold the SENSOR SEARCH button on the forecast station. The outdoor temperature area will flash.
  3. Remove battery cover from the outdoor sensor and press and release the TX button to send the signal.
  4. Wait for 2 minutes for the outdoor temperature to appear on the forecast station.
- ✓ [Factory Restart](#): If the above procedure does not work, please try the factory reset.

### Outdoor Temperature Signal Strength

**Explanation:** The forecast station will search for the outdoor temperature/humidity outdoor sensor for 3 minutes after batteries are installed or when the SENSOR SEARCH button is held for 3 seconds.

- ✓ The antenna symbol will flash during reception.
- ✓ The temperature display will be dashes “---”.
- ✓ If synchronization fails once, the antenna will lose one bar.
- ✓ If synchronization fails twice, the antenna will lose two bars.
- ✓ If RF (radio frequency) reception fails five times, the antenna symbol will show without bars.
- ✓ The antenna will show full display with successful RF (radio frequency) reception.

### Dashes show for Outdoor Temperature

**Explanation:** Dashes mean the connection is lost between the forecast station and the outdoor sensor.

- ✓ [Batteries](#) often resolve the connection.
- ✓ [Distance/Resistance](#) can cause loss of connection between the outdoor sensor and the forecast station.
- ✓ Turn the forecast station 90 degrees towards the outdoor sensor to provide better reception. This allows more antenna surface to face the outdoor sensor signal.
- ✓ Try the [quick connect](#) or [factory restart](#).

### Power Requirements

- ✓ 2-AA [batteries](#) power the outdoor sensor.
- ✓ We recommend Alkaline batteries for the outdoor sensor.
- ✓ You may choose to use Lithium batteries for temperatures below -20°F/-28.8°C.

### Inaccurate Outdoor Temperature Reading

**Explanation:** High outdoor temperature readings are generally a location issue. Low outdoor temperature readings are power related or a sensors going bad.

- ✓ The outdoor sensor reads the environment where it is mounted. When mounted inside the home, it will read inside temperature/humidity.
- ✓ When the outdoor sensor reads high during the day, but not at night, it is a [positioning](#) problem.
- ✓ Look for heat sources such as sunlight, door or window frames or reflected heat.

**Side-by-side test:** Bring the outdoor sensor in the house and place it next to the forecast station for 2 hours.

- ✓ Compare indoor and outdoor temperature. The temperatures should be within 4 degrees to be within tolerance.
- ✓ If the outdoor sensor reads correctly when next to the forecast station, try a different location outside.

### Intermittent Outdoor Temperature/Humidity

**Explanation:** Intermittent problems are the hardest to resolve. RF (radio frequency) communication may come and go occasionally. This can be normal in some environments (e.g. moister climates). If outdoor sensor signal is lost, please wait 2-4 hours for the signal to reconnect on its own.

- ✓ Move the outdoor sensor to a closer location.
- ✓ [Distance/Resistance](#) can cause loss of outdoor sensor signal.
- ✓ Check [Batteries](#).

**Freezer test:** Confirm the forecast station is reading the correct outdoor sensor. Place the outdoor sensor in the freezer for an hour and watch the temperature drop on the forecast station.

**Indoor distance test:** Please complete the [Restart](#) with outdoor sensor and forecast station 5-10 feet apart and inside to establish a strong connection.

- ✓ After 15 minutes, if there is a reading in the outdoor temperature area, move the outdoor sensor to another room with one wall between the outdoor sensor and the forecast station.
- ✓ Observe to see if the temperature remains on consistently for 1 hour.
- ✓ If the temperature remains on while in the house, then it is likely a [distance/resistance](#) issue.
- ✓ Move the outdoor sensor to different locations outside to find a location where the temperature reading will hold.

### Outdoor Temperature is stuck or HH.H, LL.L

**Explanation:** These symbols are error messages indicating the outdoor sensor is outside of its readable range.

- ✓ Check [Batteries](#). Overpowered or underpowered batteries can cause this reading.
- ✓ Replace outdoor sensor.

**Note:** The last outdoor reading may remain (not change) for several hours when connection is lost. The outdoor temperature reading will flash when the connection is first lost or intermittent.

### Outdoor sensor drains batteries quickly

- ✓ Test a new set of alkaline batteries. Write down the date of installation and the voltage of the batteries.
- ✓ When the batteries fail, please note the date and voltage again.
- ✓ Check the [distance](#) and [resistance](#) between the outdoor sensor and forecast station. Outdoor sensors at the end of the range may work while batteries are fresh but not after they drain a bit.
- ✓ Check for leaking batteries, which may damage the outdoor sensor.
- ✓ Battery life is over 24 months when using reputable battery brands for both Alkaline and Lithium batteries.

### Outdoor sensor fell. The sensor no longer works

**Explanation:** If there is no physical damage to the outdoor sensor, the fall may not have caused internal damage. A fall can shock the outdoor sensor or the batteries in the outdoor sensor. Batteries that have fallen on a hard surface may be damaged and unable to function properly.

- ✓ Complete a [Restart](#) with fresh batteries.
- ✓ Use [Batteries](#) dated at least six years in advance of the current year. Batteries dated earlier than six years from now may still work, but may be unstable in performance.

**Note:** An outdoor sensor that has fallen into puddle, snow, or other standing water, will likely have water damage and need to be replaced. Outdoor sensors are water resistant, not waterproof.

### Replacement Outdoor Sensors

- ✓ Visit your local Retailer or La Crosse Technology® Store <http://store.lacrossetechnology.com/>  
**Note:** Be sure to order the correct model and frequency to avoid receiving the incorrect item.
- ✓ Call La Crosse Technology® Store at **608-785-7939** or e-mail from the store website if you are unsure about the correct item to order. Each item carries the original new product warranty and includes access to La Crosse Technology technical support.

### Temperature Trend Arrows

**Explanation:** The indoor and outdoor temperature trend indicators will update every 30 minutes or less. These trends represent temperature changes over the past three hours.

- ✓ UP ARROW: Temperature rose more than 2°F /1°C in the past three hours
- ✓ RIGHT ARROW: Temperature has **not changed** more than 2°F /1°C in the past three hours
- ✓ DOWN ARROW: Temperature fell more than 2°F /1°C in the past three hours

### MIN/MAX Temperature readings

**Explanation:** The forecast station shows the daily minimum and maximum temperatures each day starting at midnight (12:00 AM). The forecast station automatically resets the MIN/MAX temperatures at midnight (12:00 AM).

- ✓ **View MIN data:** Press and release the MIN TEMP button to view the minimum Indoor and Outdoor Temperatures.
- ✓ **Reset MIN data:** Hold the MIN TEMP button for 5 seconds and the Indoor and all Outdoor Minimum Temperatures will reset. The temperature area will show dashes briefly then return to current temperatures.
- ✓ **View MAX data:** Press and release the MAX TEMP button to view the maximum Indoor and Outdoor Temperatures.
- ✓ **Reset MAX data:** Hold the MAX TEMP button for 5 seconds and the Indoor and all Outdoor Maximum Temperatures will reset. The temperature area will show dashes briefly then return to current temperatures

### Heat Index/Dew Point temperature

#### Heat Index:

- ✓ Heat Index combines the effects of heat and humidity.
- ✓ It is the apparent temperature of how hot it feels to a human being.
- ✓ As humidity increases, the body is unable to cool effectively.
- ✓ The temperature will feel warmer.

**View Heat Index:** From a normal display, press the HEAT/DEW button once and Heat Index will show instead of the outdoor ambient temperature.

**Note:** Heat index will be the same number as the temperature until the outdoor temperature is above 26.7°C (80°F).

#### Dew Point Temperature:

- ✓ Dew Point Temperature is the saturation point of the air, or the temperature to which the air has to cool in order to create condensation.
- ✓ The higher the dew points, the higher the moisture content of the air at a given temperature.

**View Dew Point Temperature:** From a normal display, press the HEAT/DEW button twice and Dew Point will show instead of the outdoor ambient temperature. The words “Dew Point” will show near outdoor temperatures.

**Note:** Dew Point is lower than the actual temperature.

### Mounting/Positioning Outdoor sensor

**First:** Place the outdoor sensor in the desired shaded location and the forecast station in the home. Wait approximately 1 hour before permanently mounting the outdoor sensor to ensure that there is proper reception.

#### POSITION

- ✓ Mount outdoor temperature outdoor sensors **vertically**.
- ✓ Protect the outdoor sensor from standing rain or snow and from the overhead sun, which can cause it to read incorrectly.
- ✓ Mounting under an eave or deck rail works well.
- ✓ If you choose, you can construct a small roof or box for the outdoor sensor. Be sure a box has vents.
- ✓ Mount the outdoor sensor on the North side where to prevent sun from causing incorrect readings.
- ✓ Mount at least 6 feet in the air for a strong RF (radio frequency) signal.
- ✓ Outdoor sensors are water resistant, not waterproof.
- ✓ Avoid more than one wall between the outdoor sensor and the forecast station.
- ✓ The maximum transmitting range in open air is over 200 feet (60 meters).
- ✓ Obstacles such as walls, windows, stucco, concrete and large metal objects can reduce the range.
- ✓ Do not mount near electrical wires, transmitting antennas or other items that will interfere with the signal.
- ✓ RF (radio frequency) signals do not travel well through moisture or dirt.
- ✓ Do not mount the outdoor sensor on a metal fence. This significantly reduces the effective range.

#### MOUNT

##### Option 1:

- ✓ Install one mounting screw (not included) into a wall.
- ✓ Place the outdoor sensor onto the screw (hanging hole on the backside).
- ✓ Gently pull down to lock the screw in place.

##### Option 2:

- ✓ Insert the mounting screw through the front of the outdoor sensor and into the wall.
- ✓ Tighten the screw to snug (do not over tighten).

### Position Forecast station

- ✓ The forecast station has a wide base to sit on a desk or table.
- ✓ Place within range of the outdoor sensor.
- ✓ The maximum transmitting range in open air is 200 feet (60 meters).
- ✓ Obstacles such as walls, windows, stucco, concrete and large metal objects can reduce the range.
- ✓ Choose a location 6 feet or more from electronics such as cordless phones, wireless gaming systems, televisions, microwaves, routers, baby monitors, etc., which can prevent signal reception.
- ✓ Be aware of electrical wires and plumbing within a wall. This will interfere with RF (radio frequency) signal reception.

### Distance/Resistance/Interference

#### Distance:

- ✓ The maximum transmitting range in open air is over 200 feet (60 meters) between the outdoor sensor and the forecast station. This range is in open air with ideal conditions.
- ✓ Consider what is in the signal path between the forecast station and the outdoor sensor.
- ✓ Avoid placing electronic in the signal path between the forecast station and the outdoor sensor.

#### Resistance:

- ✓ Obstacles such as walls, windows, stucco, concrete and large metal objects can reduce the range.

- ✓ When considering the distance between the outdoor sensor and the forecast station (200 feet open air), cut that distance in half for each wall, window, tree, bush or other obstruction in the signal path.
- ✓ Closer is better.
- ✓ Windows reflect the RF (radio frequency) signal.
- ✓ Metal absorbs the signal and reduces the range.
- ✓ Stucco has a metal mesh that absorbs the signal.
- ✓ Do not mount the outdoor sensor on a metal fence. This significantly reduces the effective range.

#### **Interference:**

- ✓ Consider items in the signal path between the outdoor sensor and the forecast station.
- ✓ Sometimes a simple relocation of the outdoor sensor or the forecast station will correct the interference.
- ✓ Windows can reflect the radio signal.
- ✓ Metal will absorb the RF (radio frequency) signal.
- ✓ Stucco has a metal mesh that absorbs signal.
- ✓ Avoid transmitting antennas: (ham radios, emergency dispatch centers, airports, military bases, etc.)
- ✓ Electrical wires (utilities, cable, etc.)
- ✓ Vegetation is full of moisture and reduces signal.
- ✓ It is difficult for RF (radio frequency) signal to travel through a hill.

### **Temperature Alerts**

**Explanation:** The outdoor and indoor temperature alerts are set in two separate steps.

- ✓ Set the alert value.
- ✓ Arm/Disarm the alert.

#### Select Temperature Alert Values:

Hold the TEMP ALERT button for five seconds to select and set temperature alert values.

1. **OUTDOOR HI** alert will flash. Press the ARROW buttons to set the alert value, and press the TEMP ALERT button to confirm and switch to OUTDOOR LOW setting.
2. **OUTDOOR LO** alert will flash. Press the ARROW buttons to set the alert value, and press the TEMP ALERT button to confirm and switch to INDOOR HI setting.
3. **INDOOR HI** alert will flash. Press the ARROW buttons to set the alert value, and press the TEMP ALERT button to confirm and switch to INDOOR LOW setting.
4. **INDOOR LO** alert will flash. Press the ARROW buttons to choose the value, and press the TEMP ALERT button to confirm and exit.

**Note:** After selecting temperature alert values, use the next step to arm or disarm individual alerts.

#### Arm/Disarm Temperature Alerts

1. In normal mode, hold then release the TEMP ALERT button to toggle the alerts:
  - Outdoor HI
  - Outdoor LO
  - Indoor HI
  - Indoor LO
2. Press the UP ARROW button to arm the selected alert. The alert icon (bell) appears next to the alert, when the alert is active.
3. Press the DOWN ARROW button to disarm the selected alert.

**Note:** When no temperature alerts are set, the Temperature Alert area will show ALERTS OFF.

#### Active Temperature Alert

- ✓ When temperature alert sounds, the corresponding alert icon (bell) will flash.
- ✓ The alert beeps once every minute, until the temperature is out of alert range.
- ✓ Press any button to stop alert. The alert symbol will still show.
- ✓

## Forecast Station

### How tall are the time numbers?

The time numbers are 0.59 inches tall.

### Power Requirements

- ✓ This forecast station is powered by a 5 volt AC power adapter
- ✓ Alternatively, optional 3-AAA alkaline batteries may be used.

### 12-Hour or 24-Hour time format

- ✓ Time can display in 12-hour (am, pm) or 24-hour format.
- ✓ Default is 12-hour time.
- ✓ Use the [Program Menu](#) to switch time formats.

### Fahrenheit/Celsius

- ✓ Use the [program menu](#) to switch between Fahrenheit and Celsius.

### Backlight

**AC adapter:** The backlight is on continuously when operating the Forecast Station with the 5-volt AC adapter.

**Note:** When the AC adapter is NOT in use, the HI/LOW/OFF light feature is not available.

- ✓ **HIGH:** The backlight is defaulted to HI at setup when the AC adapter is in use.
- ✓ **LOW:** Press and release the HI/LOW/OFF button to dim the backlight.
- ✓ **OFF:** Press and release the HI/LOW/OFF button again to turn the backlight off. Press and release the HI/LOW/OFF button to return to full strength.

**Note:** When the backlight is off, press any button to activate the backlight for 10 seconds.

**Battery power:** When operating on battery power only, press and release the any button and the backlight will show for 10 seconds.

### Dashes, HH.H, LL.L or stuck Indoor Temperature/Humidity

**Explanation:** These symbols are error messages indication the indoor sensor is outside of its readable range. For indoor readings, this is generally a power related issue.

- ✓ [Batteries](#) may be overpowered or underpowered. Remove batteries from the forecast station.
- ✓ Press any button 20 times. Leave the forecast station unpowered for 1-2 hours.
- ✓ Install fresh Alkaline batteries with correct polarity.
- ✓ If the indoor temperature is still shows dashes, HH.H or LL.L, the forecast station may need replacement.

### Inaccurate Indoor Temperature Reading

**Explanation:** When the indoor temperature is inaccurate, it is often due to the location of the display or overpowered/under powered batteries. You can test the accuracy at you home.

**Side-by-side test:** Bring the outdoor sensor in the house and place it next to the forecast station for 2 hours.

- ✓ Compare indoor and outdoor temperature. The temperature should be within 4 degrees to be within tolerance.
- ✓ Look for heat sources such as sunlight, door or window frames or reflected heat or cold near the forecast station.

**Check [batteries](#).**

## Set Time Alarm

In normal mode, hold the TIME ALARM button for three seconds to enter alarm set mode.

1. HOUR: The **Hour** will flash, use the ARROW buttons to set the hour, and press TIME ALARM button to confirm and switch to minutes.
2. MINUTES: The **Minutes** will flash, use the ARROW buttons to set the minutes, and press TIME ALARM button to confirm.
3. Press the SETTINGS button to return to normal mode.

**Note:** When no buttons are pressed for ten seconds, the forecast station will save the last change and default back to normal mode

## Activate/Deactivate time alarm

- ✓ In normal mode, press and release the TIME ALARM button once to show alarm time.
- ✓ Press and release the TIME ALARM button repeatedly to turn ON/OFF alarm.
- ✓ The alarm icon  appears when alarm is active.
- ✓ **Note:** The alarm will ring for 2 minutes then turn off if no buttons are pressed.

## Snooze Alarm

- ✓ When the alarm sounds, press the HI/LOW/OFF button to snooze the alarm for 10 minutes.
- ✓ The snooze option can repeat three times.
- ✓ The alarm icon  will flash while the snooze feature is active.
- ✓ **Note:** while the alarm sounds press any button **except** the TIME ALARM button to turn the alarm off.

## Time is off by hours

- ✓ This forecast station has manual set time.
- ✓ Use the [program menu](#) to set the time.

## Manually Set Time/Date: Program Menu

Hold the SETTINGS button for three seconds to enter time set mode.

1. 12/24-HOUR: The time format **12H** will flash, use the ARROW buttons to choose 12-hour or 24-hour time format and press the SETTINGS button to confirm and move to hour.
2. HOUR: The **Hour** will flash, use the ARROW buttons to choose the hour, and press the SETTINGS button to confirm and move to minutes.
3. MINUTES: The **Minutes** will flash, use the ARROW buttons to choose the minutes, and press the SETTINGS button to confirm and move to the year.
4. YEAR: The **Year** will flash, use the ARROW buttons to choose the year, and press the SETTINGS button to confirm and move to the month.
5. MONTH: The **Month** will flash, use the ARROW buttons to choose the month, and press the SETTINGS button to confirm and move to the date.
6. DATE: The **Date** will flash, use the ARROW buttons to choose the date, and press the SETTINGS button to confirm and move to Fahrenheit/Celsius.
7. FAHRENHEIT/CELSIUS: **°F or °C** will flash. Use the ARROW buttons button to select Fahrenheit or Celsius. Press and release the SETTINGS button to confirm and exit the program menu.

**Note:** When no buttons are pressed for ten seconds, the forecast station will save the last change and default back to normal mode.

## USB Charge Port

**Explanation:** The forecast station has an integrated USB charging port (on back) that will charge a device when the forecast station is plugged into a power outlet.

**Note:** This is a power-output charging port. It does not supply power to the forecast station.

- ✓ Connect your external device's USB charging cable (not included) to the USB charging port.
- ✓ Charging times will vary.
- ✓ USB Power Output: 1A maximum current. Charge 1A devices or devices that are self-regulating.

**Note:** Some USB cables are for data transfer only and cannot be used for charging. Make sure that the USB cable you use will charge your device. Most USB cables included with mobile devices will work for charging.

**Note:** Many devices may require more power to charge than provided by this forecast station.

### Forecast Icons Inaccurate

#### **THIS FORECAST STATION LEARNS OVER TIME!**

Please allow 3-4 weeks for barometer calibration to generate an accurate forecast.

**IMPORTANT:** As the Forecast Station builds memory, it will compare the current average pressure to the past forty day average pressure for increased accuracy. The longer the Forecast Station operates in one location, the more accurate the forecast icons will be.

**Weather Forecast Icons:** This Forecast Station has five forecast icons that predict the weather condition of the next 12-hours based on the change of atmospheric pressure.

- ✓ Sunny
- ✓ Partly Cloudy
- ✓ Cloudy
- ✓ Rainy
- ✓ Stormy

The icons forecast the weather in terms of getting better or worse and not necessarily sunny or rainy, as each icon indicates.

The weather forecast is about 70-75% correct. As weather conditions cannot be 100% correctly forecasted, we are not responsible for any loss caused by an incorrect forecast.

### Forecast Trend Arrows

The forecast trend arrows in the upper right corner of the forecast display indicate the rising or falling pressure trend.

- ✓ The UP trending arrow indicates the weather is improving.
- ✓ The DOWN trending arrow indicates the weather may worsen.
- ✓ When there is no arrow, the pressure is steady.

### Forecast station is dim

**Explanation:** Most forecast stations have a gray background. Place the forecast station at eye level, to determine if it is dim. Forecast stations that sit in the sunlight can develop a cloudy film over time.

- ✓ This is generally a power related issue.
- ✓ [Batteries](#) may be overpowered or underpowered. Remove batteries from forecast station.
- ✓ Press any button 20 times. Leave the forecast station unpowered for 1-2 hours.
- ✓ Install fresh alkaline batteries with correct polarity.

### Forecast station has distorted or frozen display

**Explanation:** On a brand new forecast station, check for thin plastic film of **printed scratch guard** that may be on the screen of the forecast station. This thin piece of plastic has printed numbers for store displays. When the batteries are installed, the "real" numbers show behind the printed scratch guard and create distortion.

- ✓ With all power removed, the forecast station should be blank.
- ✓ If numbers still appear, please check for scratch guard.

#### **Power:**

- ✓ Check that the batteries are installed correctly.
- ✓ This is generally a power related issue.
- ✓ [Batteries](#) may be overpowered or underpowered.
- ✓ Remove batteries from forecast station.
- ✓ Press any button 20 times. Leave the batteries out of the display for 2 hours.
- ✓ Insert batteries into the forecast station.

### Forecast station is blank: No letters, numbers or dashed lines

- ✓ Check that the batteries are installed correctly.
- ✓ [Batteries](#) may be overpowered or underpowered.

- ✓ Remove batteries from forecast station.
- ✓ Press any button 20 times. Leave the batteries out of the display for 2 hours.
- ✓ Insert batteries into the forecast station.

#### Forecast station drains batteries quickly

- ✓ Test a new set of alkaline batteries. Write down the date of installation and the voltage of the batteries.
- ✓ When the batteries fail, please note the date and voltage again. This is helpful in determining the problem.
- ✓ Check for leaking batteries, which may damage the forecast station.
- ✓ Battery life is over 12 months when using reputable battery brands.

#### Forecast station has missing segments

**Explanation:** When parts of numbers, letters, or pictures are missing on the display, it is often power related.

- ✓ Batteries may be overpowered or underpowered. Remove batteries from forecast station.
- ✓ Press any button 20 times. Leave the forecast station unpowered for 1-2 hours.
- ✓ Install fresh alkaline batteries with correct polarity.