

WIRELESS TEMPERATURE STATION

QUICK START GUIDE




MODEL: 308-1415BW
DC: 062018


POWER UP

1. Insert 2-AA batteries into your Outdoor Sensor.
2. Insert 2-AA batteries into your Temperature Station.
3. Adjust time and date settings on the station.
4. Once the Outdoor Sensor is reading to your station, place it outside in a shaded location.

Watch sensor mounting video: http://bit.ly/TH_SensorMounting




Outdoor Sensor
TX141-Bv2



Temperature Station
308-1415BW

CUSTOM DATE DISPLAY

- Press the SET button to select between full Weekday or Calendar (Weekday, Month, Date) display.



SETTINGS

1. Hold the SET button to enter the Settings Menu.
2. Use the + or - button to adjust and SET to confirm.

Settings Menu order:

- Language (English, Spanish, French)
- Beep ON/OFF
- 12/24 Hour Time
- Hour
- Minutes
- Year
- Month
- Date
- Month/Date or Date/Month Display (see below)
- Fahrenheit/Celsius

Note: When Español or Français is selected, the following instructions and weekday will be presented in that language.

Note: Weekday sets automatically when Year, Month and Date are set.

MONTH/DATE OR DATE/MONTH

- In the Settings Menu, choose Month/Date or Date/Month calendar display.




ALARM

1. Hold the ALARM button until the Alarm Hour begins to flash.
2. Press the + or - button to adjust values, hold to adjust quickly.
3. Press the ALARM button to confirm and move to the Alarm Minutes.
4. Use the + or - buttons again to adjust, and press ALARM to confirm and activate the alarm.

Note: This station uses a crescendo alarm, which will increase in volume over time. If no buttons are pressed within 2 minutes, it will shut off automatically.

DEACTIVATE/ACTIVATE ALARM 🔔

- Press and release the ALARM button to deactivate or activate the alarm. The alarm time will show for 2 seconds.
- Alarm Icon (bell) and ALARM ON will show when active
- ALARM OFF will show when inactive.




SNOOZE

- When alarm sounds, press the ALARM button to silence alarm for 10 minutes.
- The Alarm Icon will flash
- Press any button except ALARM to silence the alarm for 24 hours

HI & LO TEMPERATURE RECORDS

- Press and release the PLUS (+) button to view HI/LO temperature readings with time/date stamp. Continue pressing the PLUS (+) button to cycle through:
 - Outdoor temperature HI
 - Outdoor temperature LO
 - Indoor temperature HI
 - Indoor temperature LO



RESET TEMPERATURE RECORDS

- While viewing individual values, hold the MINUS (-) button for 3 seconds to reset the individual value.
- Value, time and date stamp will reset to current readings.

LOW BATTERY INDICATOR

- When battery indicator shows next to outdoor temperature, replace batteries in the outdoor sensor.
- When battery indicator shows next to the indoor temperature, replace batteries in the station.


SEARCH FOR OUTDOOR SENSOR

- Hold the PLUS (+) button for 3 seconds to search for your outdoor sensor.
- If sensor loses connection to the station for any reason, the station will show dashes after 30 minutes.
- The station will search for 3 minutes every hour to try and reestablish a connection with the sensor.
- While searching the reception icon will flash.
- When sensor is connected, the reception icon will be solid.

SENSOR WEATHER SHIELD-NOT INCLUDED

- The Sensor Weather Shield is designed to protect your outdoor sensor from rain and snow.
- This shield will offer limited protection from the sun's heat.
- Purchase at: <http://bit.ly/925-1418>



 **WARNING:** This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov

SPECIFICATIONS

Indoor:

Temperature Range: 32°F to 99°F (0°C to 37°C)

Outdoor:

Temperature Range: -40°F to 140°F (-40°C to 60°C)

Transmission Range: over 300 feet (91 meters) in open air RF 433MHz

Power Requirements:

308-1415BW: 2 "AA" LR6 Batteries (not included)

TX141-Bv2: 2 "AA" LR6 Batteries (not included)

Battery Life:

308-1415BW: over 24 months with reputable batteries

TX141-Bv2: over 24 months with reputable batteries

Dimensions:

308-1415BW: 3.24" L x 2.16" W x 5.98" H (8.23cm L x 5.48cm W x 15.19cm H)

TX141-Bv2: 1.57" L x 0.82" W x 5.11" H (3.98cm L x 2.08cm W x 12.98cm H)

WE'RE HERE TO HELP!

Our knowledgeable customer support team is available:
Monday-Friday, 8am-6pm CST. Phone: 1.608.782.1610

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

For Full Warranty Details, Visit: www.lacrossetechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

CANADA STATEMENT

This device complies with CNR Industry Canada license -exempt devices. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.