

## 616-1950V2 FAQs

The links below will work in most PDF viewers and link to the topic area by clicking the link. We recommend Adobe Reader version 10 or greater available at: <http://get.adobe.com/reader>

## CONTENTS

<b>616-1950v2 FAQs</b> .....	1
<b>Power</b> .....	1
<b>Clock Factory Restart</b> .....	1
<b>Projection Alarm Clock</b> .....	2
How tall are the Time Numbers? .....	2
12-Hour Time Format .....	2
Fahrenheit/Celsius.....	2
Inaccurate Indoor Temperature Reading .....	2
Projection.....	2
Manually Set Time/Calendar/Alarm: Program Menu .....	2
Set Time Alarm.....	3
Activate/Deactivate Time Alarm .....	3
Snooze Alarm.....	3
Time is incorrect.....	3
Display Date Two Ways .....	3
Backlight Intensity .....	3
Nap Feature .....	4
USB Charging Port .....	4
Clock Has Missing Segments .....	4
Clock Is Dim .....	4
Clock Has Distorted Display.....	4

### Power

- The 5.0-volt power cord is required. Version 2 is due to a different power adapter.
- Optional 2-AAA batteries for backup or time/date.

### Clock Factory Restart

1. Remove batteries and power cord from the clock.
2. Press one of the buttons on the clock at least 20 times to clear all memory. Verify that the clock is blank before proceeding.
3. Let the clock sit with batteries out for at least 10 minutes.
4. Insert the power cord in the clock.

## Projection Alarm Clock

### How tall are the Time Numbers?

- The time numbers are one inch tall.

### 12-Hour Time Format

- This clock operates in 12-hour time only.

### Fahrenheit/Celsius

- Use the [program menu](#) to select Celsius or Fahrenheit temperature display.

### Inaccurate Indoor Temperature Reading

- Look for heat sources such as sunlight, door or window frames, or reflected heat of cold.

### Projection

TIME will project continually when operating with the power cord.

**Projection Arm:** The projection arm will rotate 180 degrees to allow you to project on the wall or ceiling. Projection arm can fold into the case if you do not want to view the projection.

**Projection Rotation:** Hold the Circling Arrow button for two seconds to rotate the projected time in 90-degree increments.

**Projection Intensity:** Press and release the Circling Arrow button to adjust the projected image 4 levels or turn Off.

### Manually Set Time/Calendar/Alarm: Program Menu

**TIP:** Press only one button at a time while setting the clock.

- Hold the **SET** button to enter time set mode.
- Press the + or - button to adjust the values.
- Press the **SET** button to confirm adjustments and move to the next item.
- Press the **SNOOZE/LIGHT** button at any time to exit.

#### Setting Order:

- Language (English | Español)
- Beep ON/OFF
- Hour
- Minutes
- Year
- Month
- Date
- Fahrenheit / Celsius
- Snooze duration (5-120 minutes)

1. Hold the SET button for 2 seconds. **ENGLISH** will show. Press the + or - button to select ESPAÑOL for weekday language.
2. Press the SET button to move to **BEEP ON/OFF**. Use the + or - button to turn off the beep sound.
3. Press the SET button to set the **Hour**. Press the + or - button to adjust.
4. Press the SET button to set then set the **Minutes**. Press the + or - button to adjust. Hold to adjust quickly.
5. Press the SET button to set the **Year**. Press the + or - button to adjust.
6. Press the SET button to set the **Month**. Press the + or - button to adjust. Hold to adjust quickly.
7. Press the SET button to set the **Date**. Press the + or - button to adjust. Hold to adjust quickly.
8. Press the SET button to select **Fahrenheit** or Celsius temperature. Press the + or - button to select.
9. Press the SET button to set the **Snooze** Duration (5 minutes to 120 minutes). Press the + or - button to adjust. Hold to adjust quickly.
10. Press the SET button to confirm and exit.

### Set Time Alarm

1. Hold then release the **ALARM** button (clock) for two seconds to enter alarm set mode. The alarm hours will flash.
2. Press and release the + or - buttons to adjust the hour. Hold to adjust quickly.
3. Press and release the **ALARM** button to confirm and move to the minutes. The alarm minutes will flash.
4. Press and release the + or - buttons to adjust the hour. Hold to adjust quickly.
5. Press and release the **ALARM** button to confirm and exit.

### Activate/Deactivate Time Alarm

- The alarm will be active after setting. The alarm icon (clock) will show.
- From normal time display, press and release the ALARM button to deactivate or activate the alarm.

### Snooze Alarm

- When alarm is sounding, press **SNOOZE LIGHT** button to silence the alarm for 10 minutes.
- Press any button except **SNOOZE/LIGHT** to silence the alarm for 24 hours.

### Time is incorrect

- Time is manually set.
- Enter the program menu to adjust the time.

### Display Date Two Ways

Press and release the MINUS button to toggle between different date displays:

- Full weekday
- Weekday/Month/Date

### Backlight Intensity

- Press and release the SNOOZE/LIGHT button to adjust the backlight 4 levels or turn off.

## Nap Feature

1. Press and hold the NAP button for 2 seconds to enter nap set mode.
2. The time will flash and start at the pre-set of 15 minutes. The date area will read NAP.
3. Press + or - buttons to set nap duration. Increase or decrease in 5 min intervals up to 120 min.
4. Press the NAP button to confirm and start nap.
  - While a nap is in progress the date area will display "NAP and minutes will count down to zero. Then the alarm will sound.
  - During NAP setting mode, press SNOOZE/LIGHT button to confirm and exit.
  - During NAP count down, press any button *except* for SNOOZE/LIGHT button to exit count down
  - During NAP count down, press SNOOZE/LIGHT button only to change the backlight
  - The nap duration will be saved in the clock. Next time the NAP button is pressed it will display the amount of time used last and the nap will start.
  - When alarm sounds, NAP - Duration "00m" will flash. Alarm ring for 2 minutes then return to normal display or press any button to stop ringing and return to normal display.

## USB Charging Port

1. When a device is plugged in to a USB charging port the date area will greet the user with "HELLO" for 3 seconds.
2. The lightning bolt will flash while the battery is charging.
3. When the device is fully charged the battery will be full on the LCD.
4. When there is no device plugged in, no battery icon will show.

### USB Output: 1 Amp output

- Charge devices that self-regulate
- Must operate clock with power cable, to charge other devices
- Plug your device into the USB charging port

## Clock Has Missing Segments

- This is generally a power related issue.
- Remove power from clock. Press any button 20 times. Leave the clock unpowered for 1-2 hours.

## Clock Is Dim

- Press your SNOOZE/LIGHT button a few times to be sure your backlight is adjusted properly.
- Check you power cord for proper connection.

## Clock Has Distorted Display

- On a brand new clock check for thin plastic films of printed scratch guard that may be on the upper and lower screen of the clock. This thin piece of plastic has printed numbers for store displays.
- This film will be easy to peel off the LCD.
- With all power removed the clock should be blank.
- If numbers still appear, please check for scratch guard.
- This is generally a power related issue. Check that the AC cord is plugged in correctly.
- Remove all power from clock.
- Press any button 20 times. Leave the clock unpowered for 1-2 hours.
- Install power cord and/or fresh alkaline batteries with correct polarity.