

617-4817 FAQs

The links below will work in most PDF viewers and link to the topic area by clicking the link. We recommend Adobe Reader version 10 or greater available at:

<http://get.adobe.com/reader>

CONTENTS

617-4817 FAQs	1
Power & Charging.....	1
Manually Set Time/Date: Program Menu.....	1
Set Time Alarms	2
Snooze	2
Activate/Deactivate the Alarm	2
Bluetooth Pairing	3
Light Modes	3
Nature Sounds / Music.....	3
Preset Timers for Lights or Sounds.....	4
Buttons and Functions	4





Power & Charging


Primary Power: Built-in 3.7V 2200mAh lithium battery (Sealed inside, do not remove)
Included USB cable and wall adapter to charge the clock: Input is 100-240~50/60Hz
0.35A. The output is 5V/2A.

The Charging Indicator light will glow red while charging. Charge the clock fully before use (7-10 hours) for best performance. Once charged, the clock will operate on battery power for 12-16 hours when lights and sound are used.




Note: Charging and use times will vary based on active hours and features used. The clock will shut down automatically when the battery is low.

Manually Set Time/Date: Program Menu

1. Press and release the  TIME ON/OFF button once to turn the clock on (or off).
2. Hold the  TIME button until the minutes start flashing. Press and release the + or - buttons to adjust the minutes.
3. Press and release the  TIME button. The hour starts flashing. Press and release the + or - buttons to adjust the hour.
4. Press and release the  TIME button to exit.

Time Display ON/OFF: Press and release the  TIME ON/OFF button to hide or display the time. The time settings will be saved when the time display is hidden and when the clock is powered OFF.

Set Time Alarms

1. Hold the  ALARM button until the minutes start flashing. Press and release the + or - button to adjust the minutes.
2. Press and release the  ALARM button to confirm. Press and release the + or - button to adjust the hour.
3. Press and release the  ALARM button to move to alarm sound. Press and release the + or - buttons to select your desired alarm sound.

bb - Beep Sound

01 - Summer Night

02 - Brook

03 - Wind

04 - Ocean

05 - Rain

06 - Rain Forest

07 - Campfire

08 - Thunderstorm

09 - Heartbeat

10 - Whitenoise

11 - Brahms Lullaby

12 - Twinkle Twinkle
Little Star

13 - Moonlight Sonata

14 - Schubert Serenade

15 - Edelwiss

16 - Red River Valley


17 - Meditation from Thais

18 - Mozart's Lullaby

4. Press and release the  ALARM button to confirm and exit.




Note: When the alarm time is reached, the alarm will sound for 1 minute before automatically entering Snooze.

Snooze



When the alarm sounds, press and release any button to silence the alarm for 9 minutes; the Alarm Icon  will flash while snoozing.



Press and release the  ALARM button to stop a snoozing alarm (Icon will stop flashing).

Activate/Deactivate the Alarm

- Press and release the  ALARM button to deactivate the alarm.
- Hold the  ALARM button for two seconds to activate the alarm.
- The Alarm Icon  will show when active.
- If the display is OFF, the alarm will still sound.




Bluetooth Pairing

1. Restart the clock or turn it on by holding the  **POWER/BT** button until it lights up. The Bluetooth pairing mode will start automatically, shown by the blinking Bluetooth Indicator .
2. On your mobile device, turn on Bluetooth and connect to “Firefly Alarm Clock.”




Connect Different Device: Double press the  **POWER/BT** button. The clock will return to pairing mode, and the Bluetooth Indicator  will blink quickly, ready to connect to a new device.

Stop Bluetooth Pairing: Hold the  **POWER/BT** button briefly until the Bluetooth Indicator  no longer shows.

Light Modes

1. Hold the  **LIGHT** button until the lights come on.
2. Press and release the  **LIGHT** button to select your light pattern options. Varied patterns of stars, and fireflies are available.
3. Hold the  **LIGHT** button to turn the lights Off.

Nature Sounds / Music

1. Hold the  **SOUND** button until a sound begins to play. The Music Icon  will show by the time.
2. Press and release the  **SOUND** button to select from 18 nature sounds or music options. Your clock will continue playing until that sound is turned OFF.

01 - Summer Night

02 - Brook

03 - Wind

04 - Ocean

05 - Rain

06 - Rain Forest

07 - Campfire

08 - Thunderstorm

09 - Heartbeat

10 - White noise

11 - Brahms Lullaby

12 - Twinkle Twinkle
Little Star

13 - Moonlight Sonata

14 - Schubert Serenade



15 - Edelweiss

16 - Red River Valley

17 - Meditation from Thais

18 - Mozart's Lullaby

3. Adjust the volume with the + or – button while the sound is playing.

Turn Off Sound: Hold the  **SOUND** button to turn off the clocks audio. The Music Icon  will disappear.

Preset Timers for Lights or Sounds

- Set the Timer by pressing and releasing the ⌚ TIMER button when the sound and/or light features are active. The light above the selected Timer will light up (15 / 30 / 45 / 60 Minutes or OFF).
- The sounds and/or lights will shut off when the Timer expires.
- This is a nice feature if you wish to fall asleep to nature sounds or music from your mobile device.

Buttons and Functions



1. TIME

Hold to enter Time Settings.
Press and release to adjust clock
brightness (High/Low).

2. TIMER

Press and release to select
Timer Duration (15, 30, 45, or 60
minutes, or turn it off).

3. ALARM

Hold to enter Alarm Settings.
Press and release to activate
or deactivate the alarm.

4. - MINUS

Press and release to adjust
by one setting. Hold to adjust
quickly.

5. POWER/BLUETOOTH

Hold to turn the clock ON or
OFF. A shorter hold will turn BT
pairing ON and OFF

6. + PLUS

Press and release to adjust
by one setting. Hold to adjust
quickly.

7. LIGHT

Press and release to change
light modes. Hold to turn the
Light Display ON or OFF.

8. TIME ON/OFF

Press and release to turn the
Time Display ON or OFF.

9. SOUND

Press and release to turn the
sound ON and to select from
18 sounds. Hold to turn the
Sounds OFF.