


## Mood Light Alarm Clock with Nature Sounds



Model: C83117-AU  
DC: 040121

### POWER UP

1. Insert the provided USB power cord into the **bottom** of the alarm, as shown in the image.
2. Plug the other end into an outlet using **your own** USB wall/ power adapter (sold separately). This is required.
3. Pull out the plastic tab on the bottom to activate the CR2032 battery. **For backup only.**
4. Select your language, time, and other settings.



### USB CHARGING PORT

There is a 1 Amp USB charging port on the side of the clock.

- Connect your external device's USB charging cable (sold separately) to the USB charging port.
- Charging times will vary.
- USB Power Output: 1A maximum current.
- Charge 1A devices or devices that are self-regulating.

### SETTINGS

1. Hold the SET button to enter the Settings Menu.
2. Use the + or – button to adjust, and SET to confirm.
3. Press the SNOOZE/LIGHT button at any time to exit.

#### Settings Menu Order:

- Language (English, Español, Français)
- Beep ON/OFF
- Hour
- Minutes
- Year
- Month
- Date
- Snooze Duration (5-120 minutes).

**Note:** Whichever Language is selected, the following instructions will be in the selected language.

**Note:** Weekday will set automatically when Year, Month and Date are set.

### WAKE UP WITH LIGHT

Wake up naturally with a white mood light that gently increases in brightness over a 5 minute period.

#### Set Light Alarm:

1. Hold the LIGHT ALARM 1 button until your alarm time begins to flash.
2. Use the + or - button to adjust your alarm time.
3. Press the LIGHT ALARM 1 button to confirm selections.

### WAKE UP WITH SOUND

Wake up to your favorite nature sound, which will gradually increase in volume over a 5 minute period.

#### Set Sound Alarm:

1. Hold the SOUND ALARM 2 button until your alarm time begins to flash.
2. Use the + or - button to adjust your alarm time & nature sound.  
Nature Sound Options: Beep | Rain | Backwoods | Thunder | River
3. Press the SOUND ALARM 2 button to confirm selections.

### SNOOZE (LIGHT OR SOUND)

- When your alarm time is reached, press the SNOOZE/LIGHT button to delay your alarm function for your preselected snooze duration.
- Press any button except the SNOOZE/LIGHT button to exit snooze countdown.

### ACTIVATE/DEACTIVATE ALARMS

1. Press the LIGHT ALARM 1 or SOUND ALARM 2 button.
2. Alarm time and indicator will show for 3 seconds.
3. Press the LIGHT ALARM 1 button or SOUND ALARM 2 button again to deactivate or activate correct alarm.

### PLAY NATURE SOUNDS

- Press the SOUND button to listen to Nature Sound continually.
- Change volume with the + or - buttons.
- Press the SELECT button to change Nature Sounds.
- Press SOUND button again to turn off Nature Sounds.



## FALL ASLEEP TO NATURE SOUNDS

### Set Sleep Timer

- Press the SOUND button to turn sound on.
- Press and release TIMER button to select the Sleep Timer duration in minutes (15, 30, 45, 60, 75, 90, OFF).
- When selection is made the Sleep Timer will start.
- Nature Sound will play for the designated time then shut off.
- Press the SELECT button to change Nature Sounds.
- Press SOUND button again to turn off Nature Sounds.

## NAP FEATURE

Program your custom nap duration, from 5 to 120 minutes, and all future sessions will start a countdown for this set amount of time with a single press of the NAP button.

### Set Nap Time:

1. Hold the NAP button until your nap time begins to flash.
2. Use the + or - button to adjust your nap duration.
3. Press the NAP button to confirm and start the countdown.
4. When the Nap countdown reaches zero, the alarm will sound.
5. Press any button to exit the nap countdown.

## BACKLIGHT INTENSITY

- Tap the SNOOZE/LIGHT button to select the intensity level of the backlight (4 levels and OFF).
- The word BACKLIGHT with the number will show.

## MOOD LIGHT INTENSITY AND COLOR

- Press the MOOD LIGHT button to select brightness: (4 levels & OFF)
  - When selection is made, press the COLOR button to select your mood light color or to cycle through all colors.
- Choices:** Red, Yellow, Green, Cyan, Blue, Purple, White, Cycle

## LOW BATTERY INDICATOR

- When the low battery indicator appears, replace the CR2032 battery in your clock.

## SPECIFICATIONS

**USB Power Cord:** USB180-P5.5x11B (required, included)

Optional: 1- CR2032 battery (included)

**Note:** The battery will keep time during loss of power. You will not see the clock display on battery power alone.

**USB Output:** 1 Amp maximum (when using 1.2v adapter)

**Battery Life:** Battery life is over 24 months

**Dimensions:** 5.44" W x 3.4" D x 5.5" H (13.81cm W x 8.6cm D x 13.97cm H)

## JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



**WARNING:** This product can expose you to chemicals including styrene, which is known in the State of California to cause cancer.

For more information go to: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

## BUTTONS & FUNCTIONS

<b>LIGHT ALARM</b>	Press to view Light Alarm Time. When alarm time is viewed press to activate/deactivate alarm. Hold to set Light Alarm.
<b>NAP</b>	Hold to enter Nap Settings. Press to start or stop Nap Countdown.
<b>SOUND ALARM</b>	Press to view Sound Alarm Time. When alarm time is viewed press to activate/deactivate alarm. Hold to set Sound Alarm.
<b>- (MINUS)</b>	Press to decrease values in setting menus. Press to decrease volume of Nature Sounds.
<b>SET</b>	Hold to enter Settings Menu. Press to confirm setting an move to next menu item.
<b>+ (PLUS)</b>	Press to increase values in setting menus. Press to increase volume of Nature Sounds.
<b>MOOD LIGHT</b>	Press to adjust Color Mood Light Brightness (OFF, 1, 2, 3, 4).
<b>COLOR MODE</b>	Press to select Mood Light Color or cycle through all colors.
<b>SOUND</b>	Press to start or stop selected Nature Sounds.
<b>TIMER</b>	Press preset time for Nature Sound to play (OFF, 15, 30, 45, 60, 90).
<b>SELECT</b>	Press to select Nature Sound (Rain, Ocean, Backwoods, Thunder, River). Use the SOUND button to play Nature Sound.

**WARNING:** ⚠️ ☞

1. This product contains a button battery.
2. If swallowed, it could cause severe injury or death in just 2 hours.
3. Seek medical attention immediately.

### WARNING - KEEP BATTERIES OUT OF REACH OF CHILDREN

1. Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
2. If you suspect your child has swallowed or inserted a button battery, immediately seek urgent medical assistance.
3. Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened.
4. Do not use if compartment is not secure.
5. Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous.
6. Tell others about the risk associated with button batteries and how to keep their children safe.

## WARRANTY

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

La Crosse Technology, Ltd.  
2830 S. 26th St.  
La Crosse, WI 54601

## CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

### Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.