


WIRELESS TEMPERATURE STATION



Setup with Multiple Sensors

Observe correct polarity when inserting batteries. **Note:** When only using one sensor, use steps 1, 2 and 5.

Step 1: Insert 2 fresh AA, LR6 1.5 volt batteries into sensor 1.

Step 2: Insert 2 fresh AA, LR6 1.5 volt batteries into the temperature station

Step 3: When outdoor temperature appears, insert 2 fresh AA, LR6 1.5 volt batteries into sensor 2

Step 4: When channel 2 appears, insert 2 fresh AA, LR6 1.5 volt batteries into sensor 3

Step 5: Keep the temperature station and all sensors together for 15 minutes. All three sensors should be displayed in the first minute.

Restart: If the outdoor temperature is not displayed after 3 minutes, remove batteries from the wireless temperature station & all outdoor sensors. Press any button on the wireless temperature station 20 times. After 15 minutes, return to **Step 1** above.

Outdoor Temperature Reception Icon/Channel Indicator

- The outdoor temperature reception icon will flash every second when searching for the sensor.
- Once connected, once every 4 seconds when outdoor temperature update is received.
- The channel indicator will show below the reception icon.
- Press the **CH** button to view sensors on other channels.

Note: Channel 1 will not show if only one sensor is connected.



Set Time, Date, Temperature Units, Forecast Sensitivity

1. Press and hold the SET/CH button for 5 seconds.
2. "12h" or "24h" will flash in the TIME section of the LCD. Press and release the MIN/MAX/+ button to select 12/24 hour time.
3. Press and release the SET/CH button once.
4. The **hour** will flash. Press and release the MIN/MAX/+ button to advance the hours.
5. Press and release the SET/CH button once more, and the **minutes** will flash. Press and release the MIN/MAX/+ button to advance the minutes.
6. Press and release the SET/CH button to confirm selections and exit.

Note: Selecting 12 hour time will automatically select Fahrenheit (°F) temperature.
Selecting 24 hour time will automatically select Celsius (°C) temperature

View/Reset MIN/MAX Values

The temperature station shows MIN/MAX temperatures.

- Press the **MIN/MAX/+** button to view minimum, maximum then current temperature readings.
- Hold the **MIN/MAX/+** button to reset all temperature readings to current.

Low Battery Icon

Low battery icon indicates low battery for station or sensor.

- If the TX icon is displayed, replace batteries in the outdoor sensor.
- If the RX icon is displayed, replace batteries in the temperature station.

Low
Battery

RX

TX

Position Outdoor Sensor

- Mount the outdoor sensor on a north-facing wall or in any well shaded area. Under an eave or deck rail is preferred.
- The maximum transmitting range to the wireless temperature station is over 330 feet (100 meters) in open air, not including walls.

Specifications

Temperature measuring range:	
Indoor:	14.1°F to 139.8°F (9.9°C to 59.8°C)
Outdoor:	-39.8°F to 139.8°F (-39.8°C to 59.8°C)
Indoor relative humidity range:	1% to 99%
Indoor checking interval:	Every 15 seconds.
Outdoor checking interval:	Every 4 seconds.
Transmission Range:	330 feet (in open space).
Power Supply:	
Weather Station:	2 x AA, IEC LR6, 1.5V.
Temperature Sensor:	2 x AA, IEC LR6, 1.5V.
Battery life cycle:	Approximately 24 months.
Recommended battery type:	Alkaline.
Dimensions (L x W x H)	
Weather Station	2.91" x 1.15" x 3.86" (74 x 29.1 x 98mm).
Temperature Sensor:	1.44" x 0.76" x 4.80" (36.6 x 19.3 x 121.8mm)

Care and Maintenance

- **Do not mix old and new batteries**
- **Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries**
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Installed the batteries correctly in regard to polarity (+and -).
- Remove batteries from equipment with is not to be used for an extended period of time.
- Remove expired batteries promptly.
- Do not expose to extreme temperature, vibration or shock.
- Clean with a soft damp cloth. Do not use solvents or scouring agents.
- The product is not a toy. Keep it out of reach of children.
- The product is not to be used for medical purpose or for public information. It is intended for home use only.
- The specs of this product may change without prior notice.
- Improper use or unauthorized opening of housing voids warranty.

Warranty and Support Information

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

Before returning a product, please contact our friendly customer support with questions or visit our online help (manuals and FAQs):

Phone: 1-608-782-1610

Online Product Support: www.lacrossetechnology.com/support

Product Registration: www.lacrossetechnology.com/support/register

View full warranty details online at: www.lacrossetechnology.com/warranty_info.pdf

Warranty Address:

La Crosse Technology, Ltd
2830 S. 26th St.
La Crosse, WI 54601



Protected under U.S. Patents: 5,978,738 | 6,076,044 | RE43903

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter. **Operation is subject to the following two conditions:**

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.