



ATOMIC DIGITAL ALARM CLOCK


FRONT VIEW



BUTTONS




BACK VIEW



GET STARTED

Step 1: Insert 2 *new* AAA Alkaline batteries (not included) into the alarm clock. Observe the correct polarity.



Restart: If there is no indoor temperature data after 60 seconds, remove batteries from the alarm clock, press any button 20 times. After 15 minutes, return to **Step 1** above.

SET TIME, DATE AND TEMPERATURE

1. Hold the **SET °F/°C** button to enter time set mode.
2. Press the **UP** or **DOWN** buttons to adjust values.
3. Press the **SET °F/°C** button to confirm adjustments and move to the next item.



TIME SET ORDER:

1. WWVB time signal (On/Off)
2. Time Zone - 7 time zones
3. DST (Daylight Saving Time On/Off)
4. Hour
5. Minutes
6. Year
7. Month
8. Date

TIME ZONE	
AST	Atlantic
EST	Eastern
CST	Central
MST	Mountain
PST	Pacific
AKT	Alaska
HAT	Hawaiian

Press the **SET °F/°C** button to exit, or wait 20 seconds without pressing buttons to return to the normal time display.

FAHRENHEIT/CELSIUS

- Press the **SET °F/°C** button to select temperature readings in Fahrenheit or Celsius.



LOW BATTERY ICON

- When the icon is displayed above the seconds, replace batteries in the clock.

Low
Battery
Icon



SET TIME ALARM


Setting the alarm and activating the alarm are separate actions.

1. Hold the **ALARM** button for 2 seconds to enter alarm time set mode.

The letters "AL" will replace the seconds and the alarm hour will flash.

2. Press the **UP** or **DOWN** buttons to adjust the alarm hour.
3. Press the **ALARM** button to confirm and move to the alarm minutes.
4. Press the **UP** or **DOWN** buttons to adjust the alarm minutes.
5. Press the **ALARM** button to confirm and exit.

Note: After 10 seconds the clock will default to regular time mode.



Alarm Time setting order:

1. Hours, 2. Minutes

ACTIVATE/DEACTIVATE TIME ALARM

- Press the **ALARM** button once to enter alarm mode. The letters "AL" will replace the seconds
- Press the **ALARM** button again to activate the alarm.

Once activated, the bell icon appears.

- Press the **ALARM** button again to deactivate the alarm. The bell icon will disappear.



Alarm
Bell Icon

SNOOZE (SILENCES ALARM TEMPORARILY)

- When alarm sounds, press the **SNZ** button to silence the alarm for 10 minutes.
- The snooze icon **Zz** will flash.
- In snooze mode, press any button to stop alarm for one day.

Note: The alarm is crescendo sound. The alarm will sound for 2 minutes and then shut off completely if no buttons are pressed.

WWVB (ATOMIC) TIME MANUAL SEARCH

- Hold the **DOWN** button for 3 seconds to start or stop a WWVB signal search.
- WWVB Icon will flash when searching.



For information about WWVB visit:

www.nist.gov/pml/div688/grp40/wwvb.cfm

ATOMIC SIGNAL SEARCH:

When batteries are inserted, the alarm clock will start searching. If there is no WWVB reception, the alarm clock will search the WWVB time signal every 2 hours until the WWVB time is received. After reception, this alarm clock will only search for the atomic signal after midnight (UTC 7:00, 8:00, 9:00, 10:00, and 11:00)

POSITION THE ALARM CLOCK

- Position the alarm clock six feet from other electronics for best WWVB reception.
- Have the front or back of the alarm clock facing Colorado.

SPECIFICATIONS

Indoor:

Temperature Range: +32°F to +122°F (0°C to 50°C)

Power:

Battery: 2-AAA, IEC, LR3 batteries (not included)

Battery Life:

Battery Life: Battery life is over 12 months

Dimensions:

Atomic Alarm Clock: 7.80" L x 1.10" D x 5.47 " H
(198.12 x 27.94 x 138.93 mm)

CARE AND MAINTENANCE

- Do not mix old and new batteries
- Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries
- Always purchase the correct size and grade of battery most suitable for intended use.
- Replace all batteries of a set at the same time.

- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with correct polarity (+and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove expired batteries promptly.

WARRANTY AND SUPPORT INFORMATION

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

Before returning a product, please contact our friendly customer support with questions or visit our online help (manuals and FAQs):

Phone: 1-608-782-1610

Online Product Support: www.lacrossetechnology.com/support

Product Registration:

www.lacrossetechnology.com/support/register

View full warranty details online at:

www.lacrossetechnology.com/warranty_info.pdf

Warranty Address:

La Crosse Technology, Ltd

2830 S. 26th St.

La Crosse, WI 54601



Protected under U.S. Patent: RE43903

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.

CANADA STATEMENT

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:(1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.