

# 18.5 Inch Portable Monitor User Manual



Email: [help@uperfectmonitor.com](mailto:help@uperfectmonitor.com)



In order to ensure your safe use of this product, please read this manual carefully before using this product and keep it properly.



Email: [help@uperfectmonitor.com](mailto:help@uperfectmonitor.com)

## Table of contents

---

### Chapter 01 Preparations

---

Welcome!

Checking the package contents

Monitor introduction

Product Appearance & Interface Function Introduction

The functions of the bracket & keyboard

### Chapter 02 Specifications

---

### Chapter 03 Connecting

---

TYPE-C signal transfer

Supported Devices & Models (Type-C)

HDMI signal transfer

### Chapter 04 Setting Up(Windows10)

---

1.Extend Mode/Duplicate Mode/Display Mode

1-1.Way1:Set on the device'Display Settings

1-2.Way2: Set via Windows key + P keyboard shortcut

2.Rotate the Screen

### Chapter 05 Screen Adjustment

---

On-Screen Display Menu Introduction

OSD SETTING

Save settings

### Chapter 06 Q&A

---

### Chapter 07 Service Support

---

## Chapter 01 Preparations

### Checking the Package Contents



Portable Monitor



Power Adapter



User Guide



Mini HDMI Cable




Type-C to Type-C Cable \*2

### Note:

•If any of the above items is damaged or missing, please contact us immediately. ([help@uperfectmonitor.com](mailto:help@uperfectmonitor.com))

•The appearance of the components may differ from the images shown.

## Monitor Introduction



## Product Appearance & Interface Function Introduction

### A. Mini HDMI Port

For Audio and Video Signal Transmission.

### B & C. Type C 3.1 Port

Full featured type c port. For signal and power transmission.

### D. Audio Port

Headphone/ Sound Box Extension Port

### E. Menu Button

Press MENU to enter the OSD (On-Screen Display) menu;

Short press to confirm/ turn on the monitor;

Long press to exit/ turn off the monitor.

### F: Power On/Off Button

Long press to power off


Short press to power on or return

### G. VESA:

4 M4\*4mm holes.

## The functions of the bracket & keyboard

The bracket supports 180° opening up.



## Chapter 02 Specifications


Color	Black
Model	M185E01
Resolution	1920*1080
Brightness	300 cd/m <sup>2</sup>
Color Gamut	100% sRGB
Display Color	16.7M(8 Bit)
VESA	M4*4mm
Interfaces	Mini HDMI
	Type C 3.1 Port * 2
	3.5mm Audio Port
Panel Type	IPS

# Chapter 03

## Connecting

### TYPE-C signal transfer

**Note:** For a more stable power supply, it is recommended to use our original power adapter to power.



### Supported Devices & Models (Type-C)

Laptop Model	
Brand	Model
Apple	Macbook 12", Macbook 13" 2017, MacbookPro 2016/2017/2018, New Macbook Air 2018, iPad Pro 2018
Google	ChromeBook Pixels, PixelBook Pen, MagicBook
Lenovo	Yoga C930, Yoga 5 Pro, Yoga 6 Pro, ThinkPad XI Carbon 2017, Miix 720, Legion Y7000/Y7000P/Y7000K
Dell	XPS13, XPS15, G3/G5/G7, Inspiron 5000/7000
HP	Pavilion X2, EliteBook Folio G1, EliteBook 1050 G1, Microsoft Surface Book2
ASUS	U306, U321 series, U4100, ROG series
Huawei	Matebook D, Matebook X, Matebook X Pro, Matebook E, Matebook 13
Razer	Blade Stealth
More Brands	Continuous update...


**Note:** Please check the Type C port of your PC/Laptop whether supports audio and video signal transmission(Thunderbolt3). If it is just a Type C for charging, you need connecting HDMI to transmit signal.

Mobile Phone Model	
Brand	Model
Samsung	S8, S8+, S9, S9+, S10, S10+, S10e, Note8, Note9
Huawei	Mate10, Mate10 Pro, Mate20, Mate20 Pro, Mate 20X, Mate P20, Mate P20 Pro, HonorNot10, Mate P30, Mate P30 Pro
More Brands	Continuous update...


**Note:** Please check the Type C port of your phone whether supports audio and video signal transmission ( USB 3.1 ).

## HDMI signal transfer

**Note:** For a more stable power supply, it is recommended to use our original power adapter to power.



**Note:** If the Type C of your laptop/phone is not a full-featured Type C port, or your phone is with micro USB port, lightning port, for example Google Pixel 3, you need to buy the adapter as below. Any questions you can feel free to contact us.




# Chapter 04

## Setting Up(Windows10)

### Extend Mode /Duplicate Mode/Display Mode

#### Way1: Set on the device' Display Settings


- A: Verify that your cables are connected properly to the new monitors.
- B: Right-click anywhere on your desktop and select Display settings to open the Display page.
- C: Scroll down to Multiple displays, then select an option from the drop-down list to determine how your desktop will display across your screens. For the largest work area, select Extend desktop.



Note: If you cannot see the additional monitor(s) listed, click Detect. If does not work, try restarting your computer and do steps again.

#### Way2: Set via Windows key + P keyboard shortcut


- A: Verify that your cables are connected properly to the new monitors.
- B: Enter the "Windows" key and "P" keyboard at the same time.
- C: select an option from the drop-down list to determine how your desktop will display across your screens. For the largest work area, select Extend desktop.



Note: If you cannot see the additional monitor(s) listed, click Detect. If does not work, try restarting your computer and do steps again.


## Rotate the Screen

- 1: Verify that your cables are connected properly to the new monitors.
- 2: Right-click anywhere on your desktop and select Display settings to open the Display page.
- 3: Under the "Select and rearrange displays" section, select the monitor that you want to adjust.
- 4: Under the "Scale and layout" section, use the Orientation drop-down menu to select Landscape or Portrait screen.




## On-Screen Display Menu Introduction


### PICTURE




### COLOR EFFECT




### INFORMATION



### RESET




### ADVANCE






## OPTION



## TEMPERATURE



## OSD SETTING



## Chapter 06

### Q&A

**Q:** Abnormal conditions occurred - like the splash screen or spots when using the monitor.

- A:**
1. It is caused by an insufficient power supply. Monitor required large power support. Please use the attached genuine cable provided to power the monitor.
  2. If use the mobile power bank to power the monitor, please confirm whether the mobile power bank is a PD power bank that has reached 30W or more. Please contact us if you need a power bank.
  3. If the resolutions above do not work, please try another computer device. If it failed, please contact us for the replacement of the cable.

**Q:** The monitor fails to start and the screen is blank.

- A:**
1. Please TURN ON the power supply.
  2. Please check whether the connection is correct. Please unplug the cable and reconnect. Please use the genuine cable and the power adapter.
- Note: Most Samsung mobile phones can not power for the monitor, please power the monitor with an additional power adapter.
3. Please contact us if the troubleshooting above does not help.

**Q:** The display is TURN-ON, shows "NO SIGNAL" or "POWER SAVING".

- A:**
1. Please check if the mobile phone supports USB3.1/Thunderbolt 3. when you are using Type-C to Type-C to connect the monitor and the mobile phone. An HDMI adapter is required to transfer the signal if your mobile phone does not support USB3.1/Thunderbolt 3.
  2. Please check whether the connection is correct. Please use the genuine cable provided.
  3. Please try another computer. If it failed, please contact us for the replacement of the cable.

**Q:** The monitor is constantly restarting.

**A:** 1. It is caused by an insufficient power supply. Monitor required large power support.

Please use the attached genuine cable provided to power the monitor.

2. If use the mobile power bank to power the monitor, please confirm whether the mobile power bank is a PD power bank that has reached 30W or more. Please contact us if you need a power bank.

3. If the resolutions above do not work, please try another computer device. If it failed, please contact us for the replacement of the cable.

## Chapter 07

### Service Support

Dear Customer,

Thank you for purchasing the Portable USB Monitor!

We offer 100% money back guarantee in 30 days and 90 days replacement, 12 month warranty for any issue, professional tech support to ensure no-worry service.

Any query or problem, please contact us via [help@uperfectmonitor.com](mailto:help@uperfectmonitor.com)

