0F3SR14TT26000D FDU-S050

WET SLIPPER CLUTCH **FOR PANIGALE 1199 - 1299**

f Ü e	-	(1)	901 VT 018 SCREWS	MOUNTING INSTRUCTIONS
	~	(2)	901 RD 007 TOOTHED WASHERS	The Drum/Hub group is supplied pre-assembled. In case of need, as to check the ramps wear, please see hereinafter the specific procedure to disassemble the Drum/Hub group. Place the Drum/Hub group on the drive shaft. Eventually, in order to simplify the operation, it is possible to fix the drum (15) onto the hub (18), in an at-rest position, with a M6x1 screw.
Ĩ	~	(3)	0F3SR14TT260004 BEARING REST	Replace the original clutch plates, keeping the in the original sequence except for the last steel disc 34 TEETH, which must be replaced with a steel disc equal to all other 36 TEETH. At the end of the operation the total height of the stack must be 50.8mm + 0.3 to 0.3 mm. WARNING: if in the original plates kit there are two rings (one of them is explicitly placed in between sint there have them energy of the
	~	(4)	0F3SR14TT260007 SPRING STOPPER HUB	conical), placed in between sinterized plates keep them apart and do NOT use them in the STM clutch. Remove the M6x1 screw, if you used it for the last operation. Check that the drum stopper lock screw (13) do not stick out from the surface of the drum stopper (14), where the spring pusher plate (7) will be placed.
0	←	(5)	0F3SR140T260017 MAIN TOOTHED WASHER	Verify that the secondary spring support (12) is correctly placed in its seat in the drum (15).Place the secondary spring (11) in the drum (15) with a small amount of grease. Check that the primary spring support (9) is correctly placed in its seat in the
	←	(6)	003MG007 BALL BEARING	pusher plate (10).Place the pusher plate (10) in its seats on the drum (15). Place the Evoluzione primary spring (8) on the pusher plate (10). Pre-assemble the spring stopper group: keep the spring pusher plate (7) with the groove for the bearing facing up as shown in the drawing, place the ball
	←	(7)	0F3CR620E07A008 SPRING PUSHER PLATE	bearings (6) and then place the spring stopper hub (4). Insert the spring stopper group into the pressure plate (10) so that the 9 wings of the spring pusher plate (7) overlap the 9 tips of the spring (8). Insert the notched washer(5) with the convex part facing up and in the spring stopper hub (4).
Errs	~	(8)	OS1121 PRIMARY SPRING	Tighten the spring stopper hub (4) onto the drive shaft, using the tool (19), provided with the clutch and lock it with a dynamometric wrench to the torque suggested by the manufacturer. To lock the pressure plate (10) we suggest to use the specific tool (UTL-0030) (not included). Pre-assemble the bearing rest group: mount the clutch pushrod piece and the bearing of the original clutch into the bearing rest (3).
	~	(9)	0F3SR540B140015 PRIMARY SPRING SUPPORT	Place the entire bearing rest into the specific holes in the pressure plate (10) taking care of placing it correctly in these holes and fix it with the six screws (1) and with the notched washers (2). Once the mounting operations are completed, operate the clutch lever more than once to check that pressure plate correctly activate the clutch
	←	(10)	0F3SR14TT260003 PUSHER PLATE	opening and closing, then mount the clutch guard. DRUM/HUB UN-INSTALL PROCEDURE ATTENTION: DO NOT perform this operation before removing the clutch from the bike. Remove the drum stopper lock screw (13), rotate the drum
END	←	(11)	0S2085 SECONDARY SPRING	stopper hub (14) clockwise by 60° and then remove it. The drum (15), the hub (18) and the steel balls (16) can now be disassembled. TO RE-ASSEMBLE THE GROUP: place the 6 steel balls (16) at the bottom of the grooves of the hub (18) using a small amount of grease, then position the
\bigcirc	←	(12)	0F3SR540B140016 SECONDARY SPRING SUPPORT	drum (15) onto the hub (18) in an at-rest position. Position the drum stopper hub (14) on the hub (18), aligning its three wings with the three housings on the hub (18), then rotate it until the holes of the two parts are aligned, and finally replace completely the screw (13). Check that the drum
ð	✦	(13)	0F3SR300J070086 SCREW STOPPER HUB	stopper hub (14) is correctly locked on the hub (18) and that the drum stopper lock screw (13) do not stick out from the surface where the spring stopper hub (4) will be placed.
	~	(14)	0F3SR14TT260009 DRUM STOPPER HUB	
	<	(15)	0F3SR14TT26002D	
	←	(16)	001MG025 STEEL BALLS 1/4"	
Sand and a second secon	~	(17)	0F3SR14TT260046 steel plate	GENERAL SAFETY REGULATIONS - IN THIS SHEET ARE REPORTED THE DIRECTIONS TO PERFORM CORRECTLY THE CLUTCH ASSEMBLY OPERTIONS. - STM RESERVES THE RIGHT, WITHOUT NOTICE, TO INTRODUCE ANY TECHNICAL CHANGE WHENEVER DEEMED IT TO BE NECESSARY TO IMPROVE FUNCTION AND QUALITY OF THE PRODUCTS. - ASSEMBLY OPERATIONS MUST BE PERFORMED BY A SKILLED TECHNICIAN AND MUST BE
	<	(18)	0F3SR14TT26001D	SCRUPULOUSLY OBSERVED. - BEFORE MOUNTING THE CLUTCH MAKE A COMPLETE INSPECTION OF THE MOTORBIKE COMPONENTS, IN ORDER TO VERIFY THE POSSIBLE PRESENCE OF FAULTS OR ANOMALIES ON THE VEHICLE. - MAKE SURE THAT THERE ARE NO MISSING/DAMAGED PARTS IN THE CLUTCH KIT. - SOME PARTS OF THE CLUTCH AND ITS COMPONENTS CAN HAVE SHARP SURFACE: <u>HANDLE</u> <u>WITH CARE</u> . - SOME COMPONENTS OF THE CLUTCH, BECAUSE OF THEIR SMALL DIMENSIONS CAN BE
	~	(19)	008AMY002 TOOL E38/E30	SWALLOWED: KEEP AWAY FROM CHILDREN. STM ITALY Via A. Olivetti 15 - 10020 - Riva presso Chieri (TO) www.stmitaly.com - contact@stmitaly.com