## 0F3SR620V22000D FYA – S170

## YAMAHA R1 2015/2016 **SLIPPER CLUTCH KIT**

## MOUNTING INSTRUCTION

7729				MOUNTING INSTRUCTION
Ê Ê Ê Ê	<del>~</del>	(1)	901 VT 018 Screw	The Drum/Hub group is supplied pre-assembled. <b>In case of need,</b> as to check the ramps wear, please see hereinafter the specific procedure to disassemble the Drum/Hub group.
	<del>~</del>	(2)	901 RD 007 Notched Washer	Place the Drum/Hub group on the drive shaft. Replace the original clutch plates, keeping the in the original sequence except for the last steel disc 34 TEETH, which must be replaced with a steel disc 36 TEETH supplied in the box. At the end of the operation the total height of the stack must
e C	←	(3)	0F3SR620V220004 BEARING REST	be 48.5 mm + 0.3 to 0.3 mm. WARNING: between the original basket and the hub (18) you must keep the washer of the original clutch, otherwise there could be generated wrong function and/or damage to the clutch parts.
0	←	(4)	0F3SR620V220013 CLUTCH NUT	WARNING: if in the original plates kit there are two rings (one of them is conical), placed in between sinterized plates keep them apart and do NOT use them in the
0	←	(5)	901RD101 NOTCHED WASHER	<b>STM clutch.</b> Check that the drum stopper lock screw (14) do not stick out from the surface of the drum stopper (15), where the spring stopper plate (6) will be placed.
	<del>~</del>	(6)	0F3SR620V220007 SPRING STOPPER HUB	Verify that the secondary spring support (13) is correctly placed in its seat in the drum (16).Place the secondary spring (12) in the drum (16) with a small amount of grease. Check that the primary spring support (10) is correctly placed in its seat in the
	<del>~</del>	(7)	003 MG 007 Ball Bearing	pressure plate (11).Place the pressure plate (11) in its seats on the drum (16). Place the primary spring (9) on the pressure plate (11). Pre-assemble the spring stopper group: keep the spring stopper plate (8) with the
APU-US	<b>~</b>	(8)	0F3CR620E07A008 SPRING PUSHER PLATE	groove for the bearing facing up as shown in the drawing, place the ball bearings (7) and then place the spring stopper hub (6). Insert the spring stopper group into the pressure plate (11) so that the 9 wings of the spring pusher plate (8) overlap the 9 tips of the spring (9).
Eng.	←	(9)	<b>0\$1121</b> Evoluzione primary Spring	Insert the notched washer (5) with the convex part facing up and then the nut (4) in the spring stopper hub (6). Tighten the nut (4) onto the drive shaft, provided with the clutch and lock it with a dynamometric wrench to the torque suggested by the manufacturer. To lock the pressure plate (11) we suggest to use the specific tool (UTL-0030) (not included). Pre-assemble the bearing rest group: mount the clutch pushrod piece and the
	←	(10)	0F3SR540B140015 PRIMARY SPRING SUPPORT	bearing of the original clutch into the bearing rest (3). Place the entire bearing rest into the specific holes in the pressure plate (11) taking care of placing it correctly in these holes and fix it with the six screws (1) and with the notched washers (2). Once the mounting operations are completed, operate the clutch lever more than once to check that pressure plate correctly activates the clutch opening and
	←	(11)	0F3SR14TT260003 PRESSURE PLATE	closing, and then mount the clutch guard. DRUM/HUB UN-INSTALL PROCEDURE ATTENTION: DO NOT perform this operation before removing the clutch from the bike. Remove the drum stopper lock screw (14), rotate the drum stopper hub (15)
En	<del>~</del>	(12)	0\$2085 Secondary Spring	clockwise by 60° and then remove it. The drum (16), the hub (18) and the steel balls (17) can now be disassembled. <b>TO RE-ASSEMBLE THE GROUP:</b> place the 6 steel balls (17) at the bottom of the grooves of the hub (18) using a small amount of grease, then position the drum (14)
$\bigcirc$	←	(13)	0F3SR540B140016 SECONDARY SPRING SUPPORT	onto the hub (18) in an at-rest position. Position the drum stopper hub (15) on the hub (18), aligning its three wings with the three housings on the hub (18), then rotate it until the holes of the two parts are aligned, and finally replace completely the screw (15). Check that the drum stopper (15) is correctly locked on the hub
ŋ	<del>~ -</del>	(14)	0F3UN99ZZ990018 DRUM STOPPER LOCK SCREW	(18) and that the drum stopper lock screw (14) do not stick out from the surface where the spring stopper hub (15) will be placed.
	←	(15)	0F3SR620V220009 DRUM STOPPER HUB	
	←	(16)	0F3SR620V22002D DRUM	GENERAL SAFETY REGULATIONS
	←	(17)	001 MG 025 STEEL BALLS	<ul> <li>IN THIS SHEET ARE REPORTED THE DIRECTIONS TO PERFORM CORRECTLY THE CLUTCH ASSEMBLY OPERTIONS.</li> <li>STM RESERVES THE RIGHT, WITHOUT NOTICE, TO INTRODUCE ANY TECHNICAL CHANGE WHENEVER DEEMED IT TO BE NECESSARY TO IMPROVE FUNCTION AND QUALITY OF THE PRODUCTS.</li> <li>ASSEMBLY OPERATIONS MUST BE PERFORMED BY A SKILLED TECHNICIAN AND MUST BE SCRUPLLOUSLY OBSERVED.</li> <li>BEFORE MOUNTING THE CLUTCH MAKE A COMPLETE INSPECTION OF THE MOTORBIKE COMPONENTS, IN ORDER TO VERIFY THE POSSIBLE PRESENCE OF FAULTS OR ANOMALIES ON THE VEHICLE.</li> </ul>
	←	(18)	0F3SR620V22001D HUB	MAKE SURE THAT THERE ARE NO MISSING/DAMAGED PARTS IN THE CLUTCH KIT.     SOME PARTS OF THE CLUTCH AND ITS COMPONENTS CAN HAVE SHARP SURFACE: <u>HANDLE</u> <u>WITH CARE</u> .     SOME COMPONENTS OF THE CLUTCH, BECAUSE OF THEIR SMALL DIMENSIONS CAN BE SWALLOWED: <u>KEEP AWAY FROM CHILDREN</u> .  STM ITALY Via A. Olivetti 15 - 10020 - Riva presso Chieri (TO) www.stmitaly.com - contact@stmitaly.com