



Spinbase Setup

1. Remove Spinbase from its box. Keep the packaging in case you need to return or exchange your unit.
2. Place Spinbase on a level surface. This is important for the performance of your turntable.
3. Before turning it on, plug Spinbase into a power outlet using the included power adapter.




Connect a Turntable or Record Player

1. Place your turntable on top of Spinbase.
2. **If using a turntable with a Magnetic cartridge (most common):** Connect your turntable to "MAGNETIC PHONO". Ensure the "CERAMIC CARTRIDGE" switch is "OFF".
3. **If using a turntable with a Ceramic cartridge, or a record player with a line output:** Connect it to the "LINE-IN" on Spinbase. Set the "CERAMIC CARTRIDGE" switch to "ON".
4. To prevent hum, use the ground connector if your turntable supports it.



Connect a Bluetooth Device

1. Connect to "Spinbase" in your Bluetooth settings.
2. Disconnect for another user to pair.



One Year Warranty

Andover Audio warrants Spinbase against manufacturing defects and workmanship to the initial purchaser for a period of one (1) year from the date of delivery to customer. Andover Audio will repair or replace the unit as necessary to restore proper operation. This warranty covers both parts and labor for the warranty period. The warranty excludes physical damage caused by accident or abuse outside of our control. If you think you need warranty service, please contact us to obtain an RMA (Return Merchandise Authorization) by emailing support@andoveraudio.com or calling 978.775.3670. For more information on returns and exchanges, please visit www.andoveraudio.com/pages/returns-and-exchanges.

Thank you for purchasing Spinbase.

If you're new to vinyl, or returning to it after a few years, there are some important things to know:

The turntable phono cartridge is the device on the end of the tonearm that converts record grooves to an electrical signal. The most commonly equipped cartridges are **Magnetic** and **Ceramic**. Spinbase is compatible with both, but the connections are different. (Note: Some high-end cartridges, called Moving-Coil, are not compatible with Spinbase.)

MAGNETIC CARTRIDGES - provide higher fidelity than their Ceramic siblings. They also track your records with less weight and are better at preventing record wear. They provide very little electrical output and require a circuit known as an RIAA preamplifier to boost and equalize the signal. Spinbase has this preamplifier built-in. **If your turntable has a Magnetic cartridge, plug the turntable into the "MAGNETIC-PHONO" input on Spinbase. Ensure the "CERAMIC CARTRIDGE" switch is set to "OFF".**

Some turntables also have their own preamplifiers built-in and do not require the use of the preamplifier in Spinbase. **If your turntable has a switch on it marked "Line" and "Phono", your turntable has a built-in preamplifier. You have two choices:**

1. Switch your turntable to "Line" and plug it into the "LINE-IN" input on Spinbase; or,
2. Switch your turntable to "Phono" and plug it into the "MAGNETIC PHONO" input, utilizing the preamplifier in Spinbase.

In most cases, plugging your turntable into Spinbase's Phono input and ensuring "CERAMIC CARTRIDGE" is set to "OFF" will give the best sound. Try them both and use what sounds best to you.

CERAMIC CARTRIDGES - are generally found in lower priced turntables and record players. They do not perform as well as a good magnetic cartridge, but can still give satisfying performance with Spinbase thanks to its exclusive Ceramic Equalization feature. Ceramic cartridges have high output voltage, and turntables or record players equipped with one should be plugged into the "LINE-IN" input on Spinbase. The sound quality will be improved when setting the "CERAMIC CARTRIDGE" switch to "ON". **If you are NOT using a Ceramic cartridge, leave the "CERAMIC CARTRIDGE" switch to the "OFF" position.**

SHORTING PLUGS - The shorting plugs supplied with Spinbase should remain plugged into the "MAGNETIC PHONO" input whenever it is unused, such as when you are using Spinbase with a Line input or a Bluetooth device. **Failure to do this will result in excess electronic background noise.**

STAYING GROUNDED - Because Magnetic phono cartridges have such a low output, the Phono input is much more sensitive to any noise or ground hum than other inputs. Because of this, many turntables are equipped with a grounding wire or have a screw to attach one. If your turntable requires grounding, attach the grounding wire from the ground thumbscrew on Spinbase to the ground screw on your turntable. Some turntables are not equipped with ground wires, and instead have their ground supplied through the RCA plugs.

CONTACT SUPPORT - There are so many different turntables, record players and other sources available to use with Spinbase that it's impossible to cover all the possibilities here. If you have any operation, connection, or performance questions or concerns don't hesitate to reach out to us. We're ready to help!

Support@andoveraudio.com | +1 978.775.3670

FCC STATEMENT: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.