



ECHELON[®]

TRUE WIRELESS EARPHONES

USER MANUAL

CHARGING THE DEDICATED CARRYING CASE

Note: Before charging your earphones for the first time, please remove and discard the plastic film from the back of each earphone.

Connect the provided USB charging cable to a power source and insert the USB-C tip into the charging port located on the back of the carrying case. Indicator lights on the front of the case will light up and blink when the earphones are charging. The earphones are at full battery capacity once all four (4) lights are lit up. Let the earphones reach full charge before use. This will take approximately 1.5 hours if the battery was completely drained.

PAIRING YOUR EARPHONES

How to pair both of your earphones at once:

Once the earphones are fully charged, remove the earphones from their charging case. The LED light on one earphone will flash white and the other will be solid white. Turn on the wireless pairing settings on your smartphone, tablet, or computer and select the device labeled "ECHBUDS". Once the earphones are paired, the LED light on both earphones will be solid white. Once your device is connected, the earphones will pair automatically upon future use and stay paired until you manually disconnect it. If the earphones are turned off, press and hold the multi-function buttons for 2 seconds until you see the LED light turns on.

How to pair just one single earphone:

Remove one earphone from the charging case. Wait for the LED

light on that earphone to flash white and then connect to your device's wireless pairing settings as described earlier.

HOW TO RESET THE EARPHONES

Press and hold the multi-function buttons for 8 seconds until the earphones turn on.

FUNCTIONS

TURN ON: Remove earphones from the charging case and the earphones will turn on automatically. Press and hold the multi-function buttons on both earphones for 3 seconds to turn the earphones on manually.

TURN OFF: Place earphones back inside the charging case and they will turn off automatically.

Press and hold the multi-function buttons on both earphones for 3 seconds to turn them off manually.

PLAY/PAUSE: Click the multi-function button on either earphones once to pause or play.

PREVIOUS/NEXT: Hold the multi-function button on the **right** earphone for 1.5 seconds to skip a song. Hold the multi-function button on the **left** earphone for 1.5 seconds to go back to a previous song.

VOLUME UP/DOWN: Double-click the multi-function button on the **right** earphone to turn the volume up. Double-click the multi-function button on the **left** earphone to turn the volume down.

ANSWER/END CALL: Click the multi-function button on either earphone once when receiving incoming calls to accept calls.

Click the multi-function button on either earphone once during the phone call to end the call.

REJECT CALL: Press and hold the multi-function button for 2 seconds to reject incoming calls.

ACTIVATE VOICE ASSISTANT: Triple-click the multi-function button on either earphone to activate your device's voice assistant.

FEATURES

- IPX7 waterproof rating
- Up to 5 hours of audio playtime
- Built-in microphone
- Wireless functionality with a range of 33 ft (10 m)
- Compatible with smartphones and other media devices
- Built-in rechargeable battery
- Comes with a magnetic closure carrying case

SPECIFICATIONS

- Earphone playback time: 5 hours
- Earphone charging time: 1.5 hours
- Carrying case charging time: 2.5 hours
- Earbud battery: 3.7V/50mAh
- Charging case battery: 3.7V/800mAh
- Accessories included: USB-C charging cable & three (3) silicone ear tips (sizes Small / Medium / Large)

ECHELON FIT® 1-YEAR LIMITED WARRANTY

For questions, assistance, or replacement parts, do not return to your retailer. Contact Echelon® customer service below.

For refunds on items not purchased from Echelon® directly, please contact your retailer.

Echelon® warrants this product to be free of manufacturing defects. Should any such defect develop or become evident within one year from the date of purchase, Echelon® will replace the entire product or, at its option, repair or replace the defective part(s) without charge.

Contact Echelon® customer service at 833-937-2453 or at info@echelon.com to determine

whether it is necessary to return the unit. To return, securely pack the entire unit. Be sure carton clearly identifies sender by name and address. Attach a letter or card describing defect and original sales receipt. Mail prepaid to Echelon Fitness Multimedia, LLC 6011 Century Oaks Dr. Chattanooga, TN 37416.

This warranty is void if damage or malfunction is due to abuse or failure to operate product in accordance with instructions and on recommended electrical current. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. If you have any questions, or would like to learn more about Echelon®, please contact us at 833-937-2453 or at info@echelonfit.com.

Register your product online at www.registermyechelon.com

Customer Service / Le service a la clientele / Servicio al Consumidor

833-937-2453 or Email at cs@echelonfit.com

DO NOT DISPOSE OF BATTERIES IN FIRE. ALWAYS DISPOSE OF BATTERIES PER LOCAL & FEDERAL GUIDELINES.

© 2020 ECHELON FITNESS MULTIMEDIA, LLC. All specifications are subject to change without notice. All rights reserved.

Echelon Fitness Multimedia, LLC 6011 Century Oaks Dr. Chattanooga, TN 37416

ECHELONFIT.COM



**Read Instructions
Before Operating**

**MADE IN
CHINA**



**PATENT
PENDING**

**REV: 092220
MODEL: ECHBUDS**