



slackers® RICKETY BRIDGE

Product #- SLA.835
Age Grade- 5+
Weight Limit- 250lbs

Contents:

- A- Bachar Ladder
- B- 3 Delta carabiners



ADULT INSTALLATION REQUIRED –This product should be unpacked and assembled by an adult, including site and tree selection as well as the secure and proper installation.



ADULT SUPERVISION RECOMMENDED- SEVERE INJURY OR DEATH MAY RESULT–Always exercise extreme caution when using the Rickety Bridge and Ninjaline™.



WARNING: Un-Healthy Tree Hazard –Do not attach or use a tree that is not healthy, diseased or damaged. It may fail causing serious injury or death.



WARNING Domestic Outdoor use only

BE SAFE! - ALWAYS FOLLOW THESE RULES

- The Rickety Bridge is intended for use by ages 5+ up to 250lbs with adult supervision
 - Every time you use the Rickety Bridge, make sure everything is installed correctly and check for wear before using.
 - If worn or damaged parts are found, contact b4Adventure for replacement parts - Do not substitute with other, non-b4 Adventure parts or failure resulting in injury could result.
 - One person only at a time. Wear close fitting, athletic style clothing, NO scarves or other loose clothing that could become entangled.
 - Never use the line when it is wet or if there is rain or lightning in the area.
 - As with any type of exercise or athletic activity, you should consult your physician BEFORE engaging in the activity.
- Choose a clear area for the Rickety Bridge with a sturdy anchor point, a healthy tree 38" (97cm) in circumference or 12" diameter


slackers® RICKETY BRIDGE

Product #- SLA.835
Age Grade- 5+
Weight Limit- 250lbs

Follow installation instructions and warnings for before installing Rickety Bridge



1. Installing your Rickety Bridge to the Ninjaline®

- Your Ninjaline has multiple pockets for attaching a variety of obstacles. Your Bridge will need 3 pockets
- Attach the Rickety bridge anywhere along the Ninjaline




Adjust the bars of your Rickety Bridge

- You can adjust both the top and bottom bars.
- Adjust the top bars down and the bottom bars up for shorter users
- Adjust the top bars up and put the bottom bars at the lowest level for taller users



- You can also adjust the bottom bars up and down to create a 'hill' or 'valley' pattern for extra difficulty





Product #- SLA.835
Age Grade- 5+
Weight Limit- 250lbs

MAINTENANCE OF YOUR Rickety Bridge™

At the beginning of each play season:

- Tighten all hardware.
- Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
- Check all metal parts for rust. If found, sand and repaint using a non-lead based paint meeting the requirements of 16CFR 1303. Lubricate all metallic moving parts per manufacturer's instructions
- Check all moving parts including disks, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.
- Check the rope and disks for deterioration, cracking or fraying. If found, DO NOT USE and dispose of immediately.

• X.3.1.1 Loose-Fill Materials:

X.3.1.1 Maintain a minimum depth of 9 inches of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet high; and 9- inches of sand or pea gravel for equipment up to 5 feet high. NOTE: An initial fill level of 12 inches will compress to about a 9- inch depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically refilled to maintain a least a 9- inch depth.

Twice a month during play season:

- Tighten all hardware.
- Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.

• X.3.1.1 Loose-Fill Materials:

X.3.1.1 Maintain a minimum depth of 9 inches of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet high; and 9- inches of sand or pea gravel for equipment up to 5 feet high. NOTE: An initial fill level of 12 inches will compress to about a 9- inch depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically refilled to maintain a least a 9- inch depth.

Once a month during play season:

- Check all moving parts including disks, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.

• At the end of each play season or when the temperature drops below 32 Degrees Fahrenheit take in your Rickety Bridge and store indoors in cool dry location.

• X.3.1.1 Loose-Fill Materials:

X.3.1.1 Maintain a minimum depth of 9 inches of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet high; and 9- inches of sand or pea gravel for equipment up to 5 feet high. NOTE: An initial fill level of 12 inches will compress to about a 9- inch depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically refilled to maintain a least a 9- inch depth.

TRAIN LIKE A NINJA! HAVE FUN WITH YOUR RICKETY BRIDGE ALWAYS BE SAFE!



Product #- SLA.835
Age Grade- 5+
Weight Limit- 250lbs

- Place the equipment on level ground, not less than 6 ft (1.8 m) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- To prevent serious injury, children must not use the equipment until properly installed.
- Do not install home playground equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious injury or death to the equipment user.
- Disassemble and dispose of the Rickety Bridge per city regulations
- Observing the following statements and warnings reduces the likelihood of serious or fatal injury.
- Do not to walk close to, in front of, behind, or between moving items
- Do not twist swing chains or ropes or loop them over the top support bar since this may reduce the strength of the strap
- Do not to use the equipment in a manner other than intended
- Do not wear inappropriate items, such as but not limited to, loose fitting clothing, hood and neck drawstrings, scarves, cord-connected items, capes and ponchos. These items can cause death by strangulation
- Do not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.
- Remove their bike or other sports helmet before playing on the playground equipment.
- Dress children with well fitting and full foot enclosing footwear. Examples of inappropriate footwear are clogs, flip flops, and sandals.
- When measured from the ground, there shall be no part of the bridge where the child is able to climb, sit or stand above a height of 8ft (250 cm)

PRODUCT DISCLAIMER & NOTICE

Any person purchasing, installing or using equipment from B4Adventure must:

- Obtain proper training and instruction regarding its proper use and safety precautions to always practice.
 - Ensure proper & adequate supervision and instruction (this include the continuous use of appropriate safety procedures & equipment) for themselves and others using the equipment;
 - Check that all equipment is properly maintained, in good working order and inspected for damage or wear prior to each use, and;
 - You assume all risks and accept full responsibility for any injury (including death) or damages that may occur from its use.
- Warranty: one year on all parts and workmanship. Normal wear from use not covered

All the information provided by b4Adventure either printed, electronic or other, is not to be considered professional instruction or advice. Users of this equipment are encouraged to seek professional instruction regarding specific questions about usage, location, installation or other aspects of training courses and slacklines.

Please save these instructions for future reference.

Owners shall be responsible for maintaining the legibility of the warning labels.

PRODUCT COMPLIES WITH ALL CPSC & ASTM F1487 HOME PLAYGROUNDEQUIPMENT STANDARDS AND EN71

