




# ORB OUTDOOR

## Quick Start Guide

v2.0.0

## What's in the Box



## Know your Orb Outdoor

Disconnect the camera from the power before installation or removing its SD card.



- Press and hold the reset button for 10 s to reset the camera.
- Double-press the reset button to enable camera's hotspot.

See the table below for definitions of camera's LED behaviors.

LED Indicator Status	Device Status
Off	<ul style="list-style-type: none"><li>Power off/LED turned off</li><li>Rebooting after reset</li></ul>
Solid red	<ul style="list-style-type: none"><li>Booting</li><li>Device malfunction</li></ul>
Flashing red	<ul style="list-style-type: none"><li>Network connection failed</li><li>Pairing failed</li></ul>
Flashing green	<ul style="list-style-type: none"><li>Ready for network configuration</li><li>Ready to pair</li></ul>
Solid green	Operating properly
Flashing green and red alternately	Updating firmware

## Camera Setup

Follow the steps below to add the camera to your IC Home account.

**Step 1** Scan the following QR code or search "IC Home" in Google Play or the App Store to download & install the app.

If you already use the app, make sure that you are using the latest version.




**Step 2** Launch the app. Then create an account if you are a new user.

**Step 3** Connect the camera to power source with the power adapter.

**Step 4** After the camera boots up, the LED indicator light flashes green (wire-free camera) or is on solid green (wired camera).


If the LED indicator status goes wrong, reset the camera.

**Step 5** Follow the on-screen prompts to add the camera. Repeat the adding process if you have multiple cameras.



## Camera Installation

Make sure that the mounting surface is strong enough to hold at least three times the weight of the camera and the bracket.







**Step 1** Peel the U-shaped mounting template and stick it to the desired installation location.


**Step 2** Drill holes following the template hole locations and then insert the provided wall anchors.





## About the Guide

- This quick start guide is for reference only. Minor differences might be found in the user interface.
- All the design and software here is subject to change without prior written notice.
- All trademarks & registered trademarks mentioned are the properties of their respective owners.
- Please visit our website or contact your local service engineer for more information.
- If there is any uncertainty or controversy, please refer to our final explanation.

- Step 3** Secure the mounting bracket to the surface with the included mounting screws.
- Step 4** Align  on the top of the camera with  on the bracket, then fit the two parts together.
- Step 5** Rotate the camera counterclockwise until it is locked. Make sure align  with .
- Step 6** Power on the camera and then adjust its angle properly.


### Wall Mount







- Step 1** Peel off the rectangular mounting template and stick it to the desired installation area.
- Step 2** Drill holes into the mounting surface as the mounting template marks and then insert wall anchors as needed.
- Step 3** Secure the mounting bracket to the surface with included mounting screws.
- Step 4** Align  on the top of the camera with  on the bracket, then fit the two parts together.
- Step 5** Rotate the camera counterclockwise until it is locked. Make sure  align with .
- Step 6** Power on the camera and then adjust its angle properly.

### Pole Mount

- Make sure that the pole is strong enough to hold at least three times the weight of the camera and the bracket.
- The clamps are not provided. Please prepare them in advance.



- Step 1** Thread the clamp through the mounting holes on the bracket, then attach the bracket to the pole.

- Step 2** Align  on the top of the camera with  on the bracket, then fit the two parts together.
- Step 3** Rotate the camera counterclockwise until it is locked. Make sure align  with .
- Step 4** Power on the camera and then adjust its angle properly.

## FAQ

- **Q: The device doesn't boot up or work as expected?**  
Check the LED indicator status. If the light is not in green, press and hold the reset button for 10s to reset the camera.
- **Q: How do I connect the camera to another Wi-Fi network?**
- If the camera is online, select Device Details > Network Config to change the Wi-Fi connection on the app.
  - If the camera is offline, reset the camera, and then configure the camera again.
- **Q: Is the connection taking too long?**
- Check if the distance between the camera and the router, and that between the camera and the smart phone is both within 5 m (16.4 ft) during the connection.
  - Check the Wi-Fi configuration of the router: Select the channel to auto, and the mode to 11bgn mixed.
- **Q: How is the recorded video saved when the SD card is full?**  
When the micro SD card is full, the system will overwrite the previous recorded videos. Save the important information in time.
- **Q: Where are the recorded videos saved?**  
If you have activated the cloud storage and installed a micro SD card, the recordings will be both saved to the card and cloud. If the cloud storage is deactivated, the recordings are saved to the SD card. Videos recorded during live view or playback is saved on your phone.
- **Q: Is the device offline?**  
Check the indicator status:
- Solid green: Check whether the router can connect to the Internet. If the network is connected, restart the camera.
  - Flashing red: Reset the camera, and then configure the camera again.
  - Solid red: The camera is faulty.



For more questions, please scan the QR code below or visit:  
[www.icrealtime.com/help-center](http://www.icrealtime.com/help-center)