


# SMART UPRIGHT ROW-N-RIDE®

# EXERCISER

# NO. 077 SMART USER MANUAL



**IMPORTANT!** Please retain owner's manual for maintenance and adjustment instructions. Your satisfaction is very important to us, **PLEASE DO NOT RETURN UNTIL YOU HAVE CONTACTED US**: support@sunnyhealthfitness.com or 1- 877 - 90SUNNY (877-907-8669).



# **IMPORTANT SAFETY INFORMATION**


We thank you for choosing our product. To ensure your safety and health, please use this equipment correctly. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained, and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.

- 1. Before starting any exercise program, you should consult your physician to determine if you have any medical or physical condition that could put your health and safety at risk or prevent you from using the equipment properly. Your physician's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
- 2. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, shortness of breath, lightheadedness, dizziness, or feelings of nausea. If you do experience any of these conditions, you should consult your physician before continuing with your exercise program.
- 3. Keep children and pets away from the equipment. The equipment is designed for adult use only.
- 4. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 2 feet (60 cm) of free space all around it.
- 5. Ensure that all nuts and bolts are securely tightened before using the equipment. The safety of the equipment can only be maintained if it is regularly examined for damage and/or wear and tear.
- 6. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during exercise, discontinue use of the equipment immediately and do not use until the problem has been rectified.
- 7. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may become entangled in the equipment.
- 8. Do not place fingers or objects into the moving parts of the equipment.
- 9. The maximum weight capacity of this unit is 220 lbs (100kgs).
- 10. The equipment is not suitable for the rapeutic use.
- 11.To avoid bodily injury and/or damage to the product or property, proper lifting and moving are required.
- 12.Your product is intended for use in cool and dry conditions. You should avoid storage in extremely cold, hot or damp areas as this may lead to corrosion and other related problems.

13. This equipment is designed for indoor and home use only; it is not intended for commercial use.

# **PRE-ASSEMBLY CHECK LIST**

Before you start to assemble, please make sure all parts are included.



No.	Description	Spec.	Qty.	No.	Description	Spec.	Qty.
3	Bolt	M8*42	1	40	Right Pedal		1
4	Handlebar		1	41	Meter	DSC03601N- APP	1
6	Nut	M8*13	1	47	Device Holder		1
7	Handlebar Tube		1	48	Support Tube		1
13	Left Pedal		1	Α	Spanner	S13, S15, S17	1
18	Seat		1	В	Allen Wrench	S5	1
21	Knob	Ф47*40*M8	1	С	Manual		1
28	Main Frame		1	D	Thank You Card		1
36	Front Stabilizer		1	E	Battery	AA	2
38	Rear Stabilizer		1				

# Ordering Replacement Parts (U.S. and Canadian Customers only)


Please provide the following information in order for us to accurately identify the part(s) needed:

- ✓ The model number (found on cover of manual)
- ✓ The product name (found on cover of manual)
- ✓ The part number found on the "EXPLODED DIAGRAM" (page 13) and "PARTS LIST" (page 14)

Please contact us at <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877 - 90SUNNY (877-907-8669).

# **ASSEMBLY INSTRUCTIONS**


We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877-90SUNNY (877-907-8669).




STEP 1:

Open the **Main Frame (No. 28)** as shown in the picture on the left.

NOTE: The Pin (No. 29) has been inserted into Front Connecting Tube (No. 32).






### STEP 2:

Remove 2 Bolts (No. 35), 2 Nuts (No. 33) and 2 Washers (No. 5) from the Front Stabilizer (No. 36) with Spanner (No. A). Attach Front Stabilizer (No. 36) to Front Connecting Tube (No. 32) using 2 Bolts (No. 35), 2 Nuts (No 33) and 2 Washers (No. 5) that were removed. Tighten and secure with Spanner (No. A).

Remove 2 Bolts (No. 35), 2 Nuts (No. 33) and 2 Washers (No. 5) from the Rear Stabilizer (No. 38) with Spanner (No. A). Attach Rear Stabilizer (No. 38) to Main Frame (No. 28) using 2 Bolts (No. 35), 2 Nuts (No. 33) and 2 Washers (No. 5) that were removed. Tighten and secure with Spanner (No. A).





### STEP 3:

Insert the **Connecting Tube (No. 15)** into the metal bracket slot of **Seat Connecting Tube (No. 31)**. Then insert the **Bolt (No. 3)** into the **Seat Connecting Tube (No. 31)** and secure the **Nut (No. 6)** using **Spanner (No. A)**.

### STEP 4:


Loosen and pull out the **Knob** (No. 10) from the **Pedal Connecting Tube** (No. 9), insert the **Handlebar Tube** (No. 7) into the **Pedal Connecting Tube** (No. 9). Then insert and secure with the **Knob** (No. 10) after adjusting to proper height.





### STEP 5:

Remove preassembled 2 Bolts (No. 3), 2 Washers (No. 5) and 2 Nuts (No. 33) from the Handlebar (No. 4) and attach the Handlebar (No. 4) to the Handlebar Tube (No. 7) using 2 Bolts (No. 3), 2 Washers (No. 5) and 2 Nuts (No. 33) and secure with Spanner (No. A).




### STEP 6:

Insert the **Meter (No. 41)** onto the tab on the **Handlebar (No. 4)**.

### STEP 7:


Attach the **Fixed Iron Sheet (No. 19)** to the **Seat Connecting Tube (No. 31)**, adjust the **Seat (No. 18)** to your desired position, then tighten and secure with the **Knob (No. 21)**.



### STEP 8:

Remove 1 Bolt (No. 51),1 Bolt (No. 49),1 Nut (No. 6) and 3 Washers (No. 50) from the Main Frame (No. 28).

Attach the **Support Tube (No. 48)** to the **Main Frame** (No. 28) using 1 Bolt (No. 51),1 Bolt (No. 49),1 Nut (No. 6) and 3 Washers (No. 50) that were removed, tighten and secure with **Spanner (No. A)** and **Allen Wrench (No. B)**.





### STEP 9:

Remove the **Butterfly Nut (No. 45)** and the **Washer (No. 46)** from the **Device Holder (No. 47)**.

Attach the **Device Holder (No. 47)** onto the bracket of the **Support Tube (No. 48)** using the **Butterfly Nut (No. 45)** and the **Washer (No. 46)** that were removed, tighten and secure with your hand.


**NOTE:** When assembling the **Device Holder (No. 47)**, ensure that it is aligned to the bracket slot of the **Support Tube (No. 48)**.





### **STEP 10:**


Attach the Left & Right Pedals (No. 13 & No. 40) to the Pedal Connecting Tube (No. 9) and tighten Left & Right Pedals (No. 13 & No. 40) <u>*clockwise*</u> with the Spanner (No. A).



### **STEP 11:**

Unhook Exercise Bands (No. 42) from the Seat Connecting Tube (No. 31), and connect the Exercise Bands (No. 42) to the hooks on the Main Frame (No. 28).

The assembly is complete!




# **ADJUSTMENT INSTRUCTIONS**

	ADJUSTING THE HANDLEBAR
1 2 2 10 2 10	Loosen the <b>Knob (No. 10)</b> and pull out. Raise or lower the <b>Handlebar</b> <b>Tube (No. 7)</b> to desired height. Then tighten the <b>Knob (No. 10)</b> .
	ADJUSTING THE SEAT Loosen and remove the Knob (No. 21) located under the Seat Connecting Tube (No. 31). Move the Seat (No. 18) to desired position, then re-insert and tighten the Knob (No. 21).
	ADJUSTING THE SEAT TUBE
31 29 -32 28 -32 28 -32 28 -32 28 -32 28 -32 28 -32 28 -31 -32 -32 -32 -32 -32 -32 -32 -32	To adjust the Seat Tube (No. 25), lift the Seat Connecting Tube (No. 31). Remove the Pin (No. 29) from Front Connecting Tube (No. 32) and raise or lower the Seat Tube (No. 25) to desired position. Re-insert the Pin (No. 29) to secure. Then lower the Seat Connecting Tube (No. 31). Raising or lowering Seat Tube (No. 25) will change the difficulty of your exercise.
	NOTE: Make sure Exercise Bands (No. 42) are not hooked to Main Frame (No. 28) when adjusting the Seat Tube (No. 25). Do not extend the Seat Tube (No. 25) to pass "MAX" line.
	ADJUSTING THE EXERCISE BAND
-42 28-	You can adjust the difficulty of your exercise by adjusting the <b>Exercise Bands (No. 42)</b> . To reduce difficulty, unhook <b>Exercise Bands (No. 42)</b> from the <b>Main Frame (No. 28)</b> and connect the <b>Exercise Bands (No. 42)</b> to the hooks on the <b>Seat Connecting Tube (No. 31)</b> .
31 42 28	
37	ADJUSTING THE BALANCE
37 37	In order to achieve a smooth and comfortable ride, you must ensure that the bike is stabled and secured. If you notice that the bike is unbalanced during use, you should adjust the <b>End Caps (No. 37)</b> located on the rear stabilizer until the bike becomes levelled with the floor surface.

# **FOLDING INSTRUCTIONS**

	A. Adjust the Seat Tube (No. 25) to the lowest level by the Pin (No. 29). NOTE: Make sure Exercise Bands (No. 42) are not connected to Main Frame (No. 28) when folding.
	B. Adjust the Handlebar Tube (No. 7) to the lowest level by Knob (No. 10).
A Contraction of the second se	C. Hold the <b>Handlebar (No. 4)</b> and fold the product.

# **BATTERY INSTALLATION & REPLACEMENT**



# **BATTERY INSTALLATION:**

- 1. Take out 2 AA batteries from manual bag.
- 2. Press the buckle of battery cover on the Meter (No. 41), then remove battery cover.
- 3. Install 2 AA batteries into the battery case on the back of the **Meter (No. 41)**. Pay attention to the battery + and poles before installing.
- 4. Press the buckle of battery cover, then put the battery cover back to the back of the **Meter (No. 41)**.

The installation is complete!

# **BATTERY REPLACEMENT:**

- 1. Press the buckle of battery cover on the back of the Meter (No. 41), then remove battery cover.
- Remove the 2 old AA batteries in the battery case and install 2 new AA batteries into the battery case on the back of the Meter (No. 41). Pay attention to the battery + and – poles before installing.
- Press the buckle of battery cover, then put the battery cover back to the back of the Meter (No. 41).


The replacement is complete!

**NOTE:** Dispose battery according to your state and regional guidelines.

# **EXERCISE METER**

# **SPECIFICATIONS:**

TIME	00:00-99:59 MIN/SEC.
COUNT (CNT)	0-9999 STROKES
CALORIES (CAL)	
TOTAL.	0-9999 STROKES



# FUNCTIONS:

TIME: Displays the workout time while exercising.
COUNT (CNT): Accumulate the strokes while exercising.
CALORIES (CAL): Displays calories amount burned while exercising.
TOTAL: Displays the total number of strokes since batteries installed.
SCAN: Automatically scan through each function between ①TIME ②CALORIES (CAL) ③TOTAL.

# **KEY FUNCTION:**

**MODE:** Press to select the function you want. Hold the key for 4 seconds to reset all values.

# **OPERATION PROCEDURES:**

**AUTO ON/OFF:** The meter will turn on when exercise starts or when **MODE** is pressed. The meter will shut off automatically after there is no activity for 4 minutes.

# **APP CONNECTION:**

Connect Smart Equipment to SunnyFit App:

1. Scan to download SunnyFit from the app store:



- 2. Ensure that the Bluetooth function is turned on from your mobile device.
- 3. If this is your first time using the SunnyFit app, follow the in-app instructions to register for your free SunnyFit account and log in.
- 4. Begin any workout activity that matches your smart equipment, then follow the onscreen prompts to search for and connect to your smart equipment.
- 5. When connected, your stats and records will be displayed at the end of your course/session, and recorded in your account profile!


Troubleshooting:

 If you are having trouble connecting your smart equipment, visit <u>www.sunnyfit.com/guide</u> or scan the QR code below:



• If you require additional support, please contact <a href="mailto:support@sunnyfit.com">support@sunnyfit.com</a>

# EXPLODED DIAGRAM



# PARTS LIST

No	Description	Spec.	Qty.	Ν
1	Sponge	Φ29	2	2
2	Plug	Φ25*1.5	3	2
3	Bolt	M8*40.5	4	3
4	Handlebar		1	3
5	Washer	OD22*ID8	6	3
6	Nut	M8*13	3	3
7	Handlebar Tube		1	3
8	Bushing	30*30*T1.5	2	3
9	Pedal Connecting Tube		1	3
10	Knob	Ф38*L65*M16	1	3
11	Bearing Sleeve	Φ28*13	2	3
12	Hexagon Screw	M8*50	1	3
13	Left Pedal		1	4
14	Bearing Sleeve	Φ25*11	4	4
15	Connecting Tube		1	4
16	Bearing Sleeve	Ф19*12	4	4
17	Plug	30*30*1.5	1	4
18	Seat		1	4
19	Fixed Iron Sheet		1	4
20	Screw	M6	2	4
21	Knob	Ф47*40*M8	1	4
22	Plug	40*20*1.5	1	4
23	Bolt	M10	3	5
24	Stopper		1	5
25	Seat Tube		1	1
26	Washer	OD20*ID11	6	E
27	Nut	M10	3	

			_
No.	Description	Spec.	Qty.
28	Main Frame		1
29	Pin	Ф8*42.5	1
30	Plug	Ф19*35	2
31	Seat Connecting Tube		1
32	Front Connecting Tube		1
33	Nut	M8*12	6
34	Сар	Ф46*36	2
35	Bolt	M8*48	4
36	Front Stabilizer		1
37	End Cap	Ф38*35	2
38	Rear Stabilizer		1
39	Square Buckle	Ф3.2	3
40	Right Pedal		1
41	Meter	DSC03601N -APP	1
42	Exercise Band	Ф8*710	3
43	Bolt	M8*65	1
44	Plastic Wheel		3
45	Butterfly Nut	M6	1
46	Washer	Ф6	1
47	Device Holder		1
48	Support Tube		1
49	Bolt	M8*20	1
50	Washer	Ф8	3
51	Bolt	M8*60	1
А	Spanner	S13, S15, S17	1
В	Allen Wrench	S5	1

# CONNECT with us



Track your fitness progress & join **FREE** workout courses!

### Download **3 SUNNYFIT** today!





# FOLLOW

Find us on social media @sunnyhealthfitness



/sunnyhealthandfitness

www.sunnyhealthfitness.com