




TWISTING STAIR STEPPER WITH BANDS

NO. 068

USER MANUAL



IMPORTANT! Please retain owner's manual for maintenance and adjustment instructions. Your satisfaction is very important to us, **PLEASE DO NOT RETURN UNTIL YOU HAVE CONTACTED US:** support@sunnyhealthfitness.com or 1- 877 - 90SUNNY (877-907-8669).



IMPORTANT SAFETY INFORMATION

We thank you for choosing our product. To ensure your safety and health, please use this equipment correctly. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.

1. Before starting any exercise program, you should consult your physician to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your physician's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
2. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, shortness of breath, lightheadedness, dizziness or nauseous feeling. If you do experience any of these conditions, you should consult your physician before continuing with your exercise program.
3. Keep children and pets away from the equipment. The equipment is designed for adult use only.
4. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 4 feet (1.2 M) of free space all around it.
5. Ensure that all nuts and bolts are securely tightened before using the equipment. The safety of the equipment can only be maintained if it is regularly examined for damage and/or wear and tear.
6. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during exercise, discontinue use of the equipment immediately and do not use until the problem has been rectified.
7. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may become entangled in the equipment.
8. Do not place fingers or objects into the moving parts of the equipment.
9. The maximum weight capacity of this unit is 220 pounds (100 KG).
10. The equipment is not suitable for therapeutic use.
11. To avoid bodily injury and/ or damage to the product or property, proper lifting and moving are required.
12. Your product is intended for use in cool and dry conditions. You should avoid storage in extreme cold, hot or damp areas as this may lead to corrosion and other related problems.
13. This equipment is designed for indoor and home use only; it is not intended for commercial use.

PARTS LIST

No.	Description	Spec.	Qty.
1	Pedal (R&L)		2
2	Screw	M6	2
3	Bearing Cap		2
4	Bearing Sleeve		4
5	Pedal Tube (L)		1
6	Internal Ring		2
7	Main Frame		1
8	Nut	M6	2
9	Meter		1
10	Sensor		1
11	Pedal Webbing		2
12	Connecting Ring		2
13	Pedal Tube (R)		1
14	Magnet		1
15	Screw	M5	4
16	Stopper		2

No.	Description	Spec.	Qty.
17	Cap		4
18	Bolt	M6	4
19	Bolt	M6	2
20	Nut	M6	4
21	Hydraulic Cylinder		2
22	Nut	M8	3
23	Washer		2
24	Bolt	M8	2
25	Pulley		1
26	Pulley Bracket		1
27	Washer		1
28	Knob		1
29	Bolt	M8	1
30	Cable		1
31	Exercise Band		2
32	Screw	M5	2

Ordering Replacement Parts (U.S. and Canadian Customers only)


Please provide the following information in order for us to accurately identify the part(s) needed:

- ✓ The model number (found on cover of manual)
- ✓ The product name (found on cover of manual)
- ✓ The part number found on the “EXPLODED DIAGRAM” and “PARTS LIST” (found near the front of the manual)

Please contact us at support@sunnyhealthfitness.com or 1- 877 - 90SUNNY (877-907-8669).



ASSEMBLY INSTRUCTIONS

We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).





STEP 1:

Remove the main frame from the box. Lift one pedal up with your hands. Ensure the **Cable (No. 30)** is secured around the **Pulley (No. 25)** as shown in the picture below.



STEP 2:

Turn the **Knob (No. 28)** *clockwise* "+" all the way until it reaches its furthest point.




STEP 3:

Attach the **Exercise Bands (No. 31)** to the pedal hooks located at the front of the left and right pedals as shown in the picture below.

ASSEMBLY INSTRUCTIONS

We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).



The assembly is complete!

❖ TO ADJUST THE STEPPING HEIGHT:


NOTE: The stepper is set at its highest stepping height after assembly.

To lessen the range of the stepping height, loosen the **Knob (No. 28)** by turning *counter-clockwise*.

NOTE: Height range will decrease with each *counter-clockwise* turn.

EXERCISE BAND INSTRUCTIONS


1. Unscrew the hook nut located on the band until one end of the hook is open as shown in the first picture below.
2. Attach the band hook onto the pedal hook and screw the hook nut closed so that the pedal hook is secured within the hook nut.
3. Assembly is done.



Adjusting the Rope Length	
To Lengthen Rope	To Shorten Rope
<p>Pull one side of the rope down and pull the bottom of the rope downward as shown in the picture below. Repeat this process until the rope is at the desired length.</p> <p>NOTE: This adjustment decreases the tension on the bands.</p>	<p>Push the rope upward from the bottom, then pull one side of the top rope as shown in the picture below. Repeat this process until the rope is at the desired length.</p> <p>NOTE: This adjustment increases the tension on the bands.</p>
<p>NOTE: When lengthening the rope, only one side of the rope can be pushed down. If the side that you're trying to push down on doesn't move, try the other side of rope.</p>	

MAINTENANCE & CARE

1. If the stepper screeches during exercise, please discontinue use and do the following: loosen the screw located on the U-Shaped iron and then loosen the cable as shown in the picture below. Next, lubricate both the U-Shaped iron and cable to improve the sliding condition. Re-tighten and secure the screw and cable.
2. For safety and efficiency, please be sure to inspect and lubricate the U-Shaped iron and cable regularly.
3. Always use dry cloth when cleaning the stepper, never clean the stepper using a wet or damp cloth.
4. Store the stepper in a dry area free of moisture, do not store or leave outdoors.
5. During exercise the hydraulic cylinders may produce noise if they become too hot, it is perfectly normal for this to occur.
6. To avoid potential injuries to your hands, please refrain from touching the hydraulic cylinders during or immediately after an exercise.



OPERATING INSTRUCTIONS

1. Please read all instructions before attempting to assemble the equipment. During assembly and during the use of the equipment, please make sure to follow all instructions carefully. Any improper techniques of use or assembly may result in injury or damage to the equipment.
2. The suggested exercise regimen for optimal results is 10-15 minutes per day, at least three times a week.
3. Before beginning exercise, always inspect the equipment to ensure that all moving parts, as well as hardware, are secured correctly and in proper condition.
4. Use the **Knob (No. 28)** to adjust the stepping height & tension.
“+” When the knob is tightened, the tension level is increased along with the height of the stepping range. (Turn the knob *clockwise* to tighten).
“-” When the knob is loosened, the tension level is decreased along with the height of the stepping range. (Turn the knob *counter-clockwise* to loosen).

EXERCISE COMPUTER

Our computerized display console on the Sunny Twisting Stair Stepper with Bands allows the user to tailor a personalized workout by monitoring their progress. During a workout, the display console will alternately and repeatedly display your Time, Calories, Count, Reps per minute and Scan (all of the above). With our easy-to-use console, the user can efficiently track their fitness improvements from one workout to the next.

FUNCTION KEY:

- 1. MODE:** To select your specification mode and/or turn on display console. Hold the MODE button for 3 seconds to reset functions back to zero.

FUNCTIONS AND SPECIFICATIONS:

SCAN -- Repeatedly displays all functions alternately (in the following order)

TIME -- Counts the total time elapsed (counts up to 99:59 MIN.)

COUNT -- Automatically accumulates the count of steps taken during sessions. Meter counts 1 step after you step once with each foot.

REPS/MIN -- Displays the count of steps per minute

CALORIES -- The rate of calories burned per hour (0.0-999.9 KCAL)

HOW TO USE:

1. AUTO ON/OFF:

Begin pedaling or press the MODE button to turn on the console. Once the display console is on, it will remain active while in motion. The display console will automatically turn off when it has reached approximately 4 minutes without any motion.


2. RESET:

To reset the display console, hold down the MODE button for 3 seconds. You can also reset the console by removing the batteries.

- 3. BATTERY/TROUBLESHOOT:** The display console uses (1) LR44, 1.5V battery. If the display appears improper or becomes difficult to read, please try installing new batteries before contacting our customer service.


NOTE:

1. The monitor is auto-powered. It turns on at start of exercise and turns off when no movement is made between 4 to 5 minutes.
2. All functions will automatically stop calculating when a "STOP" icon appears in the upper left corner of the display monitor. This occurs when there is no signal for a period of 4 seconds. Once the exercise begins again, the meter will automatically start recalculating and the "STOP" icon will disappear.



CHANGING THE BATTERY

1. Remove the plastic cap from the battery.
2. Remove the battery using your hand or with the tool provided.
3. Insert the new battery with your hand or the provided tool. Ensure that the positive side of the battery (+) is facing upward once the new battery is in place.
4. Place the plastic cap over the battery.
5. Connect the wire onto the meter.
6. Insert the meter onto the Main Frame.



CONNECT WITH US

FOR FITNESS
ARTICLES, VIDEOS
& WORKOUTS



@SUNNYHEALTHANDFITNESS



@SUNNYHEALTHFITNESS



@SUNNYHEALTHFIT



/SUNNYHEALTHFITNESS



/SUNNYHEALTHANDFITNESS

WWW.SUNNYHEALTHFITNESS.COM