


# FOLDABLE MAGNETIC X-BIKE PRO SF-B223011

### **USER MANUAL**



**IMPORTANT!** Please retain owner's manual for maintenance and adjustment instructions. Your satisfaction is very important to us, **PLEASE DO NOT RETURN UNTIL YOU HAVE CONTACTED US**: <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877-90SUNNY (877-907-8669).














### **IMPORTANT SAFETY INFORMATION**

We thank you for choosing our product. To ensure your safety and health, please use this equipment correctly. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained, and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.

- 1. Before starting any exercise program, you should consult your physician to determine if you have any medical or physical conditions that could put your health and safety at risk or prevent you from using the equipment properly. Your physician's advice is essential if you are taking medication that affects your heart rate, blood pressure, or cholesterol level.
- 2. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, shortness of breath, lightheadedness, dizziness, or feelings of nausea. If you do experience any of these conditions, you should consult your physician before continuing with your exercise program.
- 3. Keep children and pets away from the equipment. The equipment is designed for adult use only.
- 4. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 2 feet (60 CM) of free space all around it.
- 5. Ensure that all nuts and bolts are securely tightened before using the equipment. The safety of the equipment can only be maintained if it is regularly examined for damage and/or wear and tear.
- 6. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during exercise, discontinue use of the equipment immediately and do not use until the problem has been rectified.
- 7. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may become entangled in the equipment.
- 8. Do not place fingers or objects into the moving parts of the equipment.
- 9. The maximum weight capacity of this unit is 300 lbs (135 kgs).
- 10. The equipment is not suitable for therapeutic use.
- 11. To avoid bodily injury and/or damage to the product or property, proper lifting and moving are required.
- 12. Your product is intended for use in cool, dry conditions. You should avoid storage in extreme cold, hot, or damp areas as this may lead to corrosion and other related problems.
- 13. This equipment is designed for indoor and home use only; it is not intended for commercial use.

## PRE-ASSEMBLY CHECK LIST


Before you start to assemble, please make sure all parts are included



No.	Description	Spec.	Qty.
1	Front Main Frame Post		1
2	Rear Support Frame		1
3	Front Stabilizer		1
4	Rear Stabilizer		1
5	Seat Support Post		1
6	Handlebar Connect Post		1
7	Front Handlebar Post		1
12	Computer		1
22	Bottle Cover		1

No.	Description	Spec.	Qty.
23	Left Bottle Cover		1
24	Right Bottle Cover		1
28	Left Pedal		1
29	Right Pedal		1
30	Seat		1
Α	Hardware Package		1
В	Thank You Card		1
С	Manual		1
D	Battery	AAA	2

### **HARDWARE PACKAGE**



### Ordering Replacement Parts (U.S. and Canadian Customers only)


Please provide the following information in order for us to accurately identify the part(s) needed:

- √ The model number (found on cover of manual)
- √ The product name (found on cover of manual)
- ✓ The part number found on the "EXPLODED DIAGRAM" and "PARTS LIST" (found near the end
  of the manual)

Please contact us at <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877-90SUNNY (877-907-8669).

### **ASSEMBLY INSTRUCTIONS**


We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877-90SUNNY (877-907-8669).



#### STEP 1:

Pull the **Ring Spring Pin (No.53)** out and open the **Rear Support Frame (No.2)** and the **Front Main Frame Post (No.1)** as the direction of the arrow shown in Figure.

Insert the Ring Spring Pin (No.53) into the hole A in the steel plate of the Front Main Frame Post (No.1).




#### STEP 2:

Attach the Front Stabilizer (No. 3) to the Front Main Frame Post (No. 1) with 2 Bolts (No. 33) and 2 Big Curve Washer (No. 15), 2 Nuts (No. 16). Tighten and secure with Spanner (No. 93).

Attach the Rear Stabilizer (No. 4) to the Rear Support Frame (No. 2) with 2 Bolts (No. 33) and 2 Big Curve Washer (No. 15), 2 Nuts (No. 16). Tighten and secure with Spanner (No. 93).

We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877-90SUNNY (877-907-8669).




#### STEP 3:

Remove 6 Bolts (No. 17), 4 Curve Washers (No. 18) and 2 Washers (No.19) from the Handlebar Connect Post (No. 6) with Allen Wrench (No. 91).

Attach the Bottle Cover (No. 22) into the Handlebar Connect Post (No. 6).

Connect the Computer Wire II (No. 20) with Computer Wire I (No. 26). Then insert it into the Rear Support Frame (No. 2).


Attach the Handlebar Connect Post (No. 6) to the Rear Support Frame (No. 2) with 6 Bolts (No. 17), 4 Curve Washers (No. 18) and 2 Washers (No.19) that were removed. Tighten and secure with Allen Wrench (No. 91).



#### STEP 4:


Attach the Left Bottle Cover (No. 23) and Right Bottle Cover (No. 24) to the Rear Support Frame (No. 2) with 4 Screws (No. 25), 1 Screw (No. 11). Tighten and secure with Spanner (No. 93).

Lower the Bottle Cover (No. 22) to fit in the Left Bottle Cover (No. 23) and Right Bottle Cover (No. 24). We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877-90SUNNY (877-907-8669).



#### STEP 5:

Attach the Front Handlebar Post (No. 7) to the Handlebar Connect Post (No. 6) with 2 Square Neck Bolts (No. 14), 2 Big Curve Washers (No. 15), 2 Nuts (No. 16). Tighten and secure with Spanner (No. 93).



#### STEP 6:


Remove 3 Washers (No. 31), 3 Nuts (No. 32) from the Seat (No. 30) with Spanner (No. 93).

Attach the **Seat (No. 30)** to the **Seat Support Post (No. 5)** with 3 **Washers (No. 31)**, 3 **Nuts (No. 32)** that were removed. Tighten and secure with **Spanner (No. 93)**.

Loosen and pull out 1 Spring Pin Knob (No. 27) in the Front Main Frame Post (No. 1) by hand.

Attach the **Seat Support Post (No. 5)** into the the **Bushing (No. 39)** which is in the **Front Main Frame Post (No. 1)** with 1 **Spring Pin Knob (No. 27)** that was loosen Tighten and secure by hand.


We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at <a href="mailto:support@sunnyhealthfitness.com">support@sunnyhealthfitness.com</a> or 1-877-90SUNNY (877-907-8669).



#### **STEP 7:**

Keep Left Pedal (No. 28) and Left Crank (No. 87) at 90° and then gently insert Left Pedal (No. 28) into the Left Crank (No. 87), then turn the Left Pedal (No. 28) counter-clockwise as tightly as you can with your hands, then use Spanner (No. 93) to tighten securely.

Keep Right Pedal (No. 29) and Right Crank (No. 88) at 90° and gently insert Right Pedal (No. 29) into the Right Pedal (No. 29). Then turn the Right Pedal (No. 29) clockwise as tightly as you can with your hands, then use Spanner (No. 93) to tighten securely.



#### STEP 8:

Remove 4 Pan Screws (No. 13) from the back of the Computer (No. 12) with the Spanner (No. 93).

Attach Computer (No. 12) to the top end of the Front Handlebar Post (No. 7) with 4 Pan Screws (No. 13) that were removed. Tighten and secure with Spanner (No. 93).


Connect the Computer Wire II (No. 20) with Computer Wire A (No. 12a).

NOTE: Computer Wire A (No. 12a) have to go through the hole in the middle Front Handlebar Post (No. 7) Connect the wire in the back of the Front Handlebar Post (No. 7)

Insert the Hand Pulse Sensor with Wire (No. 10) into the Pulse Input jack on the back of Computer (No. 12).

The assembly is complete!

### **BATTERY INSTALLATION & REPLACEMENT**



#### **BATTERY INSTALLATION**

- 1. Take out 2 AAA batteries from computer box.
- 2. Press the buckle of battery cover on the **Computer (No. 12)**, then remove battery cover.
- 3. Install 2 AAA batteries into the battery case on the back of the **Computer (No. 12)**. Pay attention to the battery + and poles before installing.
- 4. Press the buckle of battery cover, then put the battery cover back to the back of the **Computer** (No. 12).

The installation is complete!

#### **BATTERY REPLACEMENT**

- 1. Press the buckle of battery cover on the back of the **Computer (No. 12)**, then remove battery cover.
- 2. Remove the 2 old AAA batteries in the battery case and install 2 new AAA batteries into the battery case on the back of the **Computer (No. 12)**. Pay attention to the battery + and poles before installing.
- 3. Press the buckle of battery cover, then put the battery cover back to the back of the **Computer** (No. 12).

The replacement is complete!

#### **BATTERY DISPOSAL**


Dispose the batteries according to the laws and regulations of your local region. Some batteries may be recycled. When disposing or recycling, do not mix battery types.

## **STORAGE GUIDE**


Pull the **Ring Spring Pin (No.53)** out and fold the **Rear Support Frame (No.2)** to the **Front Main Frame Post (No.1)** as the direction of the arrow shown in Figure.

Turn the Ring Spring Pin (No.53) into the hole A in the steel plate of the Front Main Frame Post (No.1).

WARNING: WATCH OUR HANDS WHEN YOU FOLD THE BIKE.



### **ADJUSTMENTS GUIDE**





#### MOVING THE RECUMBENT BIKE

Hold the Front Handlebar Post (No. 7) and tilt the bike until the 2 Transportation Wheels (No. 36) touch the ground. Now you can transport the bike to the desired location with ease.



#### ADJUSTING THE BALANCE


In order to achieve a smooth and comfortable ride. you must ensure that the bike is stable and secured. If you notice that the bike is unstable during use, you should adjust the Rear Stabilizer End Caps (No. 37) until the bike becomes levelled with the floor surface.



#### **ADJUSTING THE TENSION**

Adjust the tension by rotating the **Tension Control** Knob (No. 45) clockwise to increase the level of resistance. Rotate the Tension Control Knob (No. **45)** counter-clockwise to decrease the level of resistance.

Tension levels are set at Level 1 being the lowest and Level 14 being the highest.



#### **ADJUSTING THE SEAT**

Loosen and pull out the Spring Pin Knob (No. 27) to adjust the height of the **Seat (No. 30)**. When adjusting, you will see a limit on the Seat Support Post (No. 5). DO NOT lift the posts passed this mark. Always check the Spring Pin Knob (No. 27) and to ensure that they are fully secured when you finish making an adjustment.


#### **CLEANING**

The bike can be cleaned with a soft, clean, damp cloth. Do not use abrasives or solvents on plastic parts. Please wipe your perspiration off the recumbent bike after each use. Be careful not to get excessive moisture on the computer display panel as this might cause electrical hazard or electronics to fail. Please keep the bike, especially the computer, out of direct sunlight to prevent screen damage. Please inspect all assembly bolts and pedals on the recumbent bike for proper tightness every week.

#### **STORAGE**

Store the recumbent bike in a clean and dry environment, away from children.

### **EXERCISE COMPUTER**



#### **KEY FUNTION:**

- This key lets you to select and lock on to a particular function you want.
- SCAN→TIME→SPD →DIST →CAL→ ODO →RPM →PULSE
- Pressing and hold with 3 seconds to reset the value to zero (without ODO).

#### **SLEEP MODE**

- The system turns off automatically when the sensor has no signal input or no key are pressed for approximately 4 minutes.
- The system turns on when the MODE key is depressed or a signal input from the sensor.

#### **FUNCTION**

- SCAN: Display changes according to the next diagram every 6 seconds.
- TIME: The total working time with starting exercise.
- SPEED: The current speed with starting exercise.
- DISTANCE: The current distance with starting exercise.
- CALORIE: The current calories burned with starting exercise.
- TOTAL DIST: Counts the total distance with from start to finish. If the battery is replaced, the value returns to zero.
- RPM: The average number of turns per minute of the wheel to measure the speed of the pedal.
- PULSE: The current pulse rate.

#### **SPECIFICATIONS**

	SCAN	6 S
	TIME	0:00-999:59 M: S
	SPEED	0.0~99.99 M/H
FUNCTION	DIST	0.0~9999.9 M
	ODO	0.00~9999.9 M
	CAL	0.0~9999.9 Kcal
	RPM	0~299
	PULSE RATE	40~240 BPM
BATTERY		SIZE-AAA*2
Operating temperature		<b>0~40℃(32℉-104℉)</b>
Storage temperature		-10~60°C((14°F-140°F)

#### **APP CONNECTION:**

Connect Smart Equipment to SunnyFit App:

1. Scan to download SunnyFit from the app store:



- 2. Ensure that the Bluetooth function is turned on from your mobile device.
- 3. If this is your first time using the SunnyFit app, follow the in-app instructions to register for your free SunnyFit account and log in.
- 4. Begin any workout activity that matches your smart equipment, then follow the onscreen prompts to search for and connect to your smart equipment.
- 5. When connected, your stats and records will be displayed at the end of your course/session, and recorded in your account profile!


#### Troubleshooting:

 If you are having trouble connecting your smart equipment, visit <u>www.sunnyfit.com/guide</u> or scan the QR code below:




• If you require additional support, please contact <a href="mailto:support@sunnyfit.com">support@sunnyfit.com</a>.

## **EXPLODED DIAGRAM 1**



## **EXPLODED DIAGRAM 2**



## **TROUBLESHOOTING**

PROBLEM	SOLUTION	
There is no display on the computer.	<ol> <li>Remove the computer and verify that the wire from the computer is properly connected to the wire that comes from the front post.</li> <li>Check if the batteries are correctly positioned and battery springs are in proper contact with batteries.</li> <li>The batteries in the computer may be unresponsive. Change to new batteries.</li> </ol>	
The bike wobbles when in use.	Turn the adjustable end caps on the front and rear stabilizers as needed to level the bike.	
The bike makes squeaking noise when in use.	Some bolts on the bike might have become loose. Please inspect all the bolts and tighten any loose bolts.	

## **PARTS LIST**

No.	Description	Spec.	Qty
1	Front Main Frame Post		1
2	Rear Support Frame		1
3	Front Stabilizer		1
4	Rear Stabilizer		1
5	Seat Support Post		1
6	Handlebar Connect Post		1
7	Front Handlebar Post		1
8	Front Handlebar Foam Grip		2
9	Round Cap		2
10	Hand Pulse Sensor with Wire	L=550mm	2
11	Screw	ST4.2*20	3
12	Computer	HT060-BLE	1
12a	Computer wire A		1
13	Pan Screw	M5*10	5
14	Square Neck Bolt	M8*40	2
15	Big Curve Washer	φ8*φ20*2.0	6
16	Nut	M8	6
17	Bolt	M6*12	6
18	Curve Washer	φ6	4
19	Washer	Ф6*Ф12*1.0	8
20	Computer Wire II	L=200MM	1
21	Wire Plug II		1
22	Bottle Cover		1
23	Left Bottle Cover		1
24	Right Bottle Cover		1
25	Screw	ST4.2*15	8
26	Computer Wire I	L=950MM	1
27	Spring Pin Knob		1
28	Left Pedal	YH-30X	1
29	Right Pedal	YH-30X	1
30	Seat		1
31	Washer	Ф8*Ф16*1.5	11
32	Nut	M8 S13	5
33	Bolt	M8*60	4

No.	Description	Spec.	Qty
34	Сар		2
35	Bolt	M8*40	2
36	Transportation Wheel	Ф8*Ф16*1.5	2
37	Rear Stabilizer End Cap		2
38	Seat Post		1
39	Bushing		1
40	Plastic Shaft Sleeve	φ30*φ22*L12	6
41	PC Pad		1
42	Wire Plug I		3
43	Screw I	M8*20	6
44	Spring Washer	Ф8	6
45	Tension Control Knob	1150mm	1
46	Big Flat Washer	Ф5*Ф15*1.0	1
47	Bolt	M5*25	1
48	Seat Support Block		1
49	Screw	<b>M5*</b> 8	1
50	Bolt	M8*20	2
51	Big Flat Washer	Ф8*Ф25*2.0	2
52	Mandrel		1
53	Ring Spring Pin	Ф8*108	1
54	Shaft Circlip	Ф17	6
55	Bolt	M6*12	6
56	Plastic Bearing Seat		2
57	Bearing	6003ZZ	2
58	Flywheel	Ф165	1
59	Magnetic Plate Post		1
60	Washer	Ф5*Ф12*1.0	1
61	Magnet	20*20*8	8
62	Square Magnet	20*10*5	3
63	Magnet Plate		3
64	Spring		1
65	Nut	M6	3
66	Bolt	M6*20	1
67	Belt Pully Crank		1

## **PARTS LIST**

No.	Description	Spec.	Qty
68	Belt	240 PJ4	1
69	Belt	230 PJ3	1
70	Screw	M5*10	1
71	Big Flat Washer	Ф20*Ф8*2.0	1
72	Bearing	φ35*φ15*15	1
73	Pulley Shaft	Ф17*33	1
74	Nut	M10	1
75	Sensor Wire	L=250MM	1
76	Screw	M4*10	1
77	Driven Plate		1
78	Bearing	608	2
79	Driven Shaft		1
80	Pulling Bolt	M6*36	2

No.	Description	Spec.	Qty
81	Nut	M10*1.0	2
82	Shaft Circlip		1
83	Nut	M10*1*3	1
84	Screw	ST4.2*25	6
85	Left Cover		1
86	Right Cover		1
87	Left crank		1
88	Right crank		1
89	Nut	M10*1.25	2
90	Crank Cover Cap		2
91	Allen Wrench	S5	1
92	Washer	Ф6*Ф12*1.0	6
93	Spanner	S10,13,14,15	1



## DOWNLOAD

Track your fitness progress & join **FREE** workout courses!

Download **SUNNYFIT** today!





## FOLLOW

#### Find us on social media @sunnyhealthfitness

- (i) @sunnyhealthfitness
- f @sunnyhealthandfitness
- @sunnyhealthfit
- /sunnyhealthfitness
- /sunnyhealthfitness
- p /sunnyhealthandfitness

www.sunnyhealthfitness.com