



1/10 SCALE 4WD READY-TO-RUN BRUSHED ELECTRIC MOTOR POWERED DRIFT STREET CAR





SET-UP INSTRUCTIONS AND PARTS LISTING

-







FTX Banzai RTR Brushed 2.4GHz 4WD Drift Car

Congratulations on your purchase of the FTX 'Banzai' electric Drift car.

This 1/10th scale model has been factory assembled and all electrics installed and set up to make it the easiest possible introduction to the sport of driving RC cars.





WARNING: Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property and cause serious injury.

This is NOT a toy and must be operated with caution and common sense. Failure to operate this product in a safe and responsible manner could result in damage, injury or damage to other property.

This product is not intended for use by children without direct adult supervision.

It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, set-up or use, in order to operate correctly and avoid damage or serious injury.

Safety Precautions and Warnings

- You are responsible for operating this model such that it does not endanger yourself and others, or result in damage to the product or the property of others
- This model is controlled by a radio which is possibly subject to interference which can cause momentary loss of control so it is advisable to always keep a safe distance to avoid collisions or injury.
- Age Recommendation: 14 years or over. This is not a toy. This product is not intended for use by children without direct adult supervision.

Carefully follow these directions and warnings, plus those of any additional equipment associated with the use of this model, chargers, ESC and motors, radio etc.

- Never operate your model with low transmitter batteries.
- Always operate your model in an open area away from cars, traffic or people.
- Never operate the model in the street or in populated areas.
- Always keep the vehicle in direct line of sight, you cannot control what you cannot see!
- Keep all chemicals, small parts and anything electrical out of the reach of children.
- Avoid water exposure, moisture causes damage to electronics and may result in the loss of control or permanent damage.
- Avoid injury from high speed rotating parts, gears and axles etc.

 Noviges should seek advise from more experienced people to experienced people to experience and people to experience and
- Novices should seek advice from more experienced people to operate the model correctly and meet its performance potential.
- Exercise caution when using tools and sharp instruments.
- Do not put fingers or any objects inside rotating and moving parts.
- Take care when carrying out repairs or maintenance as some parts may be sharp.
- Do NOT touch equipment such as the motor, electronic speed control and battery, immediately after using your model because they can generate high temperatures.
- Always turn on your transmitter before you turn on the receiver in the car. Always turn off the receiver before turning your transmitter off.
- Keep the wheels of the model off the ground, and keep your hands away from the wheels when checking the operation of the radio equipment.
- Prolong motor life by preventing overheat conditions. Undue motor wear can result from frequent turns, rapid change of direction forwards/backwards, continuous stop/starts, pushing/pulling objects, driving in deep sand and tall grass, or driving continuously up hill.

Contents:

Banzai 1/10th RTR Electric Drift car. Transmitter: 2.4GHz Steerwheel.

Charger: Input Mains 240V AC. Output 300mA DC

Battery: 7.2V 1800mAh NiMH

Aerial Tube








Required equipment for operation

1. Tools required for building and maintenance:



WARNING!

Do not use a power screw driver to install screws into nylon or plastic materials. The fast locking may heat up the screws being installed that may break the molded parts or strip the threads during installation.

2.Additional items needed for operation:



4pcs AA alkaline batteries for transmitter

IMPORTANT!


Check that all screws and nuts are tight before each use.






Aerial Assembly.

Uncoil the aerial wire carefully so as not to kink or knot it in anyway, and first be sure to insert the wire up through the top chassis aerial mount hole from below. Pull the rubber tube cap off the aerial tube and push the wire all the way through the aerial tube until the first 5mm of wire shows out of the other end. Fold the wire down over the end of the tube and be sure to insert the rubber tube cap so that it traps the protruding wire to hold it firmly in the tube. Push Aerial tube into mounting hole in upper chassis until firmly seated. Bundle any excess aerial wire neatly away from rotating components on the chassis.








Charging/Installing the Battery.

Always store your model with the battery pack unplugged and removed. Always charge your battery away from the vehicle. The included 300mAh mains charger will take approx 6 hours to charge a fully discharged battery, but always remove it from the charger if it becomes warm to the touch. Always disconnect the charger from the mains supply and the battery pack when not in use. Keep children away from charger and battery during the charging process.

To install a charged battery, remove the body clips and remove the bodyshell. Remove the battery retainer clips, insert battery and reinstall retainer with the flat side facing the battery and re-insert clips. When connecting battery and turning car on, ensure it is off the ground, with wheels away from objects.







Notes on Battery use:

Always allow the battery cool after use, before recharging.

Always inspect the battery before charging.

Any bare wires, split heat shrink or leakage is a sure sign of abuse.

Never attempt to charge dead or damaged batteries.

Do not disassemble the battery or cut the connector wires.

If the battery connector gets hot enough to melt there is most likely a serious problem with your model, driveline, battery wires or speed controller. Find and correct the problem before installing another charged battery pack.

NEVER charge the battery unattended incase of overcharging, you need to be able to monitor the battery during charging

Charge away from flammable objects and on a non-flammable surface incase the battery becomes too hot.







Speed Control Set Up


FEATURES:

This ESC is set up in a simple way for easy operation. When switched on, it automatically searches the neutral point. When the automatic setup is finished, the motor sends out "DO" "RE" "MI" music indicating it snatches the neutral point. It's easy to operate.

SPECIFICATIONS:

- ▲ INPUT: 7.2v 6-cell NiMH DC (not LiPO compatible)
- ▲ BEC:5V 1A
- ▲ Current Drain: 20A, Max Forward 300A (instantanteous), Max Reverse 150A (instantanteous)
- ▲ Size: 35mm(L) X 33mm(W) X 30mm(H) Weight: 48.2g
- ▲ Applicable: 540/15T motor and above.

Wire diagram:



SETUP:

Connect all wires according to the diagram, then switch on the radio. (Put to default setting for Programmable Radio). Switch on the power of the ESC, and you'll hear "DO, RE, MI" music. The music indicates that the transmission is on, and the neutral point is set up. If the motor does not stop running a short while after the neutral point is set, please switch off the ESC and then switch it on again to get the neutral point.

FUNCTIONS:

- Forward: Press the trigger and the car will move forward. If the car is moving a little then adjust the trim (No.8 on Transmitter picture).
- Brake: To brake allow the trigger to return to neutral point
- Reverse: Push the trigger forward and the car will go into reverse. The car mustbe stationary before reverse engages. This protects the esc from exessive forward/backwards action.
- LED indicator is always on during forward, reverse and brake mode. When the ESC is not working and the car stops, LED indicator is off. When the radio is switched off, LED indicator on the ESC flashes.


Warning:

- Although this esc is waterproof the rest of the vehicle is not. Do not run the model in excesssively wet conditions or submerge as long term damage and wear can occur.
- It is dangerous to touch the motor after running as it emits heat during running and the cooling plate remains hot after running.
- ▲ This ESC is not LiPO battery compatible. Use with Lipo will damage the ESC permanently





2.4GHz Transmitter Set-Up





Install the batteries


- (1) Remove the battery compartment cover.
- (2) Replace the used batteries with new AA size batteries.

Please replace batteries when the power indicator blinks or the buzzer beeps.

Function













2.4GHz Transmitter Adjustment

A. Throttle Trigger






 \wedge

Keep the transmitter and receiver 40cm apart when operating.

Use the REV switches to reverse the steering or throttle operating direction.

- 1. Push the trigger forward to slow down or brake.
- 2. Pull the trigger backward to accelerate.
 - **B.** Steering Wheel




Throttle Trim: Trim the throttle servo slightly when the trigger is at the neutral position.


Steering Trim: If the front wheels do not align straight, use the steering trim to adjust.

Low battery alarm

Do not operate the radio system when the battery power is low. the battery power is low.

Electrical powered model






Fail Safe Function Setting

- 1. Set the TH, ST switches to the normal position.
- 2. Turn on the transmitter and receiver.
- 3. Press the F/S SET button, the LED on the receiver should start flashing rapidly.
- 4. Put the throttle trigger at the brake position, press the F/S SET button, the LED should become solid.
- 5. For electric model, put the throttle trigger at the stop position when you are making the setting.

Binding the transmitter and receiver







Getting Started

Switch on transmitter.

Hold vehicle clear of the ground, connect battery pack and switch on receiver.

Bind the Transmitter and receiver if required.

Test the transmitter to check control of the vehicle with wheels off the ground.

Start driving slowly and if the vehicle does not go straight, adjust steering trim dial on Transmitter.

For the very first run use the throttle gently, to gradually bed in the motor brushes and help the driver become accustomed to the vehicles behaviour and controls.

PLEASE NOTE:

Although the electronics are waterproof the rest of car can be subjected to damage if running in excessively wet or submerged conditions.

After Run.

Switch off the receiver power, switch off the transmitter and lower the aerial. Disconnect the battery and remove it from the vehicle, allow it to cool before recharging. If you have a second charged battery all ready to use, still allow the vehicle to cool slightly before continuing.

Regular maintenance.

Frequently check the whole vehicle for loose or missing fixings. Use thread lock on any replacement screws into metal threads.

Frequently check rotating parts are free from grass, string etc. that might bind their motion and over stress the motor or speed controller. Remove the wheels occasionally and check behind the mounting hex for obstructions or anything that might have been wrapped around the axle and caused extra drag.

Check the gear mesh frequently and remove any stones or grit from gear teeth to prevent premature wear and damage.

If the motor moves, or is removed for maintenance/exchange, the gear mesh will need to be set. Simply slacken the motor retaining screws and adjust the motor until there is just discernable backlash between pinion and spur teeth. If the gear is too tight or too loose the gears will be noisy and could be damaged.



Shock absorbers will wear prematurely if used in dirty dusty conditions. Replace oil and seals as required to keep a smooth dampening action.

Trouble shooting guide.

Short Runtime:

Battery damaged/not charged Motor dirty or brushes worn

Motor dirty or brushes worn Drivetrain binding

Sluggish Action:

Motor dirty or brushes worn Bind in drive train Battery running low on nower

Motor/ESC overheat:

Over-geared Binding transmission. Seized axle bearing. Motor binding

Motor spins but vehicle refuses to move:

Gears damaged.
Gears loose on shaft.
Slipper clutch too loose.
Drive shaft broken or
missing.

Poor Range or fails to operate:

Transmitter batteries low Vehicle Battery Low. Transmitter switched off Transmitter/receiver aerial not extended. ESC switched off or battery not connected. Loose connectors/wires. Water damage. Model electronics are not waterproof.

Warranty

Due to the nature of this product and potential use FTX warrants it to be free of material and workmanship defects when new. FTX will at its sole discretion repair or replace defective components free of charge within 30 days from date of purchase. This warranty does not cover wear and tear, crash or impact damage, modifications, component water damage failure to perform maintenance or damage from improper use. Proof of purchase date will be required to action any warranty claims.


Instructions for disposal.


This product must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of their waste equipment by handing it over to a designated collections point for the recycling of waste electrical and electronic equipment.


For more information about where you can drop off your waste equipment for recycling, please contact your local council, your household waste disposal service or where you purchased the product.
















FTX6506

FTX6576

(Dia. 4-5)

FTX6586

FTX6559W


(Dia. 4-4)

(Dia. 4-3)






Common Part List














Part List








Part List

Part List			
FTX6523 -Round Head Self Tapping Hex Screw 3*10 8pcs	FTX6522 -Round Head Self Tapping Hex Screw M3*6 6pcs	FTX6525 -Button Head Hex Screw M3*8 6pcs	FTX6526 -Button Head Hex Screw M3*10 6pcs
	77777	TTTTTT	TTTTTT
FTX6527 -Button Head Hex Screw M3*12 6pcs	FTX6528 -Button Head Hex Screw M3*14 6pcs	FTX6535 -Flat Head Hex M3*8 6pcs	FTX6536 -Flat Head Hex Screw M3*10 8pcs
		TTTTT	
FTX6537-Flat Head Hex Screw M3*12 6pcs	FTX6538 -Flat Head Hex Screw M3*14 6pcs	FTX6539-Flat Head Hex Screw M3*18 3pcs	FTX6540-Flat Head Hex Screw M3*20 6pcs
FTX6541 -Flat Head Hex Screw M3*36 6pcs	FAST118 -Cap Head Hex Screw M3 X 18 6PCS	FAST115-Cap Head Hex Screw	FTX6530 -Ring Self Tapping Screw
		M3*10 6pcs	3*4 4pcs
FTX6543 -Set Screw M4*10 6pcs	FAST123 -Set Screw M4*4 6pcs	FAST122-Set Screw M3*3 6pcs	FASTM3-Nylon Lock Nut M3 6pcs
			000
FTX6543-Nylon Lock Nut M4 6pcs	FTX6587-Bumper sponge 1pcs	FTX6588 -Sponge cover 1pcs	FTX6589-Bumper Rail 1pcs














Upgrade Parts List







Notes:











FTX is an exclusive brand of CML Distribution, Saxon House, Saxon Business Park, Hanbury Road, Bromsgrove, Worcestershire, B60 4AD England.

E-mail: info@ftx-rc.com

-◆