

User manual

WiFi Automatic Cat Feeder

Failure to heed these instructions may lead to the product being damaged or personal injury. Please follow the instructions for proper use!

Contents

SAFETY PRECAUTIONS	02
PRODUCT DIAGRAM	04
CONTROLLING VIA APP.....	07
SET UP THE FEEDER	14
CLEANING & CARE	19
WHAT'S IN THE BOX	19
SPECIFICATIONS	20
TROUBLESHOOTING	20

SAFETY PRECAUTIONS

WARNING




- Dispose of all packaging materials properly. Some items may be packed in poly bags; these bags could cause suffocation; keep away from children and pets.
- Do NOT allow small children to play with, in or around the pet feeder.
- To reduce the risk of injury, please keep close supervision when an appliance is used near children.
- Do NOT use the feeder with pets not able to reach the food tray or with any physical disability.
- Do NOT immerse the base part in water at any time as it may damage electronic components like the control panel.
- Do NOT place any foreign object in the pet feeder.
- Do NOT use outdoors. Check operation frequently to be sure the unit is dispensing properly.
- Do NOT use wet, canned or moist food.
- Do NOT use the feeder for anything other than its intended use.
- Only use attachments recommended or sold by the manufacturer. The use of attachments not recommended or sold by the manufacturer may cause an unsafe condition.
- Do not modify the pet feeder.
- Do not operate any appliance if the unit is malfunctioning or has been damaged. Do not attempt repairs on the pet feeder yourself. Contact our customer service immediately for further instructions.
- Always unplug when not in use and before cleaning.
- Never pull on the electrical power cord to remove the plug from the wall outlet.
- If the plug of this device gets wet, turn on electricity to that wall outlet. Do not attempt to unplug.

- Examine the feeder after installation. Do not plug in if there is water on the power cord or plug.
- To avoid tripping, always position power cord out of the way of foot traffic.


CAUTION

- Do NOT allow pets to chew on or swallow any parts.
- If an extension cord is necessary, one unit with a proper rating should be used.
- Do NOT install or store the pet feeder where it will be exposed to weather or temperatures below -10°C .
- Use alkaline D batteries to power Do NOT use rechargeable batteries.
- Check the batteries regularly. Before leaving for extended time, always replace batteries with new ones.
- Do NOT lift the pet feeder by Lid, food tank, or food tray. Lift and carry it using both hands and the base, while keeping the unit in an upright position.
- Suitable for dry food ONLY, with kibble size ranging from 3-13mm / 0.11-0.51inch in diameter. Larger kibble may get stuck at the food outlet.
- Read and observe all important notices listed on the pet feeder and in the packaging.

PRODUCT DIAGRAM



- 01 Open Button
- 02 Lid
- 03 Food Tank
- 04 Control Panel
- 05 Food Outlet
- 06 Base
- 07 Food Tray
- 08 Higher Floor Mat
- 09 Speaker
- 10 Battery Compartment
- 11 Type-C Power Socket
- 12 Boat Switch




10 x Higher Foot Pads




10 x Heightening Foot Pads




1 x Two Way Splitter




1 x Partition




1 x Heightening Food Tray Holder




1 x Double Foot Tray



1 x Anti-skid Pads



1 x Removal tool



LED Indicators

Blue	Rash every 0.5s	The Feeder is in Bluetooth or Manual mode, ready to connect with App.
	Slowly blink	The Feeder is in AP Mode, ready to connect with App.
	Stay solid	Connected to WIFI and fully operational
Red	Off	Normal
	Blink	Food dispensing system error *Press and hold the Reset Button for 6s to reset
	Stay for about 6s	Resetting WIFI connection



Record Button

- Press and hold the Record button, start recording after a beep is heard.
- Record your voice for less than 10s. Release the button, 2 beeps will be heard indicating it's saved.



RESET

Reset Button

- When the device is connected to the App, Press and hold the Reset Button for 6s to reset the device.
- When the device is not connected to the App, Press and hold the Reset Button for 6s to switch between Manual Mode and AP Mode.



FEED

Feed Button

- Press to manually feed a portion.
- Press and hold for 6s, the indicator will flash twice meaning the control panel is locked. Repeat to unlock.
- In the locked state, you can long press the RESET button to restore the factory settings.

CONTROLLING VIA APP

1. System Requirements

- iPhone on iOS 9.0 or later, smartphone on Android 4.4 or later
- Wireless router 2.4GHz (802.11 b/g/n)
- High-speed internet connection

2. Before the Configuration

- Please use indoor only to avoid direct exposure to the sunlight.
- Please connect the Feeder via 2.4GHz only. If your WIFI is 5GHz only, set it to be compatible with 2.4GHz mode.
- The WIFI password is composed of no more than 12 digits and letters. No special symbols are supported.
- Please keep the feeder close to the router The distance in a range of 6 meters without wall barriers is recommended.

- If the configuration fails, please power off and restart the feeder (press and hold the Reset button for 6s), then wait for about 2mins to re-configuration.

3. How the System Works

The iPettie WIFI Automatic Feeder connects to your home's wireless router and allows you to program and monitor your pet's meals from anywhere, right from your smartphone with the Smart Life app. Use the app to schedule your pet's meal times and portion sizes, view the last 7 days of feeder activity, and even dispense a meal remotely. Smartphone alerts let you know when your pet has been fed for added peace of mind. Delivering a convenient lifestyle to you and helping your pets become their best, the iPettie WIFI Automatic Feeder keeps you connected to your pet's feeding routine wherever you are!

4. Download the App & Log In

- Scan the QR code or search for "Smart Life" on App Store or Google Play to download the app.
- Sign up or Log in to your account.



Google Play




App Store




5. Three Ways to Connect Your Feeder with APP

A. Configuring via Bluetooth Mode


Open App, select Home page, Click +/" Add device".



To add the auto-pop-up device by entering WIFI account and password.



Feeder Connected, start to set the mealtimes and portion sizes.



B. Configuring via Manual Mode

Add the device via "Pet Feeder" in Small Home Appliances.

C. Configuring via AP Mode


- **Note:** Please make sure the Bluetooth is turned off on your mobile before starting the AP mode connection.
- When the blue LED indicator flashes, press and hold the RET button for 65 until 3 beeps are heard. The LED indicator will turn to blink slowly. Now the feeder is under AP mode,
- Open the app on your mobile, tap Add Device -> Smart Feeder, tap the icon at the top right corner and select Configure WIFI via AP mode. Enter your WIFI name and password and go to the WIFI connection interface on your mobile, find the device "smartlife-xxxx" and tap to connect. Return to the app and wait for connecting.

Notes

- Device name: WIFI Feeder.
- Connect the Feeder via 2.4GHz only, if your WIFI is 5GHz, please set it to 2.4GHz before the connection.
- If it still fails connecting, please contact our Support Team.

6. Reset Feeder on App


- Enter Setting on Control Center, Select Factory Reset.
- 3 beeps will be heard, wait for about 1 minute until the blue light starts to flash slowly and your device is ready for re-connection.



7. Share Your Feeder

Enter Setting, select Share Device, add Sharing Via Smart Lift Account Name.


8. Control Center on APP



SET UP THE FEEDER

1. Assembling Food Tank and Tray


- Place the feeder in a desired location. Check the food tank is in place.
- Align the bulging of the food tank and holes in the base, and flip the toggle switches on both sides to "🔒".




- Take out the anti-skid pad and stick it to the reserved opening above the heightening feet in turn.




- Please place the feeder on the side, and there are four anti-skid pads at the bottom. You can remove the anti-skid pads with a disassembly tool, and then insert the heightening feet into the corresponding four interfaces.




- There is also a corresponding access port on the back of the heightened food tray support, insert it into the heightened foot pad.




- Take out the double food tray, there are two corresponding plugs in the middle, which match with the middle socket of the raised food tray bracket, install them together, and press firmly.



- There are four corresponding reserved openings for the heightened foot pads on the back of the double food tray, and the heightening foot pads can be inserted in sequence.




- Put the double food tray on a stable place, and slowly straighten the feeder so that the corresponding two sockets below it fit together with the middle socket of the solid tray. Finally, put the partition plate in the middle of the double food tray, and the installation is completed.



2. Connecting Power

- Insert the 5V power adapter into a wall socket. Plug in the power socket of the feeder.
- The boat switch at the bottom of the equipment can cut off or open the power supply.
- Open the battery compartment at the bottom of the unit, and install 3 alkaline D batteries (not included) in case of outage.
- The LCD display will light up automatically indicating the feeder is on now.



3. Placing Desiccant Bag

Place the desiccant bag into the inner box under the lid.

Notes


- It is recommended to change the desiccant bag every 15 days to prevent mold growth.
- Remove the desiccant bag before cleaning the lid.

4. Filling Food Tank

Fill food tank with dry pet food and close the lid.

Note: (1). Do NOT use canned, wet or moist pet food.

(2). Recommend kibble size ranging from 3-13mm / 0.11-0.51in in diameter.



5. Recording a Meal Call

- Press and hold the Record button, start recording after a beep is heard.
- Record your voice for less than 10s. Release the button, 2 beeps will be heard indicating it's saved.

Note: When feeding time is up, the recording will be played when food is dispensing.



6. Manually Feeding Your Pet

- Press the Feed button and one portion will be fed each time.

Note: The normal schedule and portion will not be affected.



CLEANING & CARE

- It's recommended to clean the feeder regularly for the health of your pet.
- The washable parts of the iPettie automatic feeder are as follows: food tank, food tray, and lid [without desiccant bag]; they can be submerged in water. Clean by hand-washing using cool or warm soapy water.

WHAT'S IN THE BOX

1 x WIFI Automatic Pet Feeder
1 x 5V Power Adapter
1 x Desiccant Bag
1 x User Guide Kit
10 x Higher Foot Pads
10 x Heightening Foot Pads
1 x Two Way Splitter

1 x Partition
1 x heightening food tray holder
1 x Double Foot Tray
1 x Anti-skid Pads
1 x Removal tool
2 x Stainless Steel Bowls

SPECIFICATIONS

Food Tank Capacity	5 Liters
Power	DC 5V power adapter/ 3 x alkaline D batteries
Power Adapter	AC100-240V Input, DC 5V output
System Supported	Android & iOS
Weight	1.95kg/4.4Lbs
Dimensions	285x175x291mm/711.2"x6.9"x11.4"

TROUBLESHOOTING

Problem	Solution
The food won't come out.	<ul style="list-style-type: none">• Please be sure to fill in with dry food, kibble size should range from 3-13 mm / 0.11-0.51 inch in diameter.• Check whether any foreign objects are placed -disassemble the food tank and check the chute. Also check the food outlet.• Check whether it's low battery level-whether the power adapter is connected or there is any outage when no battery is installed.

Problem	Solution
I can't disassemble the food tank.	Please follow steps in Clean & Care.
I can't hear any voice recordings when feeding.	Make sure you've recorded successfully-unlock the control panel, press the Feed button to check. If no sound is heard, you may need to record again and be sure to save following instructions in the Recording a Meal Call section.
Food volume for each portion is not the same.	The first few portions may vary, and it doesn't mean a faulty equipment. After about 6 feedings it should be almost even.
I can't configure the feeder on my mobile.	<p>Incorrect account and password format- Use only number and letter for username and password, 12 digits at most.</p> <p>5G not supported - Please use 2.4G wireless network.</p> <p>Application problem-Some program conflicts.</p>
Feeder appears disconnected from WIFI.	Weak disconnection - Please check that the distance between your feeder and router is no more than 10m/33ft, and no concrete walls or too many obstacles between them. Otherwise the WIFI network can be weak and cause unstable connection.

iPettie

MADE IN CHINA



This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.