


not disturb	Factory Reset
l day	Tap on this to reset watch data.
thedule ( )	Note: All data will be erased if watch is reset
	150000000000000000000000000000000000000
	Restart
attery saver mode	Tap on this to restart your watch.
off feature	
Standard 5	
n Off. 5	50% ( 680)
0	About
Control of the Contro	Shows the device details.
an QR code	
DXXIII	
<b>10.7</b>	
T 64802	



enable this feature. Select the match for which you want live scores on the watch. Note: There might be a delay in iOS app to get the scores due to device security

Tap on this icon to select any activity. You can select from a

list of activities like walking, treadmill, running, badminton,

football, basketball, tennis, yoga, dancing, indoor cycling,

hiking , hockey, kabaddi, bowling.

Check you daily workout records here.

any activity of your choice.

**Activity records** 

the crucial in-game stats.

boxing, calisthenics, karate, table tennis, pilates, skipping,

You can also select from 700+ Active modes from the app.

Go to 700+ Active modes from the home screen and select

Tap on any sport mode to start the activity. Press any side

Sync your smartwatch to the app to get the detailed analysis.

SensAl feature help to improve your cricket game and analyze

You can select batting or bowing once you enter this menu.

button or swipe right to pause or stop the activity. If the

activity is less than 3 mins, it will not be recorded.



MAINTENANCE:
Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.
Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.
For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.
FAQ
Search for the app to connect keeps failing  1. Keep the boAt Crest app updated to the latest version  2. Close all the programs on the watch → Stop and restart Bluetooth and GPS → Connect again.  3. Check and analysis on the watch is foreigned to the programs on the watch in

boAt Wave Primia Talk

-20°C-60°C

2402-2480Mh2

Click on this icon if you are a batsman, select right-handed or left

Once started, you can record your hand speed, no. of shots,

Select right-handed or left-handed. Once you are in, select the

Sync your activity on the boAt crest app for detailed analysis.

Click on this to check your daily activity data like step count,

Once you are in, you can record your arm speed, no. of balls, total

If you are a right-handed batsman, wear the watch in left hand and

handed as per your requirement.

You can set time and shots goal also.

Swipe left to pause or stop the activity.

Swipe left to pause or stop the activity.

You can also set time and no. of balls goal also.

bowl type, spin, medium, fast.

calorie and distance covered.


Check your sensAl records from here.


PRODUCT PARAMETERS:

SensAl records

other wading or deep-water activities with high-speed water flow.
SAFETY & PRODUCT INFORMATION Battery  • Do not disassemble, bore or damage the battery.
Do not disassemble the built in batteries of non-replaceable battery  Do not use sharp objects to remove the battery.
Health Warning
<ul> <li>If you are wearing a pacemaker or other implanted electronic device before using the heart rate monitor of the watch.</li> </ul>
<ul> <li>The optical heart rate sensor will glow green. If you suffer from epile blinking light sources, please consult your physician before wearing ti</li> </ul>

Make sure smart reminders on the app are on and synced to the Wave Primia Talk. Also make sure your notification center of the phone is displaying messages. Make sure app is running in the background and battery optimization feature Make sure there is not more than 7m distance between Bluetooth on the phone and the watch. Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and Bluetooth calling need Bluetooth connectivity to work. he IP68 water resistance will only work under the following conditions: 1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes he watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and described in this manual without any prior notice. At the same time, we hold the right to at disassemble the built in batteries of non-replaceable battery devices. continuously update the product content. RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.







**Heart Rate Monitor** 

Note: Measurements are for reference only and not for

Wear the watch on your wrist, press the side button then click on

the icon to start measurements. You can also view the data on the

Swipe up to check the more detailed view of the SpO2 record.

Note: Measurements are for reference only and not for medical

Click this option to start the stress monitoring. Make sure you were

your watch on your wrist properly to get the accurate results.

My Wave Primia Talk is receiving no alerts, texts, or phone calls

Only then will your smartwatch also display those notifications.

. There is no obstacle in between the watch and the phone.

Will it be okay to take a bath wearing the Wave Primia Talk?

Which functions of the Wave Primia Talk need Bluetooth to work?

Analysis of the measurement is:

Normal: 30-59 Medium: 60-79

on the phone is disabled.

My Bluetooth keeps getting disconnected

Make sure the app is running in background

are wearing a pacemaker or other implanted electronic devices, please consult your doctor using the heart rate monitor of the watch.

ptical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to glight sources, please consult your physician before wearing this device.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS. Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of