

USER MANUAL

boAt



AAVANTE BAR THEME

USER MANUAL

Thank you for choosing the boAt Aavante Bar Theme as the audio source for your home. Discover a new level of immersive, cinematic audio experience at home with the boat Aavante Bar Theme. With a powerful 160W RMS total output, this sound bar brings every aspect of your entertainment be it a song, show or movie to life. The 2.1 channel sound system provides a balanced sound for your movies, music and even video games and you can experience cinematic sound that revolves around you. Stay plugged into the sound with an array of wired connections, USB and Bluetooth@ v5.3 wireless technology. Bring your home to life with the boAt Aavante Bar Theme. We request that this installation guide be carefully read for proper usage of the device and should be referred to whenever needed.

COMPONENTS LIST

- 1X Soundbar
- 1X Subwoofer
- 1X AUX Cable
- 1X User Manual
- 1X Remote Control
- 1X Warranty Card
- 1x Wall Mounting Accessories

SAFETY & WARNINGS

Caution

To reduce the risk of electric shock, do not dismantle the product and do not expose the apparatus to rain or moisture. The unit has no user-serviceable parts inside. Refer servicing to qualified personnel only



The lightning flash within an equilateral triangle is intended to alert you to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute an electric shock to a person or persons.



Important! This symbol alerts you to read and observe important warnings and instructions on the unit or in this manual.

Notice:

This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

1. To prevent possible hearing damage, do not listen at high volume levels for long periods of time or a sudden high volume level.
2. Never use the device unsupervised! Switch off the device whenever you are not using it, even if not using it only for a short while.
3. The appliance is not intended to be operated by means of an external timer or separate remote control system.
4. If the power supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. Before operating this system, check the voltage of this system to see if it is identical to the voltage of your local power supply.
6. The unit should not be impeded by covering the ventilation opening with items such as newspaper, table-cloths, curtains etc. Make sure that there are at least 20 cm of space above and at least 5 cm of space on each side of the unit.
7. The apparatus must not be exposed to dripping or splashing. Do not place objects filled with liquids such as vases, bottles or humidifiers on the unit.
8. To prevent fire or shock hazard, do not expose this equipment to direct heat, rain, moisture or dust.
9. Do not place this unit near any water sources e.g. taps, bathtubs, washing machines or swimming pools. Ensure that you place the unit on a dry, stable surface.
10. Do not place this unit close to a strong magnetic field.
11. Do not place the unit on a amplifier or receiver.


12. Do not place this unit in a damp area as the moisture will affect the life of electric components.
13. Do not attempt to clean the unit with chemical solvents as this might damage the finish. Wipe with a clean, dry or slightly damp cloth.
14. When removing the power plug from the wall outlet, always pull directly on the plug, never pull on the cord.
15. Depending on the electromagnetic waves used by a television broadcast, if a TV is turned on near this unit while it is also on, lines might appear on the LED TV. Neither this unit nor the TV is malfunctioning. If you see such lines, keep this unit well away from the TV set.
16. The mains plug is used to disconnect the device, the disconnected device should remain readily operable.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions. Keep these instructions. Follow all instructions. Heed all warnings.
2. Do not use this apparatus near water.
3. Clean only with a dry cloth.
4. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
5. Do not install near any heat sources such as radiators, heaters, stoves, or other devices (including amplifiers) that produce heat.
6. Do not ignore the safety measures of a polarized or grounding-type plug. A polarized plug has two blades with one wider than the other.
7. Protect the power cord from being walked on or pinched. Pay special attention to the positioning of cords, plugs, power sockets especially the point where they exit from the unit.
8. Only use attachments/accessories specified by the manufacturer.
9. Unplug this apparatus during lightning storms or when not in use.
10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, for example, when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
11. The AC plug is used to disconnect the device, the disconnected device should remain readily operable. In order to disconnect the apparatus from the AC power completely, the AC plug must be removed from the AC outlet completely.


SOUNDBAR CONTROL PANEL & PORTS

1. Power Button: Short press for standby ON/OFF.
2. Input Button: Short press for standby ON/OFF. Short press in steps to choose among Bluetooth, HDMI(ARC), Optical, USB and AUX modes.
3. (-) Button: Short press to return to previous track; long press to decrease volume
4. Play/Pause Button: In Bluetooth mode, short press to play/pause whereas long press to disconnect/reconnect. In USB mode, short press to play/pause. In AUX mode, short press to mute/unmute.
5. LED Button: Short press to turn on /off the soundbar LED.
6. (+) Button: Short press to skip to next track; long press to increase the volume.
7. USB Input




SOUNDBAR (REAR)

1. AUX IN.
2. OPTICAL INPUT.
3. HDMI (ARC) INPUT.



REMOTE CONTROL



1.Power Button: Standby mode for Power ON/OFF.

2.Mute: Mute ON/OFF

3.Pair: Connect or disconnect Bluetooth; long press the button to disconnect or reconnect to Bluetooth

4.INPUT: Switch among input modes: BT; Optical; HDMI(ARC); USB and AUX

5.Volume+: Increase the volume

6.Volume-: Decrease the volume

7.Next Button: In Bluetooth mode, short press for next song; in USB mode short press for next song and long press for fast forward.

8.Previous Button: In Bluetooth mode short press for previous song; in USB mode short press for previous song and long press for Rewind.

9.Reset/Play-Pause Button: In Bluetooth and USB mode short press to play/pause; in AUX mode, short press to mute/unmute; long press the button to reset the soundbar and clear Bluetooth memory.


- 10.MUSIC: For MUSIC EQ effect
- 11.MOVIE: For MOVIE EQ effect
- 12.NEWS: For NEWS EQ effect
- 13.3D: For 3D EQ effect
- 14.TREB+: Increase treble
- 15.TREB-: Decrease treble
- 16.BASS+: Increase bass
- 17.BASS-: Decrease bass

REMOTE BATTERY INSTALLATION

1. Open the battery panel
2. Insert 2 batteries without polarity reversed
3. Close the battery panel
4. Keep the remote control within 8m-10m of the soundbar unit





Note:

Remove the batteries when the unit is not being used for a long period of time.




WALL MOUNTING

- Measure 24,41 inches (620mm) and drill 2 parallel holes (1/4 inch each) in the wall
- Firmly apply a dowel into each hole in the wall (dowel required only for solid wall).
- Attach the soundbar to the wall and push the soundbar to the right 1/8inch each to lock in.



WIRELESS SUBWOOFER & SOUNDBAR CONNECTION

- Connect the wireless subwoofer to the power supply.
- Switch on the subwoofer using the power switch in the back and the LED light will start blinking in blue colour.
- Switch on the soundbar using the power button on the control panel & enter the "BT" mode
- Soundbar & Subwoofer will pair automatically within 10 seconds & a voice prompt "ding-dong" will be heard & the blue LED will turn solid.



RESET: Long press the RESET button to disconnect the subwoofer if needed and follow the same procedure to pair it again.

USING THE SOUNDBAR

Plug in the power cable of the soundbar to an external power socket; the unit goes into standby mode. Short press the Power Button on the remote or soundbar control panel to turn on the soundbar.

AUX: Use the provided 3.5mm AUX cable to connect external audio sources to the soundbar. Press the Input button on the remote control to select AUX mode.

HDMI(ARC): Use an HDMI cable to connect the soundbar to your HDMI(ARC) enabled device. Press the Input button on the remote control to select HDMI(ARC) mode.

OPTICAL: Use an Optical cable to connect the soundbar to your Optical device. Press the Input button on the remote control to select OPT mode.

USB: Insert your USB drive into the USB port on the soundbar. The soundbar goes automatically under USB mode. You can also press the Input button on the remote control to switch to USB mode.

Bluetooth: Press the Input button on the remote control to enter Bluetooth mode. Turn on the Bluetooth functionality on your media device, search for “Aavante Bar Theme” and select the same to establish pairing.

AC POWER

Notes:

- *Make sure the power supply is correct and never handle the power cord or its plug with wet hands when plugging into or unplugging from an outlet. Ensure the main power switch is in OFF state before connecting the power cord to the power supply to avoid damage to the unit.*
- *A damaged power cord can easily cause an electric shock or fire hazard, never use a power cord after it has gotten damaged.*

TECHNICAL SPECIFICATIONS

Model	boAt AAVANTE BAR Theme
Technology	Optical; HDMI(ARC); Bluetooth v5.3; AUX; USB
Drivers	2.25"*4 SB + 6.5"*1 SW
Output Power	160W R.M.S.
Frequency Response	40Hz-20KHz
Signal-to-Noise Ratio	≥ 70dB
Impedance	4Ω*4+4Ω*1
BT Transmission Range	Up to 10m
Bluetooth	V5.3
Dimensions	Soundbar: L900*H79*D90mm Subwoofer: L190*H372*H324.5mm