

CARVE
YOUR OWN PATH



WATCH
xplorer

Thank You for choosing the boAt Watch Xplorer as your trusted fitness companion. The boAt Watch Xplorer is here to help you fearlessly carve your own path!

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it, for a smooth sail. You may refer to these instructions for later use as well.


Happy exploring, boAthead!

Package Contents

- 1 boAt WATCH XPLORER x1
- 2 User Manual x1
- 3 USB magnetic charging cable x1
- 4 Warranty Card x1

CHARGING THE WATCH


The smart watch must be charged before initial use. Connect and charge the watch with the image below as a reference.



WEARING THE WATCH

Wear the watch at a finger's distance from your wrist bone, adjusting the tightness of the band to a comfortable position.

Note: Wearing too loosely or tightly might affect the accuracy of the measurements of the wellness mode.



CHANGING THE STRAP

Flip the switch on the side to take the wristband out.



TURNING THE WATCH ON

Long press the side button to turn the watch on



CONNECTING TO THE APP

1. Download the boAt ProGear app on your phone. Available on both App Store (iOS 8.0 and above) and Google Play Store (Android 4.4 and above)



Google Play App Store

OR

Scan QR Code

2. Connect the device directly with the mobile application. Do not connect with the phone's Bluetooth directly.
3. Select XPLORER on the home screen of the app and click OK to connect.
4. To use all features of your Watch Xplorer seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
5. Turn your phone's Bluetooth and GPS on.


Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

iphones will not prompt any information unless you complete Bluetooth pairing with XPLORER.

SYNCING YOUR SMARTWATCH TO THE APP

On the app, connect the watch with bluetooth to synchronize your data.

Open mobile app - swipe down click on the sync prompt



Note: Synchronize data at least once daily to avoid data loss in the watch.

CHANGING THE DIAL INTERFACE

Long press the dial to change watch faces

FUNCTIONALITY

Swipe the screen to enter different menus



Sports Modes

Tap on the sports mode's icon -> Select your sport -> Enter countdown automatically



During sports
To Pause: Short press the right key
To Restore: short press the right key
To End: Long press the right key -> select end on the screen

Note: For Outdoor Running, Outdoor walking, outdoor cycling, the watch Xplorer will automatically revert for GPS. If you skip the GPS positioning, the motion trail will not be measured and displayed.

WELLNESS MODE



Heart Rate Monitor

Click on the heart rate monitor icon to check heart rate and data for the day.



Sleep Monitor

Tap on the icon to review sleep data of the previous night. Once the sleep criteria is met, your watch Xplorer will start recording from 8 pm at night to 12 pm in the afternoon the next day.

Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement.

You can check the data on the app only after the awake criteria is met.



Guided Breathing Mode

Click on the guided breathing icon to regulate your breathing and relax.



Alarm & Timer

To enable this feature, add it on the app on your phone.



Music Control mode

Tap on this icon to launch music control mode.

Note: Enable the feature on the app to use it.



Weather Forecasts

Make sure the app is connected to your smartwatch to receive live weather updates for the next 3 days.



Menstruation Cycle Tracker

To enable this feature, turn it on from the app.

The menstruation cycle tracker records menstrual cycle, predicts changes and ovulation.

TURNING THE WATCH OFF

Go to Settings on your watch -> Tap on Power off.

PRODUCT PARAMETERS:

Model	WATCH Xplorer
Screen Type	1.3 Inche Full-Touch 2.5D Curved Display
Battery Capacity	210 mAh
Charging Voltage	5.0 2V
Charging time	2.5 hours
Battery life	8-10 days
Water Resistance	5 ATM
Weight of product	39g
Operating Temperature	-20°C - 45°C
Bluetooth version	BLE 4.2
Product frequency	2402-2480 MHz
Max. transmission power consumption	0.75 dBm

Charging norms & Precautionary Guidelines:-

1) Charger/Brick/Adapter	- 5V 2A
--------------------------	---------

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Maintenance:

Regularly clean your wrist and the strap of the smart watch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

FAQ

Search for the app to connect keeps failing

1. Keep the boAt progear app updated to the latest version
2. Close all the programs on the watch -> Stop and restart Bluetooth -> Connect again

Note: Make sure your phone system meets Android 4.4 and above and iOS 8.0 and above

My Watch Xplorer is receiving no alerts, texts, or phone calls

Make sure smart reminders on the app are on and synced to the Watch Xplorer.

My Bluetooth keeps getting disconnected

1. Make sure there is not more than 2m distance between bluetooth on the phone and the watch.
2. There is no obstacle in between the watch and the phone.

Which functions of the Watch Xplorer need Bluetooth to work?

Call & Text Notifications and Find My Phone needs
For the functions of call alert, message alert, find the phone, you need to turn on the mobile phone's Bluetooth, and maintain the connection with the mobile phone.

I can't see my recorded data on the watch or on the app

The data of the watch is automatically synchronized when you open the app. Make sure you open it to synchronize daily. The watch will only keep your data for 7 days at a time.

SAFETY & PRODUCT INFORMATION

Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built in batteries of non replaceable battery devices.
- Do not use sharp objects to remove the battery.

HEALTH WARNING

If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.

-The optical heart rate sensor will glow green and flash. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.

-The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

-The device accessories, heart rate sensor, blood pressure, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data is for reference only. We're not responsible for any deviation in data.

THINGS TO KEEP IN MIND

- Sync data every 7 days to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

DISCLAIMER

This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION

- RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.
- DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
- Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.