USER MANUAL

© Breath Training Mode











WAVE MAX

Thank you for choosing the boAt Wave max as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.





Tap on this icon to use the stop watch.

Fap on the icon to make your phone ring. Make sure the

World Clock

① Find phone 02:18

* 1249 Tap on this to see world clock

Find My Phone

app and phone are connected.

Tap on it to turn your dial into a flashlight.



CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A

bo At Wave Max x1 • USB magnetic charging cable x1

User Manual x 1 + Warranty Card x 1





URNING THE WATCH ON

ong press the side button to turn the watch or

Screen-on time: Adjust the screen on time from here

You can access all watch faces from the settings menu.

*Battery will drain out faster if enabled.

Watch faces

Restart

Power off

Always On mode: Enable this feature to set the always on mode on your screen

You can also long press on the home screen to see watch face options. Swipe left or

Adjust the vibration levels to strong, weak or none

Cover to turn the display off: Enable this feature to use the palm gesture.

right to navigate and then long press to select your preferred watch face.



CONNECTING TO THE APP

1. Download the boAt Wave app on your phone.

Available on both App Store (iOS 9.0 and above) and

2. Connect the device with the mobile application.

the 'connection' and 'grant access' system prompt.

6. Turn your phone's Bluetooth and GPS on.

4. Select Max on the home screen of the app and tap on bind.

5. To use all features of your Wave Max seamlessly, tap on 'yes' to

To ensure connectivity throughout your journey, make sure the app is

allowed to run in the background of your phone at all times.

App View

Power off

Select from grid view or list view for how your UI should look

This will reset the watch and all the data will get lost.

Click on this button to switch off the device

Do not connect with the phone's Bluetooth

directly.

Vibration

Power off

(B) About

① Help

Restart

Power off

(Ahout (7) Help

Google Play Store (Android 6.0 and above) Scan FOR CODE!







Watch Face Market Select more watch faces by clicking "new arrivals"

ACCESSING FEATURES ON THE APP

see the values of your step, duration, HR, stress, etc.

Customize your watch face by adding a photo from your camera or album or select from the pre-loaded ones.

Note: Make sure your watch and phone are connected via Bluetooth. Do not exit the downloading interface until it displays 100% downloaded.



Enable automatic or real time heart rate monitoring, stress monitoring, enable excessive stress reminder, hydration reminder, sedentary reminder, and menstrual cycle alerts. Open App-> devices -> device info-> health monitoring



weather and music control.

Swipe right to access recently used applications

Swipe down to view all your notifications

Swipe up to access the shortcut menu

Settings from the shortcut menu.

TURNING THE WATCH OFF

PRODUCT PARAMETERS:

Screen Type

Net weight

Battery Capacity

Bluetooth version

Charging time

Frequency band

Working time

Working temperature

Maximum transmission power

You can turn on call alerts to get notification of important calls when you

Swipe left to access activity, heart rate, blood oxygen, stress levels, sports menu,

Note: The watch can be used to reject calls, but cannot be used to answer calls or messages.

You can access DND, Wake Gesture, Brightness, Find my phone, Flashlight, Alarms &

Wave Max

AMOLED

300mAh

BLES.1

12 Days

-20°C to 50°C

2402-2480Mhz

Turn the feature on from the app first to receive notifications on your watch.

Press the side button --> Scroll down and go to settings --> Tap on power off

Message notifications Enable to get real time notifications on the watch.

Enable 3 second delay feature, if you want to get the notification on the

Device Settings

Enable DND. Find My Phone, Music Control, Wake Gesture, Weather forecast, world clock, auto brightness to use it on the watch Shortcuts: You can add or remove the features that you want to show in the

Training: Start any sport of your preference. Calibrate your phone's GPS shortcut screen Training type: Add or remove the sports mode from here.

Device: Click on the device info card to enter the menu

Home Page: Pull down to synchronize your data. You can add or remove

cards on the home page by tapping on 'edit cards'. You will be able to

SYNCING YOUR SMARTWATCH TO THE APP

- Data Synchronization Open the app on your phone.
- Make sure your watch Max is connected to the app.
- Synchronization will start automatically once you enter the app

Synchronize data at least once a day to avoid data loss in the watch.

Regularly clean your wrist and the strap of the smartwatch, especially after sweating

during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the Product.

Do not wash the strap with a household cleanser. Please use soap less detergent,

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol

• If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor

before using the heart rate monitor of the watch.

The optical heart rate sensor will glow green and flash. If you suffer from epilepsy or are sensitive to

blinking light sources, please consult your physician before wearing this device.

The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely

contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

Sync data everyday to avoid data loss.
 Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and

other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by

Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
 Keep your arm still while measuring data for accurate measurement.

rinse thoroughly and wipe with a piece of soft towel or napkin.

Do not disassemble the built in batteries of non-replaceable battery devices.
 Do not use sharp objects to remove the battery.

and then follow the above Pluscedure.

SAFETY & PRODUCT INFORMATION

Do not disassemble, bore or damage the battery.

NAVIGATING THROUGH THE FUNCTIONS

Press the multifunction button once to enter the main menu

Outdoor Run

Tap on this to view your daily step count, active minutes, walking



There are 100+ sports mode in wave max. You can use 24 modes at a time from the watch.

Default sports mode includes:

Outdoor Run, Indoor Run, Outdoor Walk, Indoor Walk, Hiking, Outdoor Cycle, Indoor Cycle, Cricket, soccer.

Yoga, Workout, Pool Swim, Open Water Swim, Rower, Elliptical, Pilates, dance, Zumba, core training, traditional strength training, functional strength training, HIIT, cooldown, workout other

You can select other sports mode from the app -> device-> device setting-> training

Tap on your preferred activity to begin. You can swipe left to access music control while

Disclaimer: This Product is an electronic monitoring product and is not intended as a medical

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is

for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle

To pause/resume: short press the side button

To end: short press -> tap on the X icon -> long press to end sport

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

1. Keep the boAt Wave app updated to the latest version

valuable raw materials and treatment of toxic substances

Search for the app to connect keeps failing

*All records will be available on the app if you keep it synchronized.

A minimum of 1 minute of any activity is required for the watch to record.

The touch screen will not function when exposed to water. When your watch does get wet, wipe the surface with a soft cloth before using it.

*Make sure the maximum depth of water is 50m & maximum time of exposure in water is 30 minutes



Heart Rate Monitor Tap on this icon to measure your heart rate. Wear the watch on

your wrist, keep it close to your heart, and stay still. Note: Measurements are for reference only and not for medical



your wrist and stay still. Note: Measurements are for reference only and not for medical

Tap on the icon to review the sleep data of the previous night.

Once the asleep criteria is met, your watch will start recording

from 8 pm at night to 10 am in the morning the next day.

Here's what the data indicates 0-30: Relaxed | 30-60: Normal | 60-80: Medium | 80> is considered to be dangerous.

When your HRV is higher than usual, use the guided breathing modes to take a minute and relax.

Once you lie down and the watch detects no movement for 30 minutes, it will start

*For accurate sleep data recording, the asleep criteria have to be met which includes limited

Wear the watch on your wrist and tap on the icon to measure

The stress monitor tracks your heart rate to track levels of stress.

The watch calculates your stress levels using a 1-minute heart rate

variability (HRV) test. The higher the value, the higher the stress

recording your sleep. It will stop recording if it detects excessive movement.

*The awake criteria will be met only after it records some noticeable movement.

stress levels. Try to stay still.

You can check the data on the app only after the awake criteria is met.

movement, wrist positions and angles, and more.

O Street Leve 02:11 Stress Monitoring

WAVE MAX

Note: It is recommended to record your stress levels every day before exercising. Preferably at the same time, and under the same conditions for accurate measurements.

*This measurement is for reference purposes only, and not for medical grade use.

(1) Maximum depth of water: 30m (2) Maximum time for exposure to water: 30 minute

2. Close all the Programs on the watch →Stop and restart Bluetooth and GPS→Connect 3. Check and enable notification functions of your phone and keep the phone and watch

Note: Make sure your phone system meets Android 6.0 and above and iOS 9.0 and above.

My Wave Max is receiving no alerts, texts, or phone calls

The device accessories, heart rate sensor, blood oxygen level monitor, and other relevant data is Make sure smart reminders on the app are on and synced to the Wave Max. designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood oxygen data is for reference only. We're not responsible for any deviation in data. Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in

Also make sure your notification centre of the phone is displaying messages. Only then will your smartwatch also display those notifications.

1. Make sure there is not more than 7m distance between Bluetooth on the phone and

The time displayed on my phone and on Wave Max are inconsistent

reference. We reserve the right to modify or improve any of the functions described in this manual Make sure your watch wave Max is connected to your phone through the app and not your phone's Bluetooth feature itself. without any prior notice. At the same time, we hold the right to continuously update the product

The calculated number of steps on app and on Wave Max

Ensure that your app and the watch Wave Max are synchronized.

Will it be okay to take a bath wearing Waye Max?

The water resistance will only work under the following conditions

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

Charging norms & Precautionary Guidelines: -

1) Charger/Brick/Adapter : 5V 2A Any other accessory can be paired up with the Product as long as the specifications are as per above norms.

My Bluetooth keeps getting disconnected

2. There is no obstacle in between the watch and the phone.

of the Music Apps with different control protocols. Plustocols.

Add events on the app to get reminders on your watch.

Tap on the icon, select your mode (from slow, rapid or normal,) select your preferred time duration, then follow the instructions

Weather

Enable this from the app to get weather updates for the next 3

Tap on this icon to launch music control mode.

feature to work properly. This feature might not work for some