

WAVE MAGMA

Thank you for choosing the boAt Wave Magma as your fitness transformation companion.


Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.



 USB magnetic charging cable x Warranty Card x1


CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



RNING THE WATCH ON/OFF

To turn the watch on/off, long-press the side button for 3-5 seconds. You can wake up the screen by lifting your wrist.



1 Download the boAt Crest app on your phone. Available on both App Store (iOS 12.0 and above) & Google Play Store (Android 7.0 and above)

Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Crest app; ensure that the phone's Bluetooth as well as the GPS functionalities are turned on

3. Select Wave Magma on the home screen of the app and click pair to connect. 4. Once connected, you will get an alert to connect with WAVEMAGMA XXXX, click pair if need to receive or make calls from the watch

5. To use all features of your Wave Magma seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.

6. Disable battery optimization

Tap on this to enable/disable all notifications except alarms and timers, to

sleeping it won't vibrate and make a sound except for alarms.





Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

SYNCING YOUR SMARTWATCH TO THE APP

Make sure your Wave Magma is connected to the app.

Synchronization will start automatically once you enter the app interface. Synchronize data at least once every day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS SWIPE RIGHT FOR THE MAIN MENU

lick on this to check your daily activity data like step count, calorie, active minutes, no. of times you were standing.

Use a dialer to dial any number.

Note: Make sure your watch is connected with the phone's Bluetooth.



Frequent Contacts

recent calls of the watch.

You can find your frequently contacted numbers here. Up to 10 contacts can be saved on the watch.

You can find recently received, missed, and outgoing call logs in the

Choose from multiple sports modes like outdoor run, outdoor walk,

basketball, table tennis, badminton, indoor cycle, elliptical, yoga, cricket, mountaineering, and golf. You can add or replace the activities

Tap on any sports mode to start the activity, you can pre-set your goal

as well for each activity. Press the side button or swipe right to pause

or stop the activity. If the activity is less than 3 mins, it will not be

Sync your smartwatch to the app to get the detailed analysis.

indoor walk, long jump, indoor run, strength training, football.

according to your preference through the app.

Heart Rate Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.



Stress monitoring Click this option to start the stress monitoring. Make sure you wear your

watch on your wrist properly to get the accurate results. Analysis of the measurement is

Normal: 30-59 Medium: 60-79 High: 80-100

Note: Measurements are for reference only and not for medical purposes.



Workout records

Click on the breath training icon to regulate your breathing with the instructions given to relax.

You can view the records of your workouts here

Tap on the icon to review the sleep data of the previous night.

from 8 pm at night to 10 am in the morning the next day.

You can also track sleep scores on the boAt Crest app.

Once the asleep criteria are met, your smartwatch will start recording

Once you lie down and watch detects no movement for 30 minutes, it

You can check the data on the app only after the awake criteria is met.

For accurate sleep data recording, the asleep criteria have to be met

The awake criteria will be met only after it records some noticeable

will start recording, and will stop recording if it detects excessive



Tap on this to set an alarm on your watch



Connect with the boAt crest app to get daily weather updates on

You can create event reminders from the app and get the alerts on



Women Health

Enable and set the details on the boAt crest app and get the alerts of your period and ovulation dates on the watch



Tap on this and pair the watch with the phone's Bluetooth and give the command from the watch.



Click on this to start the stopwatch on your watch

Tap on this to turn on the timer.

music from your phone.

Tap on the remote music control icon on your watch to play

Note: Some apps with different protocols might not work.

Tap on this to turn your dial into a flashlight.





Tap on this icon to do all the calculations in your smartwatch.



Tap on the remote camera icon on your smartwatch to click a photo from your phone.



Tap on this icon to find your phone. Once enabled, your phone will

start ringing and vibrating. Tap again to stop it. Note: Your smartwatch should be connected to your phone via



Bluetooth and within its range for this feature to work.





Note: Turn the camera on from your phone to use this feature.

Auto Activity

enable wake gesture



Enable auto workout mode from here





Tap on this to adjust the brightness, set the screen on time and



Tap on this to adjust the watch volume, enable/disable ringtone, adjust vibration levels



Tap on this icon to change the language

Tap on this to switch your watch off.

Change the menu style to grid or list view from here



Tap on this to restart your watch.

schedule DND, and to enable smart mode. Note: Once the smart mode in enabled if the watch detects that you are





Tap on this to reset watch data.

Note: All data will be erased if watch is reset

wipe down for shortcut menu

You can access DND, Brightness, Power saving mode, Raise to

Shows the device details

Wake, Flashlight and Settings.





ou can access daily activity, sleep, heart rate monitor, weather.

wipe left or right to access all data



Screen type	196" HD Display
Battery capacity	300mAh
Net weight	27.2g
Bluetooth version	Bluetooth 5.3
Working temperature	0 ℃ ~45 ℃
Charging time	2 Hours
Working time	5-7 Days
Water Resistance	IP68
Frequency band	2.4-2.48GHz

Swipe up to access the notifications

PRODUCT PARAMETERS:

Screen type	196" HD Display
Battery capacity	300mAh
Net weight	27.2g
Bluetooth version	Bluetooth 5.3
Working temperature	0 ℃ ~45 ℃
Charging time	2 Hours
Working time	5-7 Days
Water Resistance	IP68
Frequency band	2.4-2.48GHz

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during

exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleanser. Please use soap less detergent, rinse

thoroughly and wipe with a piece of soft towel or napkin. For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

Search for the app to connect keeps failing.

1. Keep the boAt Wearable app updated to the latest version

My Watch Wave Magma is receiving no alerts, texts, or phone calls.

2. Close all the programs on the watch --> Stop and restart Bluetooth and GPS --> Connect again 3. Check and enable the notification functions of your phone and keep the phone and watch in Note: Make sure your phone system meets Android 7.0 and above and iOS 13.0 and above.

Make sure smart reminders on the app are on and synced to the Wave Magma. Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications.

Make sure app is running in the background and battery optimization feature on the phone is My Bluetooth keeps getting disconnected.

3. Make sure the app is running in the background.

and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.

The IP68 water resistance will only work under the following conditions:

2) Maximum time for exposure to water: 30 minutes

SAFETY & PRODUCT INFORMATION

Do not disassemble, bore or damage the battery. •Do not disassemble the built in batteries of non-replaceable battery devices. •Do not use sharp objects to remove the battery.

Health Warning •The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to

•If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.

blinking light sources, please consult your physician before wearing this device. •The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

•The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We're not responsible for any deviation in data.

•Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical

without any prior notice. At the same time, we hold the right to continuously update the product

reference. We reserve the right to modify or improve any of the functions described in this manual

THINGS TO KEEP IN MIND Sync data everyday days to avoid data loss.

Sports modes support up to 6 hours of exercise at a time.

1 Make sure there is not more than 7m distance between Bluetooth on the phone and the watch. •Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the

Which functions of the Wave Magma need Bluetooth to work? •Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry. Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud Keep your arm still while measuring data for accurate measurement.

Will it be okay to take a bath wearing the Wave Magma?

(1) Maximum depth of water: 1.5m

2. There is no obstacle between the watch and the phone.

The watch isn't suitable for hot baths, hot springs, saunas, snorkelling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

Old electrical appliances must not be disposed of together with the residual waste,



DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

but have to be disposed of separately. The disposal at the communal collecting poin via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of





















RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.