



**V8 MAX WIRELESS MECHANICAL KEYBOARD  
USER MANUAL**

Knob  
Version

# Fully Assembled Version

## Keyboard

1x Fully Assembled Keyboard

### Including

1x Case

1x PCB

1x PC Plate

1x PET Film


1x Case Foam

1x Sound Absorbing Foam

5 Sets x Stabilizers

1 Set x Keycaps (PBT Double-shot)

1 Set x Switches



## Cable

1x Type-C Cable

1x Type-A to Type-C Adapter

1x Extension Adapter For Receiver

## Receiver

1x Type-A 2.4GHz Receiver


1x Type-C 2.4GHz Receiver

## Tools

1x Keycap & Switch Puller

1x Screwdriver

1x Hex Key



# Barebone Version

## Keyboard Kit

1x Keyboard Kit (Without Keycaps & Switches)

### Including

1x Case

1x PCB


1x PC Plate

1x PET Film

1x Case Foam

1x Sound Absorbing Foam

5 Sets x Stabilizers



## Cable

1x Type-C Cable

1x Type-A to Type-C Adapter

1x Extension Adapter For Receiver

## Receiver

1x Type-A 2.4GHz Receiver


1x Type-C 2.4GHz Receiver

## Tools

1x Keycap & Switch Puller

1x Screwdriver


1x Hex Key



## Quick Start Guide

If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.


Mac / Windows





## 1 Switch To The Right System


Please make sure the system toggle on the top left corner has been switched to the same system as your computer's operating system.




---

## 2 Connect 2.4GHz Receiver



Connect the 2.4GHz receiver to the device USB port.



Switch toggle to 2.4GHz mode




2.4G = 2.4GHz




Note: For the best wireless experience, we recommend using the extension adapter for receiver and putting the 2.4GHz receiver somewhere on your desk close to your keyboard for a low rate of latency and fewer signal interferences.


### 3 Connect Bluetooth



Switch toggle to Bluetooth




Press fn1 + Q (for 4 seconds) and pair with device named Keychron V8 Max.



### 4 Connect Cable




Switch toggle to Cable




## 5 The Backlight

Press **fn1 + A** to change the lighting effect




Press **fn1 + caps lock** to turn the backlight on/off




---

## 6 Adjust The Backlight Brightness

Press **fn1 + S** to increase the backlight brightness



Press **fn1 + X** to decrease the backlight brightness



## 7 Warranty


The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.




---

## 8 The Layers

There are five layers of key settings on the keyboard.  
The layer 0 is for the Mac system.  
The layer 1 is for the Windows system.  
The layer 2 is for the Mac Multimedia keys.  
The layer 3 is for the Windows Multimedia keys.  
The layer 4 is for function keys.



If your system toggle is switched to Mac, then the layer 0 will be activated.



If your system toggle is switched to Windows, then the layer 1 will be activated.



## 9 The Keychron Launcher App

Please visit [launcher.keychron.com](https://launcher.keychron.com) to access the Keychron online launcher app. This app enables users to remap keys, adjust key actuation points, assign multiple commands to a single key, enter game controller mode, and more.

If it cannot recognize your keyboard, please reach our support to get instruction.




\*The online launcher App can only run on the latest version of Chrome, Edge, and Opera browsers yet.

\*The online launcher App only works when the keyboard is connected by wire to the computer.

---

## 10 Factory Reset



### Troubleshooting? Don't know what's going on with the keyboard?

#### **Factory reset your keyboard**

1. Power on your keyboard.
2. Press and hold fn2 + J + Z (for 4 seconds). The keyboard backlight will flash in red quickly for 3 seconds, indicating that the keyboard has been reset.

#### **Flash your keyboard firmware**




1. Visit [launcher.keychron.com](https://launcher.keychron.com) to open the online Launcher web app.
2. Ensure the keyboard is in Cable or Wired mode and plug in the power cable.
3. Find the 'Firmware Update' tab on the left side of the Launcher and connect your keyboard with it.
4. Follow the instructions on the Launcher and complete the firmware update.

\*Step-by-step guide, search the keyword "firmware" on [keychron.com](https://keychron.com).

## V8 MAX WIRELESS MECHANICAL KEYBOARD SPECIFICATIONS

| Specifications       |   |
|----------------------|---|
| Layout               | 65%   |
| Switch type          | Mechanical  |
| Width                | 138 / 121.5 mm  |
| Length               | 359.5 mm  |
| Front height         | 22 mm (without keycaps)<br>31.5 mm (with keycaps installed)   |
| Back height          | 29.5 mm (without keycaps)<br>40.2 mm (with keycaps installed) |
| Keyboard feet height | 2 mm  |
| Angle                | 4 / 9 / 10.5 degree   |


## V8 MAX WIRELESS MECHANICAL KEYBOARD OVERVIEW



- 1 Bluetooth Indicator
- 2 2.4G Indicator
- 3 2.4G/Cable/BT (Mode Toggle)
- 4 Win/Android Mac/iOS (OS Toggle)
- 5 Type-C Port


## DEFAULT KEY LAYOUT:

LAYER 0: This layer will be activated when your keyboard's system toggle is switched to Mac.






LAYER 1: This layer will be activated when your keyboard's system toggle is switched to Windows.




LWin = Left Windows LAlt = Left Alt RAlt = Right Alt


LAYER 2: This layer will be activated when your keyboard's system toggle is switched to Mac and press the fn1/MO(2) key.



LAYER 3: This layer will be activated when your keyboard's system toggle is switched to Windows and press the fn1/MO(3) key.



LAYER 4: This layer will be activated when your press the fn2/MO(4) key.



## KEY DESCRIPTION

| Key Description |                            | Key Description |   | Key Description |                  |
|-----------------|----------------------------|-----------------|---|-----------------|------------------|
| Scr-            | Screen Brightness Decrease | RGBMd+          | RGB Mode Next                                   | BTH3            | Bluetooth Host 3 |
| Scr+            | Screen Brightness Increase | RGBMd-          | RGB Mode Previous                               | 2.4G            | 2.4GHz Host      |
| Bright-         | Backlight Decrease         | Hue+            | Hue Increase                                    | Batt            | Battery life     |
| Bright+         | Backlight Increase         | Hue-            | Hue Decrease                                    | NKRO            | N-key rollover   |
| Prvs            | Previous                   | RGB SPI         | RGB Speed Increase                              |                 |                  |
| Play            | Play/Pause                 | RGB SPD         | RGB Speed Decrease                              |                 |                  |
| Next            | Next                       | MO(2)           | Layer 2 will be activated when holding this key |                 |                  |
| Mute            | Mute                       | MO(3)           | Layer 3 will be activated when holding this key |                 |                  |
| Vol-            | Volume Decrease            | MO(4)           | Layer 4 will be activated when holding this key |                 |                  |
| Vol+            | Volume Increase            | BTH1            | Bluetooth Host 1                                |                 |                  |
| RGB Toggle      | Turn Backlight on/off      | BTH2            | Bluetooth Host 2                                |                 |                  |

## LED STATUS OVERVIEW

| LED Location                 | Function           | Status   |
|------------------------------|--------------------|--|
| Power Indicator              | Charging           | Charging - Static Red<br>Fully charged - Static Green<br>Low power - Slow blinking |
| Bluetooth / 2.4GHz Indicator | Bluetooth / 2.4GHz | Reconnecting - Fast Blinking<br>Paired - Light off<br>Pairing - Slow Blinking      |
| Caps Lock Indicator          | Caps Lock          | Enable Caps Lock - Static White<br>Disable Caps Lock - Light Off                   |

### FUNCTION DESCRIPTION: CHARGING

Plug the cable into a USB port and plug the other end into the keyboard port. Power Indicator: A red light will stay on while charging; Charging is completed in about 5 hours, a green battery indicator will appear. If the power is low, the red light will blink.

\*The V8 Max keyboard is compatible with all USB ports. Please use a 5V 1A adapter or USB 3.0 for the best performance. The V8 Max can be charged in 2.4GHz/Cable/Bluetooth mode.

\*\*This product supports up to 5V charging voltage and 1A charging current. We are not responsible for any problems caused by improper charging.

## **2.4GHZ / CABLE / BLUETOOTH MODE (MODE TOGGLE)**

### **2.4GHZ MODE**

1. Connect the 2.4GHz receiver to your device's USB / Type-C Port.
2. Switch the toggle switch to the 2.4GHz option. The keyboard will automatically connect to your device.

### **BLUETOOTH MODE**

1. Switch the toggle switch to the Bluetooth option.
2. Backlighting will be turned on.
3. Hold "fn1+Q" key for 4 seconds to activate Bluetooth pairing (the Bluetooth indicator fast flashes for 3 minutes to detect pairing).
4. Search for the Bluetooth device "Keychron V8 Max" on your device and connect it (the Bluetooth indicator goes off after successful pairing).

*Note: This keyboard supports pairing up to 3 devices simultaneously via key combination "fn1" + "Q" / "fn1" + "W" / "fn1" + "E".*

*\*The Bluetooth indicator will continue to flash for 3 minutes.*

*\*\*Slow or failed connections may exist due to different Bluetooth versions, please make sure all the settings are correct.*

### **SWITCH BLUETOOTH DEVICES**

Short press key combination "fn1" + "Q" / "fn1" + "W" / "fn1" + "E" to switch to other device.

## **RECONNECT:**

1. Switch the keyboard to the Bluetooth option to activate the keyboard.
2. The Bluetooth indicator flashes for 3 seconds and automatically pairs with the last paired device.
3. If the Bluetooth indicator is off, press any button to enter the connection again.

\*The keyboard must have been paired with the device to perform this function.

## **WIRED MODE**

1. Switch the toggle switch to the Cable option (it only works when a USB cable is plugged in).
2. Connect our cable with your PC and keyboard.
3. Backlighting will be turned on.

\*Under Wired Mode, keyboard will not enter into Battery Saver Mode.

## **TURN OFF THE KEYBOARD**

Switch the keyboard to the Cable option and unplug the power cable.

## **BACKLIGHT SETTING**

- Short press key combination “fn1” + “caps lock” to turn the backlight on/off.
- Short press key combination “fn1” + “A” / “fn1” + “Z” to switch between different types of lighting effects.



## TROUBLESHOOTING

If unable to pair keyboard to device, confirm that the device you're trying to pair with is Bluetooth-capable. If so, restart the device and try pairing it with the keyboard again.

Note: On a Windows computer, a new Bluetooth connection will sometimes require additional software updates—a process that may still be ongoing after a message appears indicating a successful completion. Wait at least 20 minutes after pairing to make sure all updates are completed before restarting the computer.

Confirm that the device is configured to accept Bluetooth connections (Windows) and supports an external keyboard (HID profile).

Go to Bluetooth Devices > Open Settings and select the following:

Allow Bluetooth devices to find this computer

Allow Bluetooth devices to connect to this computer

Alert me when a Bluetooth device wants to connect

### **My keyboard isn't working in Bluetooth mode.**

For the computer/smartphone:

Go to your device Bluetooth settings>Select the keyboard and remove/delete/unpair it.

Then restart your device.

For the keyboard:

Turn the keyboard off and back on. Then reconnect it to your device.

### **My keyboard isn't working in 2.4 GHz mode.**

Ensure the toggle is set to 2.4 GHz, remove the receiver from your device, and press "fn" + "4" for 4 seconds to force pair, then reinsert the receiver into the device, keeping the keyboard within 20 cm of the receiver for optimal pairing.

### **Wireless connection is interrupted even within 10 meters.**

Check if the keyboard is resting on a metal surface that can interfere with the wireless signal.


### **Third-party input tools are not compatible with the keyboard.**

Due to compatibility, versions, brands and drivers of Windows/macOS, functionalities of third-party input tools may be affected while using the keyboard. Please make sure your operating system and drivers are up to date.

### **Certain multimedia keys or function keys do not work.**

Functions of certain multimedia keys may be disabled due to compatibility, versions, brands, and drivers of devices.

\*Multimedia keys: 

Function keys: 

### **Safety Precaution:**

Keep the product, accessories and packaging parts out of the reach of children to prevent any accidents and choking hazards.

Always keep the product dry to avoid corrosion.

Do not expose the product to extreme temperatures below -10°C(14°F) or above 50°C(122°F) to preserve the lifespan of the keyboard.

**Keychron, Inc.**  
**Dover, DE 19901, United States**

Find us at:

<https://www.keychron.com>

[Support@keychron.com](mailto:Support@keychron.com)

 @keychron

 @keychron

 @keychronMK

Designed by Keychron

Made in China





V8 Max 无线机械键盘用户手册

旋钮版本

# 完全组装版本

## 键盘

1x 已组装成品键盘

## 包含

1x 外壳

1x PCB

1x PC定位板

1x PET垫


1x 底壳泡棉

1x 吸音泡棉

5套PCB卫星轴

1套键帽(PBT材质-双色注塑)

1套机械轴体



## 线材

1x Type-C 接口线材

1x Type-A to Type-C 转接头

1x 接收器延长器

## 接收器

1x Type-A 2.4GHz 接收器


1x Type-C 2.4GHz 接收器

## 工具

1x 拔轴键器

1x 十字螺丝刀

1x 内六角螺丝刀



## 套件版本

### 键盘

1x 键盘本体 (不包含键帽、轴体)

### 包含

1x 外壳

1x PCB


1x PC定位板

1x PET垫

1x 底壳泡棉

1x 吸音泡棉

5套PCB卫星轴



### 线材

1x Type-C 接口线材

1x Type-A to Type-C 转接头

1x 接收器延长器

### 接收器

1x Type-A 2.4GHz 接收器


1x Type-C 2.4GHz 接收器

### 工具

1x 拔轴键器

1x 十字螺丝刀


1x 内六角螺丝刀



## 快速入门指南

如果您是Windows用户,请在包装内中找到对应的键帽,然后按照下面的说明找到并替换以下键帽。


Mac / Windows





## 1、系统切换


请确保键盘左上角的系统拨片切换到对应系统，  
如果没有选择正确，  
部分功能将无法使用。




---

## 2、连接2.4GHz接收器



将2.4GHz接收器连接到设备USB端口。



把开关拨到2.4GHz模式




2.4G = 2.4GHz




注意:为了获得最佳的无线体验,我们建议将2.4GHz接收器  
插入线材+赠送的接收器延长器,放置在书桌上靠近你的键盘,  
以降低延迟率和更少的干扰信号。


### 3、连接蓝牙



把开关拨到蓝牙模式



长按fn1+Q四秒使键盘进入配对模式，  
键盘的配对名为: Keychron V8 Max。




---

### 4、连接有线




把开关拨到有线模式




## 5、更改键盘背光模式以及快速关闭/开启键盘背光

组合fn1+A键,更改键盘背光模式




组合fn1+caps lock键,可快速关闭/开启键盘背光




---

## 6、调整键盘背光亮度

组合fn1+S键,提高键盘背光亮度



组合fn1+X键,减少键盘背光亮度



## 7、保修

由于V8 Max 无线机械键盘是可高度定制且易于组装的，所以键盘的任何一个部件出了问题，我们只会更换键盘有问题的部件而不是整个键盘。



---

## 8、关于键盘键层说明

键盘有五层按键设置。  
层0是用于Mac系统；  
层1是用于Windows系统；  
层2是用于Mac系统多媒体  
层3是用于Windows系统多媒体；  
层4是用于功能键。



如果您的系统拨片切换到Mac档位，层0将被激活。



如果您的系统拨片切换到Win档位，层1将被激活。



## 9、关于Keychron Launcher App

请访问[launcher.keychron.com](http://launcher.keychron.com) 使用在线Launcher App。  
该软件可以映射按键, 调节按键触发点, 设置一键多重命令,  
体验游戏手柄模式等功能。

如果Launcher App不能识别你的键盘,  
请联系我们以获得技术支持。




\*在线Launcher App只能在最新版本的Chrome, Edge和Opera浏览器中运行。

\*Launcher App仅在键盘通过有线连接到计算机时有效。

---

## 10、恢复出厂模式&更新固件



### 如果键盘出现了故障, 不知道怎么办?

#### 恢复出厂设置

1. 打开键盘(任意模式均可)。
2. 按住 fn2 + J + Z (持续 4 秒)。键盘背光灯会呈红色快速闪烁 3 秒, 表示键盘已重置。

#### 刷新键盘固件




- 1 访问 [launcher.keychron.com](http://launcher.keychron.com) 打开在线 Launcher web app。
2. 确保键盘处于Cable或者有線模式, 并插入电源线。
3. 在Launcher上找到“固件更新”选项, 并将键盘与其连接。
4. 按照Launcher提示, 完成固件更新。

\*在 [keychron.com](http://keychron.com) 上搜索关键字“Firmware”可以找到步骤指南。

## V8 Max 无线机械键盘规格

| 规格     |                                  |
|--------|----------------------------------|
| 布局     | 65%                              |
| 开关类型   | 机械轴体                             |
| 宽度     | 138 / 121.5 mm                   |
| 长度     | 359.5 mm                         |
| 键盘下沿高度 | 22 mm (不含键帽) / 31.5 mm (含键帽高度)   |
| 键盘上沿高度 | 29.5 mm (不含键帽) / 40.2 mm (含键帽高度) |
| 键盘脚垫高度 | 2mm                              |
| 键盘倾斜角度 | 4° / 9° / 10.5°                  |


## V8 Max 无线机械键盘概述



- ① 蓝牙指示灯
- ② 2.4G指示灯
- ③ 2.4G /Cable /BT (连接模式切换)
- ④ Win/Android Mac/iOS (OS 切换)
- ⑤ Type-C 充电口

## 按键布局

层0:当您的系统拨片切换到Mac档位的时候,层0将被激活使用。









## V8 Max 无线机械键盘多媒体按键说明

| 按键说明       |           | 按键说明    |                | 按键说明 |            |
|------------|-----------|---------|----------------|------|------------|
| Scr-       | 屏幕亮度-     | RGBMD+  | 下一个RGB灯光模式     | BTH3 | 蓝牙连接设备 3   |
| Scr+       | 屏幕亮度+     | RGBMD-  | 上一个RGB灯光模式     | 2.4G | 2.4GHz连接设备 |
| Bright-    | 键盘背光亮度-   | Hue+    | 下一个灯光颜色        | Batt | 电池电量       |
| Bright+    | 键盘背光亮度+   | Hue-    | 上一个灯光颜色        | NKRO | 全键无冲       |
| Prvs       | 上一曲       | RGB SPI | RGB灯光速度+       |      |            |
| Play       | 播放/暂停     | RGB SPD | RGB灯光速度-       |      |            |
| Next       | 下一曲       | MO(2)   | 按住MO(2),层2将被激活 |      |            |
| Mute       | 静音        | MO(3)   | 按住MO(3),层3将被激活 |      |            |
| Vol-       | 音量-       | MO(4)   | 按住MO(4),层4将被激活 |      |            |
| Vol+       | 音量+       | BTH1    | 蓝牙连接设备 1       |      |            |
| RGB Toggle | 关闭/开启键盘背光 | BTH2    | 蓝牙连接设备 2       |      |            |

## 功能说明

LED状态显示如下：

| 功能          | LED位置            | 状态                              |
|-------------|------------------|---------------------------------|
| 充电          | 充电指示灯            | 充电—红灯常亮<br>满电—绿灯常亮<br>低电量—慢闪    |
| 蓝牙 / 2.4GHz | 蓝牙 / 2.4GHz通道指示灯 | 快闪—回连<br>常亮3秒,后熄灭—连接成功<br>慢闪—配对 |
| 大小写         | 大小写状态指示灯         | 白灯—大写<br>熄灭—小写                  |

### 充电

将电线插入USB端口，将另一端插入键盘的端口。

充电指示灯：充电时，充电指示灯红灯长亮；大约5小时充电完成，指示灯绿色长亮。

\*V8 Max键盘与所有USB端口兼容。要获得最佳信号和最快充电时间，建议采用USB3.0端口或5V-1A电源适配器。

\*V8 Max可在2.4GHz / 有线 / 蓝牙 模式下充电。

\*有线模式下，充电指示灯不会熄灭。

\*本产品最高支持5V充电电压，和1A充电电流。因不当充电而产生的问题，我们概不负责。

### 背光灯

- 短按组合键“fn1+caps lock”可关闭/开启键盘背光。

- 短按组合键“fn1+A” / “fn1+Z”可切换背光效果。

## 2.4GHz / 蓝牙 / 有线模式

### 2.4GHz模式

1. 将键盘2.4GHz接收器连接至设备端口的USB接口
2. 将键盘“模式切换”拨动到“2.4G”位置 (2.4GHz模式)，键盘将自动连接到您的设备。

### 蓝牙模式

1. 将键盘“模式切换”拨动到 BT 位置。
  2. 键盘背光灯将打开。
  3. 长按“fn1+Q”键4秒激活蓝牙配对 (蓝牙指示灯闪烁3分钟)。
  4. 在你的装置上搜索蓝牙装置“Keychron V8 Max”并连接它 (配对成功后蓝牙指示灯熄灭)。
- 注意:此键盘支持通过组合键“fn1+Q” / “fn1+W” / “fn1+E”依次配对最多3台设备。

\*因蓝牙版本较多等原因，初次连接可能出现连接缓慢或连接失败等问题，请耐心等待检查设备设置是否正确。

### 切换至蓝牙装置

短按组合键“fn1+Q” / “fn1+W” / “fn1+E”切换到其他装置。

\*切换过程可能会因切换频繁或切换速度过快，导致延迟，此时请耐心等待或重新切换。

### 回连

1. 将键盘切换到Bluetooth位置启动键盘。
2. 蓝牙指示灯快闪3秒，自动对上一次配对的设备。
3. 如蓝牙指示灯熄灭，可按任何按键再次进入回连状态。

\*键盘必须曾经配对该装置才能实现此功能。

### 有线模式

1. 将键盘“模式切换”拨动到 Cable 位置（没插USB线的时候键盘无任何反应）。
2. 使用本产品USB Type-C线连接电脑即可使用。
3. 键盘背光灯将打开。

\*在有线模式下，键盘不会自动进入省电模式。

### 关闭键盘

将模式开关拨动到Cable，拔掉电源线，此时键盘关闭所有模式。

### 疑难排解

#### 我无法将键盘与我的设备配对蓝牙。

答：确认您要配对的设备可使用蓝牙。

重新启动设备并尝试再次与键盘配对。

注意：在Windows计算机上，新的蓝牙连接有时需要额外的软件更新 - 在出现表示成功完成的消息后，该过程可能仍在进行中。配对后至少等待20分钟，以确保在重新启动计算机之前完成所有更新。

确认设备配置可接受蓝牙连接(Windows)并支持外部键盘(HID配置文件)。

转到蓝牙装置>打开设置，然后选择以下复选框：

允许蓝牙设备找到这台电脑

允许蓝牙设备连接到这台电脑

当蓝牙设备想要连接时提醒我

#### 我的键盘无法使用蓝牙。

答：请打开您的电脑/智能手机上的蓝牙设置>选择键盘并删除此设备/取消配对，然后重启您的设备；

关闭并重新打开键盘，然后重新连接到您的设备。

#### 我的键盘无法使用2.4G。

请确保开关已切换至2.4GHz，从设备中拔出接收器，按住“fn1”+“R”键4秒以强制配对，然后将接收器重新插入设备，确保在配对过程中键盘与接收器的距离不超过20厘米以获得最佳配对效果。

### 2.4GHz / 蓝牙连接或在10米内受干扰。

答：检查键盘是否放在可能干扰无线信号的金屬表面上。

### 第三方输入工具与键盘不兼容。

答：由于Windows/Android操作系统的兼容性、版本、品牌和驱动程序，使用键盘时，第三方输入工具可能会受到影响。请确保您的操作系统和驱动程序是最新的。

某些多媒体键或功能键在设备上不起作用。

答：由于设备的兼容性，系统版本，驱动程序等原因，某些多媒体键或者功能键可能无法使用。

\*多媒体键：



功能键：



### 安全预防措施：

防止儿童接触到产品、附件和包装部件，以防止任何意外和窒息的危险。

保持产品干燥，避免腐蚀。

不要将产品暴露在低于-10°C(14°F)或高于50°C(122°F)的极端温度下，以保持键盘的寿命。


**Keychron, Inc.**  
**Dover, DE 19901, United States**


<https://www.keychron.com>

通过以下方式与我们联系

Support@keychron.com

 @keychron

 @keychron

 @keychronMK

Keychron设计

中国制造

中国区总代：渴创技术（深圳）有限公司  
执行标准：GB/T 14081-2010  
售后热线：400-0766268  
地 址：深圳市龙岗区坂田街道大发埔社区  
大发路24号文坑工业区2栋201