










**DINING CHAIR**  
**UC-1**




# Hardware:

<b>A×8</b>  Φ8 Flat washer	<b>B×8</b>  Φ8 Lock washer	<b>C×1</b>  M8 Allen key	<b>D×4</b>  M8×55MM Shorter Screw	<b>E×4</b>  M8×60MM Longer Screw
---	--	--	---	--

# Parts list:

<b>F×1</b>  Back
<b>G×2</b>  Hind Legs
<b>H×2</b>  Front Legs




Put chair back on a clean flat surface. Align Hind legs in the seat pad as shown in the diagram.

Using SHORTER SCREW (D) with Washer (#A,B).

DO NOT FULLY TIGHTEN.

First HAND tighten then tightened using key up-to 60-80% only at this stage.






Align front legs in the seat pad as shown in the diagram.

Using LONGER SCREW (E) with Washer (#A,B).


DO NOT FULLY TIGHTEN.

First HAND tighten then tightened using key up-to 60-80% only at this stage.

**3**



**100%**




Put chair in the upright position and **SIT ON THE CHAIR** to press downwards on the seat pad ensuring that all 4 feet touch the ground and chair is leveled.

Proceed to tighten all screws making sure the chair remains level when tightening.

Check that all screws are tight on a regular basis to ensure chair remains level and secure.

Also you can using adjustable feet to keep four legs level .



**4**

