





USER
MANUAL

BLAZE

B24



1. ON/OFF
2. AUX
3. TF Port
4. USB Slot
5. Type C Charging Port
6.  Mode
7. Volume +
8. Volume -
9. Pause/Play
10. RGB Lights

CONTROLS

'M' - Change Mode: Bluetooth | FM | USB | TF | Aux

'+' - Volume up | Next track

'-' - Volume down | Previous track

'Play/Pause button' - Play | Pause | Answer | Hang up phone Call | TWS



Power Switch

- Turn On/Off your speaker

Bluetooth Connection

- While turning on the Bluetooth speaker, it will be in BT mode at first.
- Go to your phone's BT list and search & connect to 'Blaze B24'.
- In future, the sound bar will get automatically connected to the paired device within the effective distance range.

Music Play

- Insert USB drive or micro-SD card with MP3 files to play music.
- Using the 3.5mm audio cable to connect your phone with the speaker to play music
- “+” - Short press to play the next song | Long press to increase the volume
- “-” - Short press to play the previous song | Long press to decrease the volume

Radio Mode:

- Short press the “M” button to change to FM, in order to switch to better channels, connect the Type-C charging cable on the sound bar and press the “Pause/Play” button for 2 secs to search for automatic radio station.

TWS Function

- To connect to 2 different sound bars at the same time, press and hold the "Pause/Play" button for 3 secs, until you hear a short tone.
Note: Both the speakers should be turned ON.

RGB Led Light

- Long press on the "M" button to Change / Turn On / Turn Off the Led Light.

Calling

- Click on the "Pause/Play" button once to answer/hang up the call under Bluetooth Mode.
- Long press on the "Pause/Play" button to reject the call.

Troubleshooting

Some terminal music players are without automatic switching play function. In this case, a 'pop' noise may be heard between the songs.

If you cannot connect the speaker to your mobile device, try removing the speaker pairing name from your mobile's BT list and re-connect as instructed above.


The sound performance may also be affected when there is a weak connection between the mobile device and the speaker. To improve connection, bring the mobile device closer to the speaker or remove any obstacles between the two devices.

The sound performance may also be affected if the battery power level is low on the speaker. Please make sure the speaker is fully charged to improve the issue.

Note


- Charge the speaker fully before the first use.
- The charging time depends on the existing charged levels of the battery and the specifications of the USB adaptor.
- During the charging period, the charging indicator turns off automatically when the battery is fully charged.
- The speaker's usage time depends on charge in the battery, mode, volume level etc.
- When the speaker is turned On, but no device to connect, it will automatically turn off after 5 mins.


CHARGING GUIDELINES




- Use only 10W adapters for charging your smart watch.
- Caution against using high-power mobile adapters (beyond 10W), as this may lead to charger faults.
- Using adapters with higher power ratings can result in malfunctions and reduce the lifespan of device and your chargers.
- Users can contact customer support for any further assistance or clarification on concerns related to charging and power adapters.



 +91 96112 93293

 +91 96112 93293

 support@crossbeats.com