



COLD PRESS MASTICATING SLOW JUICER

Model: SJ 9000
220–240V ~ 50/60Hz • 200W
Capacity: 500ml



Instruction Manual

IMPORTANT:

1. The Unit is designed for household use only.
2. Commercial users will not obtain the regular warranty as stated in the terms of the warranty card.
3. This is not a toy. Please do not let children play with it or use it.


IMPORTANT SAFEGUARDS

1. Make sure the electricity supply is suitable for this unit.
2. This unit is intended for household use only. Do not use the unit at outdoors or for other purpose than intended.
3. Use the unit only as described in this manual.
4. To prevent electrical shock, do not immerse the unit, cord set and plug into water.
5. This is not a toy and not to be used by children. Close supervision is required when the unit is used near children.
6. Ensure to unplug the unit when not in use, assembling or disassembling, and before cleaning.
7. The continuous operation time of this product should be within 20 minutes.
8. No-load or overloaded operation of machine is prohibited.
9. Do not touch or move any moving parts during operation of machine.
10. Do not use finger, spoon or chopsticks to push fruits or vegetables into the chute of machine. Please only use the provided push rod.
11. Do not open the unit when it is operating.
12. Do not place the unit near any explosives, heated oven or hot surfaces.
13. Operate the unit only on flat surfaces.
14. Do not let the cords hang over the edge of table or any other surfaces.
15. Please hold the plug to disconnect from the power socket, not by the wire.
16. If parts of product structure is found to be damaged (especially the safety device and power cord), please stop using and send it to service centre to be repaired by our qualified technician.
17. This product is not intended to be operated by persons (including children) with weak physical condition, slow reaction, intellectual disability, and lack of experience, unless they are under supervision or instruction by the person who is responsible for their safety.

NOTE:

To avoid hazard of electric shock, unplug the unit from power outlet when not in use or before cleaning. If the supply cord is damaged, stop using immediately and bring it back to service centre for repair.

PARTS DIAGRAM



1	Feeding Chute	5	Juice Container
2	Screw Shaft	6	Pulp Container
3	Juicing Bowl	7	Push Rod
4	Power Base	8	Cleaning Brush

USING FOR THE FIRST TIME

1. Remove all packaging materials, plastic bags and labels.
2. Make sure the electricity supply is 220-240V~ 50/60Hz.
3. Clean the Containers / Feeding Chute / Screw Shaft / Juicing Bowl / Push Rod with Soapy water. Then rinse and dry thoroughly.
NOTE : DO NOT IMMERSE THE POWER BASE UNIT IN WATER.
4. Assemble the parts per the instruction in the assembling method section.
5. Connect the power cord to the power source.

The unit is ready to use now.

ASSEMBLING METHOD

Please make sure the unit is not plugged and the switch is turned to “O” setting prior to assembling the machine.



1. Position the Juicing bowl on the Power base by aligning the position of the spouts to the power base openings. (Fig 1)
2. Push the screw shaft firmly into the center of the bowl, making sure that it touches down the bottom, or else the cover cannot be closed. (Fig 2)
3. Position the chute on the bowl to align the ▲ to the “” and twist it clockwise until it clicks the safety lock. Please make sure that the arrow ▲ on the cover aligns with the Lock graphic “” on the Bowl. (Fig 3)
4. Place the juice container and the pulp container under the relevant spouts. (Fig 4)

Fig 1




Fig 2



Fig 3





Fig 4



OPERATION INSTRUCTION

1. Connect the unit with Power.
2. Check and make sure all parts are well assembled in correct position.
3. Make sure the machine is at off “O” position.
4. Make sure the juice and pulp containers are in position.
5. Make sure the juice spout cover is closed.
6. Prepare the fruits or vegetables and cut them into pieces max 3cm x 7cm strips or 7cm x 7cm cubes.
7. Put fruit strips/cubes into the chute.
8. Press the switch to Setting “-” to start the juicing operation.
9. Push the food down with the pusher only.
10. In case of food stuck inside the Bowl, please switch to “R” reverse function instantly.

NOTE:

Please do not use the juicer longer than 20 minutes continuously.

Open & Close Of Juice Spout Cover

During the juicing process, you could keep the Leak-Proof Plug closed before the juice is full in the juicing bowl. (Fig 5)



Fig 5

BENEFITS OF DRIP-STOP COVER :

1. To stop dripping at the end of juicing.
2. To mix the juice with different fruits and veggies.

USAGE TIPS :

1. Remove hard pits or seeds prior to pressing to prevent possible damage to the squeezing screw.
2. If mixed juices are to be made, please begin with harder fruit, and followed by the softer fruits.
3. Please let the juicer to run for 30 seconds after the last ingredient was fed.

ATTENTION :

The juicer is not suitable for juicing overly hard or fibrous and starchy fruits or vegetables such as Sugar Cane. There are some fruits which contain too much starch to juice. Some examples are Avocado, Bananas, figs, Mango, Papaya, Dragon Fruit, Strawberry, Grape without seeds etc. They will clog up the stainless steel sieve.

DISASSEMBLING METHOD

NOTE:

If the juicer gets overheated, it will turn off automatically to protect the machine. In this case, please turn the juicer off “O”. Wait 10 minutes to let the juicer cool down and then turn it on again.

To disassemble the unit after use and before cleaning. Please turn the juicer to “O” position and disconnect the juicer from power source. Then, please follow the steps below:


1. Remove the Juice and Pulp containers. (Fig 6)
2. Remove the Chute. Turn the chute anti-clockwise until the ▲ aligns with the “” sign. (Fig 7)
3. Remove the Screw Shaft by pulling it out upward. If it is very hard, swing gently and pull. (Fig 8)
4. Remove the Juicing Bowl by lifting it upward vertically. (Fig 9)

Fig 6




Fig 7




Fig 8





Fig 9



CLEANING & MAINTENANCE

IMPORTANT:

Please wash the juicing parts every time immediately after each used, otherwise the pulp might stick tightly in Juicing Bowl & Screw Shaft which will then affect the disassembly, cleaning and juicing performance.

CLEANING & MAINTENANCE

1. Switch off and unplug the juicer.

Wash the disassembled parts (Fig 10) with water. If the meshes are clogged with pulp, please use the provided cleaning brush to remove the excess fiber.




Fig 10

Attention:

- Do not use iron wire brush, abrasive or sharp object tool to clean the unit.
- Please do not use water above 40°C.

3. In case there are any residues remained in the mouth of the pulp spout, please pull out the silicone valve as shown in (Fig 11) below and clean under running water.




Fig 11

Press the silicone valve to close it properly and tightly after cleaning.

4. To clean the seal ring in the center of the juicing bowl, please follow the steps as below :

- a. Turn the Squeezing Bowl upside down for easier handling, Push the seal ring out with your thumb (Fig 12a) and clean it with water.
- b. After Cleaning, please put it back to the center hole. The small ribbed surface should be should face upward (Fig.12b) Make sure the groove of the seal ring well fit in the squeezing bowl.
- c. The big flat size of the seal ring will be inside while the small and ribbed side is outside the Squeezing Bowl. (Fig 12c)




Fig 12a




Fig 12b




Fig 12c

5. Do not put the Power Base into water for cleaning. Wipe it with damp cloth only.

6. After cleaning, please dry the parts thoroughly and store them in a dry, cool place.

STORAGE

1. Follow cleaning instructions to well maintain the unit before storage.
2. Tidy up the power cord set.
3. Keep the unit away from children's easy access.
4. Store the unit and the accessories at a dry, cool place.

NOTE:

Please make sure the unit and parts are dry before storing them.

USEFUL TIPS

Item	Warning	Reason
1	Not for Ice cubes.	Ice cubes are too hard. It may damage the parts.
2	The ingredient with long fiber needs to be cut down to 3 x 7 cm thin strips or 7 x 7 cm cubes.	Long fiber foods may easily block the spout.
3	The peel and pits/seeds must be removed from oranges, lemons, grapefruit and melons before use.	The hard pit or seeds may damage the squeezing parts. The peel may block the spout of pulp.
4	Do not use other accessory as a pusher.	It may damage the juicer and cause injury.
5	Each juicing cycle must not longer than 20 minutes.	Working over time may cause damage to the motor.
6	Never put the spoon, chopsticks into the opening of the Chute, the juice and pulp spouts.	It may damage the juicer.

TROUBLE SHOOTING

Trouble	Cause	Solutions
The juicer stops running suddenly.	Too many ingredients put into the juicer.	Switch to “R” position instantly to make the ingredients return upwards. If the machine still stops running, please clean the machine before using again.
	Hard fruits or vegetables have not been cut in small pieces.	Hard fruits and vegetables (such as carrot) should be cut into thin strips or small cubes before putting into chute.
The juice yield is low or juice flows out of the main housing.	The Bowl and the silicone valve are not installed properly.	Please re-install the Bowl silicone valve by referring to the installation method.
Abnormal noise.	Parts cause extrusion sound during squeezing.	The sound is caused by extrusion of fruits and vegetables, which is normal.
The Feeding Chute cannot be opened.	There is too much pulp inside the bowl.	Press switch to “R” setting to eject the pulps backward.
	There are hard foods stuck inside.	Press switch to “R” to eject the object backward.
	The pulp mess is stuck.	Pour water into the Chute to soften the stuck pulp mess overnight.
The container & accessories are dyed after use.	Dyed parts are due to natural color of specific fruits/veggies.	This is caused by natural coloring and unavoidable.

SERVICE & IMPORTANT NOTICE

- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarity qualified person in order to avoid a hazard.
- **WARNING:** This appliance is not intended for use by persons (including children) with reduce physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

IMPORTED BY NATIONAL ELECTRICAL TRADERS