

geemarc™ CL8360

Hear the Difference

Amplified Mobile Phone with dual SIM and Camera



English

**!!!Check our website to see if an update version
of this User Guide is available.!!!**
www.geemarc.com

CONTENTS

CONTENTS	2
INTRODUCTION	6
Unpacking the Telephone.....	7
DESCRIPTION	8
General Description	8
LCD Screen Description.....	15
Menu Navigation	17
Menu Map	17
Network Services & Password	19
SETTING UP, Install SIM Card and Battery	21
Charging the Battery	22
Switching On/Off & Battery Use	24
USING THE TELEPHONE, Standby Mode,	
Making a Call	26
Making a Call from the Call Record & Phone Book	27
Making a Call from the Phone Book.....	28
Receiving a Call, Rejecting a Call, Switch Off Alerts	28
Options During a Call	29

CONTENTS

Receiving Volume	30
Call Timer	30
Tone response.....	30
SMS	31
Write & Send a Text Message	31
Inbox - Receiving a Text Message	32
Options for a Text Message	32
Reviewing Stored Text Messages (Inbox)	33
Sent Messages	33
Draft box.....	34
Delete SMS	34
Text Message Settings	35
Service Messages.....	38
Service Loading	38
VOICEMAIL	39
Voicemail Number Setting.....	39
Listen to Voicemail	39
PHONEBOOK.....	40
Create a Phone Book Entry	40
Create a Phone Book Entry from Standby	42

CONTENTS

View Phone Book Entries.....	42
Options within Phone Book.....	43
Create a Picture Phone Book Entry	44
Dial a Picture Phone Book Entry	45
Storing a Speed Dial Number.....	45
Dialling a Speed Dial Number	45
CALL RECORD	46
Display Missed Calls	46
Display Dialed Calls	47
Display Received Calls	47
Delete Call Logs.....	48
Call Settings.....	48
HANDSET SETTINGS.....	52
I.C.E	52
Profiles	52
Boost Settings.....	53
Tone control.....	54
Phone Settings.....	54
Network Settings.....	55
Security Settings	56
Restore Default	56

CONTENTS

SOS	57
SOS Function.....	57
SOS Number Settings.....	59
SOS Message Record	59
ADVANCED SETTINGS	60
Tools.....	60
Multimedia.....	62
File Manager	63
TROUBLESHOOTING	64
SAFETY INFORMATION	67
HEARING AID INFORMATION	70
NETWORK SERVICES	71
GUARANTEE	72
RECYCLING DIRECTIVES	74

INTRODUCTION

Congratulations on purchasing your Geemarc CL8360 telephone. This telephone offers many functions such as an alarm, calendar, camera, video, SMS text messaging, a phone book and picture phone book, human voice options with talking keypad, and a speakerphone and speed dial buttons. It has an SOS function in which five numbers can be programmed as emergency contacts. In case of emergency these contacts will be called and SMS messages sent by pressing a single button.

The font size on the colour LCD display is large and the buttons on the keypad are easy to see and use. This mobile telephone has a loud ringer and strong vibrating setting. There is adjustable receiving volume control reaching up to 35dB with boost key. All these features add up to make this a highly suitable telephone for the elderly, or for people who are hard of hearing or who are vision impaired and anyone who simply wants to keep in touch with a great degree of ease.

It is important that you read the instructions below in order to make the best use of your Geemarc telephone. Keep this user guide in a safe place for future reference.

This guide explains how to use the following telephone:

CL8360

INTRODUCTION

Unpacking the Telephone

When unpacking the telephone, you should find the following in the box:

- 1 CL8360 mobile telephone handset
- 1 Desktop charging unit
- 1 Mains power adaptor
- 1 x Li-Polymer rechargeable battery
- 1 User Guide



For product support and help visit our website at

www.geemarc.com


Telephone 01707 384438

Or fax 01707 832529

DESCRIPTION


General Description

Handset Description (front)





DESCRIPTION

Handset Description (Rear, Sides)






DESCRIPTION

Charging Contacts







Micro USB port

DESCRIPTION

	<p>Power key/On-hook key</p> <ul style="list-style-type: none">• Long press to power the telephone on and off• End a call• Cancel current process and return to standby
	<p>Call Key</p> <ul style="list-style-type: none">• Make a call after dialling the number• Receive a call
	<p>Navigation Button</p> <p>Up Key</p> <ul style="list-style-type: none">• Scroll up through lists and menu options.• This is a dedicated key in Standby. It can be set up in Handset Settings or Camera function in standby mode <p>Down Key</p> <ul style="list-style-type: none">• Scroll down through lists and menu options.• This is a dedicated key in Standby. It can be set up in Handset Settings

DESCRIPTION

	<p>Left / Right key</p> <ul style="list-style-type: none">• These are soft keys: they take on different functions depending on the menu displayed. The current function is always displayed by the text above the key.
	<p>Asterisk key</p> <ul style="list-style-type: none">• Press this key to insert one or more symbols while composing a message or editing a phonebook entry name. Then use the navigation keys to move to the symbols you want to insert.
	<p>Hash Key</p> <ul style="list-style-type: none">• Press to switch between different input modes while composing a text message or editing a contact name.
	<p>Torch Key</p> <ul style="list-style-type: none">• In standby, press and hold for a few seconds and the torch will shine steadily. Press once more to turn it off.

DESCRIPTION



Volume Up and Down Key

- Use this key to increase ringer volume when you access Profiles menu or when receiving an incoming call. Increase the earpiece / speakerphone volume during a call. There are 7 volume levels available.

Volume Down Key

- Use key to decrease the ringer volume when you access Profiles menu or when receiving an incoming call. Increase the earpiece/speakerphone volume during a call. There are 7 volume levels available.

DESCRIPTION

General Description

Your CL8360 phone can be equipped with the following items, which are not included:

- One or two SIM cards
- Memory card

You can choose to install a single SIM card, in which case you will be receiving service from a single cellular service provider, or two SIM cards – in which case you will be able to receive service from two different service providers. This is useful if you want to ensure you have better network coverage and to avoid having to rely on a single service provider.

The memory card is needed to provide space for your photographs and other multimedia content, as well as for storing your SOS message, phone book and more.

The maximum capacity is 4G.

DESCRIPTION

LCD Screen Description

The LCD screen is split into three distinct areas:

The icon area. At the top of the screen. This area displays the various system icons which help you to use the telephone.

The main area. Across the centre of the screen. It displays the following:

- Number being dialled
- Caller ID information
- Phonebook
- Menu information
- In standby mode current time, date and service provider name

The soft key area. At the bottom of the screen.



Signal Strength icon








This is always displayed when your telephone is switched on. It shows the current signal strength. More bars indicate more signal strength. There is one of these icons per SIM.



Alarm icon

The alarm has been set to ring at a specified time.

DESCRIPTION

	Battery Status icon This is always displayed when your telephone is switched on. It shows the level of battery charge. More bars indicate more battery charge
	Roaming icon A roaming call is taking place i.e. international call – outgoing or incoming
	SMS icon A new SMS (text message) has been received
	Mute icon The microphone is temporarily muted during the conversation
	Silent icon The telephone is in silent mode. There will be no call alert
	Boost icon Telephone sounds are set to extra-loud.
	Headset icon The headset is plugged in
	Missed Call

DESCRIPTION

Menu Navigation

The **MENU** soft key or central square key is used to activate the menu. The **BACK** soft key is used to go back a level in the menu system.

The ▼ and ▲ keys are used to scroll through the menu.

▲ move backward through the menu

▼ move forward through the menu

Sometimes < and > are used to navigate through sub menus.

The **OK** soft key key is used to confirm/ select an action or choice on a screen.

The central square key is used to go to Menu or to confirm/ select an action or choice on a screen.

Menu Map

Messages	Write Message Inbox Drafts Outbox Sent Messages Message Settings
Phonebook	Picture Phonebook Normal Phonebook
Call Center	Call History

DESCRIPTION

	Call Settings
Multimedia	Camera Gallery Audio Player Sound Recorder FM Radio
File Manager	Phone Memory card (if available)
Services	Internet Service SIM Toolkit SIM Toolkit
SOS	SOS Record SOS Message
Settings	I.C.E Profiles Boost Setting Tone control Phone Settings Network Settings Security Settings Restore Settings
Tools	Calendar Tasks Alarm Bluetooth Calculator

DESCRIPTION

Network Services

To use this mobile telephone you must subscribe to a service from a service provider. Different service providers offer different features (at a variety of charges). This may effect the features made available to you through this mobile telephone.

Using 1 or 2 SIM Cards

Your phone will work just fine with one SIM card installed from one service provider.

However it is possible to install two SIM cards in your CL8360 - there are many reasons to do this – here are some of the main reasons:

1. If you use two SIMS from different providers you will probably get better network coverage.
2. You can add your professional SIM and keep your personal SIM.

DESCRIPTION

Passwords

This mobile telephone allows you to set up passwords to help protect your telephone from unauthorized use.

The PIN and PIN2 codes are supplied with your SIM card. The PIN code help to protect the SIM card from unauthorized use. The PIN2 code is required to access certain services.

The PUK and PUK2 codes may be supplied with the SIM card. If you enter the PIN code incorrectly three times in succession, the PUK will be required. If the codes are not supplied, contact your service provider.


SETTING UP

Install SIM Card and Battery

Always switch the telephone off and disconnect the charger before removing the battery.


Take care when handling the SIM card. The SIM card and its contacts can be easily damaged by scratches or bending.

To remove the battery compartment cover, slide the cover in the direction shown and pull it off.



Remove the battery (if battery already inside).

Slide a SIM with the gold contacts face down under the silver SIM holder as shown below.



SETTING UP

You can insert 2 SIM cards into this telephone. There are many reasons to do this, however, one important reason is that if you use two SIMS from different providers you will probably get better network coverage. However, just using one will be fine too!


Observe the battery contacts (the gold coloured contacts must face towards the top left).and insert the battery.


Place the battery cover into position and press down lightly.

Charging the Battery

Charging via the Mini USB Port

Plug the charger into a wall socket.

Connect the lead from the charger into the Micro USB port on the bottom of the telephone. During charging, the battery icon  starts to fill.




SETTING UP

Charging via the Charging Unit

Plug the charger into a wall socket.

Connect the lead from the power adapter into the Micro USB port on the charging cradle.

Place the mobile telephone in the charging cradle with the power lead facing backwards and the phone display screen and keypad facing you. If you place the phone in the cradle facing the wrong way, it will not charge.




SETTING UP

Note: Only use batteries and chargers supplied with the telephone. The guarantee will be invalid if an unapproved cable is used. Keep the battery contacts clean and free of dirt. Try and avoid removing the battery as this may cause it to short circuit.


If the battery is completely discharged, it may take a few seconds before the charging indicator appears on the display or before any calls can be made.

Before the handset is first used, the battery must be charged for a minimum of 4 hours.

Switching On/Off


Press  for 3 seconds or longer to switch the telephone on.

If no SIM card has been inserted, **INSERT SIM** will be displayed. Only emergency calls can be made until the SIM has been inserted.

Press  again for 3 seconds to switch the telephone off.

SETTING UP

Battery Use

The  icon is continuously displayed at the top right corner of the LCD display. The icon indicates the level of battery power. The more bars displayed, the more power available.



When the battery charge is low, a warning message will be displayed. The back lighting and certain other functions may stop working. When the battery is too weak for the telephone to operate, the handset will automatically switch off.

Battery talk and standby times are subject to change. Replace the battery when the battery power has deteriorated noticeably (requires charging more frequently).


USING THE TELEPHONE

Standby Mode

In standby mode, your telephone is ready for use but it conserves the battery power by switching off the battery-consuming functions such as the LCD display.

If you do are not using it, the telephone goes into standby mode after a few seconds. You can also switch the telephone to standby mode by pressing



To re-activate the LCD screen, simply press the Menu soft key .

Making a Call

Dial the number on the keypad . The phone will audibly repeat the numbers you enter.

Press the **CLEAR** soft key to delete an incorrect digit

Press , the number is automatically dialled

To end the call simply press




USING THE TELEPHONE

To place an international call you need to press + before the country code. Simply, press * key twice. Some foreign telephone networks have extension lines that cannot be dialled as dial-through, but need to be entered by the keypad. To dial these directly, press * quickly three times in a row after the telephone number. The p character will appear and then you can enter the extension.

Making a Call from the Call Record

Press  to display the “All calls” list



Use ▼ or ▲ to scroll through the list and find the desired number

Highlight the desired number. Press  again, the number is automatically dialled

USING THE TELEPHONE

Making a Call from the Phone Book

If you have stored numbers in the phone book, you can dial numbers using the phone book.


1. Menu--->Phonebook--->Picture Phonebook or Normal Phonebook--->Select the telephone number required
2. On finding the desired number, press  , the number is automatically dialed
3. To end the call simply press 


Receiving a Call

When the phone rings with an incoming call:

- If the Caller ID service is activated, the caller's telephone number will be displayed.
- If this caller's number is stored in the Phonebook, the associated name will be displayed.

Press  to answer

To end the call simply press  .

You can increase or decrease the phone volume using the Volume Up + and Down - key on the left side of the phone. 

USING THE TELEPHONE

Rejecting a Call

To reject an incoming call, simply press



Switch Off Alerts

You can temporarily switch off all of the alerts and vibrations for an incoming call.

On receiving an incoming call, press the **SILENT** soft key

Options During a Call

You can use a variety of functions during a call by pressing the **OPTION** soft key.

You get the option to do the following :

- Hold a Call
- End a Single Call
- Enter the Phonebook
- View Call History
- Messages
- Sound Record - Record the call
- Background Sound (you can create a background noise to the opposite caller)
- Mute

Call diverting", "multiparty calls", "call hold" and "call

USING THE TELEPHONE

waiting" functions require network support, so please contact your network provider.

Receiving Volume

During a conversation, you can use the **V+** and **V-** buttons on the left side of the phone to adjust the ear piece volume level. There are 7 volume levels.

Hands free Function

You can turn on the phone's built-in speakerphone. Press the right soft key. In this mode there is no need to hold the handset. You will hear the third party through the speaker and the microphone will pick up your voice.

Note: Before putting the handset to your ear, please ensure you have switched the speakerphone off.

Call Timer

Your handset automatically times the duration of every external call. The time is shown during the call and for a few seconds after the call has ended.

Tone response

In standby mode, you have the possibility to change the tone response. You must press and hold the key 0 until you see the setting on the display.

Messages Menu

The Messages menu is where you can perform all the available actions on Short Text Messages (SMS).

A text message sent using this telephone can contain up to 160 characters including spaces.

This menu enables the following functions:

- Write message
- Inbox
- Drafts
- Outbox
- Sent messages
- Message settings.

Write & Send a Text Message

1. Menu--->Messages--->Write Message--->Text Message or MMS
2. Write your text message (See text entry in the Phonebook Chapter)
3. Options--->Send to--->Enter Number and then enter the actual number **or**
Select from the Phonebook List
4. Options--->Send

SMS

Inbox - Receiving a Text Message

Upon receiving a text message, the phone plays an audible alert. **1 UNREAD MESSAGE** will be displayed on the LCD screen.

1. Press the **VIEW** soft key to display the message
2. Press the **OPTIONS** soft key to see all the options available that can be performed on this selected text message.

Options for a Text Message

You can do various things with the messages on your phone.

Press the **Options** soft key. You can now see the options available:

1. **View**
2. **Reply by SMS**
3. **Reply by MMS**
4. **Call Sender**
5. **Forward**
6. **Delete**
7. **Delete all**
8. **Save to Phonebook** (enables saving the number in the phonebook)
9. **Delete Several**

SMS

Reviewing Stored Text Messages (Inbox)

Received text messages are kept on the phone until you delete them. You can view old messages here.

1. Menu → Messages → Inbox
2. Scroll to the message you wish to review
3. Press the **OPTIONS** soft key → view
To view the message.

Sent Messages

The outbox stores successfully sent and saved messages (if the phone is set up to save outbound text messages in Message Settings).

1. Menu → Messages → Sent Messages
2. Scroll to the message you wish to review
3. Press the left soft key to view
4. Press **the OPTIONS** soft key to see all the options available for this selected text message
5. These options include:
 - View**
 - Forward**
 - Delete**
 - Delete All**
 - Delete Several**
 - Details** – shows the details of the message

Draftbox

The draft box stores messages that you have saved but not sent yet. You now get the chance to send the message, resume editing or delete it.

1. Menu → Messages → Draft Messages
2. Scroll to the message you wish to review
3. Press the central square key to view
4. Press **OPTIONS** soft key to see all the options available that can be performed on this selected text message
5. These options include **Send, Edit, Delete and Advanced Options**

Delete SMS

You can delete messages in the Inbox, Outbox, Draft box or Sent Messages.

1. Menu → Messages → Select either Inbox, Drafts, Outbox or Sent Messages → Options → Delete All → Delete All?

SMS

Text Message Settings

Service Centres distribute SMS messages. Your mobile telephone must have the telephone number for the service centre programmed into memory.

Generally, this will have already been set up by your service provider.

Menu → Messages → Message settings → Text message or multimedia message.

There are many settings options:

SIM

In which you can alter settings such as

Profile settings

You can choose the operator

Validity period

You can stipulate how long an attempt at delivering a message should be

Message type

You can choose the type of message in the list

Delivery Report

SMS

Every time a text is sent you will get a message to say it has been sent successfully (or not).

Reply Path

If you activate this feature, when you reply to a message, the cost of sending it is charged to the recipient's account instead of your own.

Preferred connection

You have the possibility to choose the connection on GPRS, GSM or GSM only.

Voicemail Server

Set up the location of the voicemail server

Memory Status

A useful option is to request to see how much memory is occupied and how much is free on both the SIM card and the telephone. For example:

SIM1: 17/100

SIM2: 2/100

Phone: 19/200

SMS

Text Message Counter

Shows how many messages have been sent and received via the SIM cards installed in your phone, in other words, how many messages have been sent and received via the respective providers of each of the SIM cards. This is useful for keeping track of the charges that will be applied by each provider for the messages sent via their respective networks.

These counts can be reset by pressing the Reset soft key.

Save Sent Message

Enables turning on or off the saving of text messages and multimedia messages.

To change between saving sent messages (On) or not saving (Off), use the * or # keys.

Preferred storage

If you select **SIM PREFERRED**, when you receive a new message it will be stored on the SIM card by default. When the SIM card memory is full new messages will be stored in the phone.

To change between saving to the phone or the SIM, use the * or # keys.

SMS

Service Messages

This telephone supports receipt of service messages, which are information services from your service provider.

Menu → Messages → Message Settings → Service Message → Enable Push → Accept all or Disable

Service Loading

You can select how you want to receive the service messages: either “Prompt” – to be prompted to view the incoming message, or “Auto Launch” – to have the service message launch automatically for you to read it, or you can disable the loading.

VOICEMAIL

Voicemail Number Setting

The voicemail function allows you to listen to any voicemail messages people may have left for you.

The voice mailbox is a network service to which you may need to subscribe. Contact your service provider if in doubt.

If your service provider does give you access to voice mail, the telephone number used to access the voice mail system will normally be set up on your telephone. If it is not, when you receive a message for the first time you will be prompted to enter the name and number settings to access your provider's Voicemail system.

Listen to Voicemail

If you have missed a call, you will receive a message on the phone's display, **1 MISSED CALL**. Press **VIEW**, you will see a list of all missed calls in the Call Record.

From standby, you can access voicemail by simply pressing and holding **1**. You will be connected to voice mail and can listen to your messages. To use the voicemail system, follow the instructions your voicemail provider gives.

PHONE BOOK

Telephone numbers and names can be stored in the phone book. This is held both on the SIM and in the phone memory. It allows you to store frequently used numbers so that you can easily make a call without having to remember or enter the telephone number. You can search and recall numbers in order to make a call, send a message or use an entry as an emergency contact. The phone book can contain up to 300 entries. If you try to add a new entry when all the memory is filled, a warning message will be displayed. You will need to delete an existing entry in order to add the new telephone number. The contacts saved in the SIM card memory are indicated by **SIM**. The advantage of saving to SIM means you can transfer the information to another telephone.

Create a Phone Book Entry

1. Menu → Phonebook → Normal Phonebook → Add new Contact
2. Select → SIM or Phone
3. Create a name for the Phonebook Entry using the numeric keypad (see below)
4. Enter a number for the phonebook entry
5. Options → Save

PHONE BOOK

The numeric keypad also has characters printed on the keys. These characters are used for entering text for the purposes of phonebook entry and modification, SMS text writing and searching for an entry in the phonebook.

Press each key the relevant number of times to get the letter you need - for example, to get the letter J, press the 5 key once, to get the letter S, press the 7 key four times in quick succession.

To move on to the next letter, wait a few seconds and the cursor will appear | after the last letter you entered. You may now enter the next letter. To switch between upper and lower case use the # key. You can also switch to numbers using # key. The input mode will be indicated on the right hand side of the name entry field indicated by a pencil..

Press 0 to insert a space.

Press the **CLEAR** soft key to delete the last character typed in while entering a number or a name. Press and hold the **CLEAR** soft key to clear the screen.

PHONE BOOK

Create a Phone Book Entry from Standby

Enter the number using the numeric keypad (always include the local area code)

1. Options → Save to Phonebook
2. Select either SIM1 or SIM2 or Phone
3. Create a name for the Phonebook Entry using the numeric keypad (see above)
4. If you are saving the contact to the Phone, you get many more options to save extra detail such as:
Email address
Caller Ringtone
5. Options → Save

View Phone Book Entries

1. Menu → Phonebook → Normal Phonebook →
2. Use ▼ and ▲ to scroll through the list until you find the desired contact. Or, you can search for a contact in the phonebook via an alphabetic search. Simply, type the first character of their name and you will be automatically positioned at the correct part of the phonebook

PHONE BOOK

Options within Phonebook

1. Menu → Phonebook → Normal Phonebook →
2. Use ▼ and ▲ to scroll through the list until you find the desired contact
3. Press **OPTIONS** soft key
4. Options available to be performed on that contact record are as follows:

VIEW
Send Text Message
Send multimedia message
Call
Edit
Delete
Copy
Add to block list
Groups
Phonebook Settings

Within Phonebook Settings you can do the following:


- 1) Assign the default storage location (SIM, Phone or all)
- 2) Assign Phonebook entries to a Speed dial number (3,4,5,6,7,8,9 can have a telephone number assigned to them)
- 3) Set Extra numbers – Fixed dial – you can set this ON or OFF, and you can enter a Fixed Dial number

PHONE BOOK

- 4) View the memory status - how much storage has been used on the SIM and the Phone

Create a Picture Phone Book Entry

You can also create a Phonebook entry with a picture associated with it. This is particularly useful when you receive an incoming call as the photograph will be displayed while the phone is ringing. Therefore you can see who is calling by simply looking at the photograph.

1. Menu → Phonebook → Picture Phonebook → Add (Use ▼ and ▲ to locate the green button) → Add → Picture
2. Take a photograph of the person that you are adding to the phonebook (press the 5 key). Press the Save soft key (or the Delete key).
 Do not forget to select in **Multimedia** → **Camera** → **Options** → **storage** → **Memory card** so the pictures are saved
3. Name → Create a name for the Phonebook Entry using the numeric keypad (see above)
4. Enter a number for the phonebook entry
5. Save → Back

PHONE BOOK

Dial a Picture Phone Book Entry

Use ▲ and ▼ to move to the desired photo to call.

Press 

Storing a Speed Dial Number

You can assign a speed dial number to a phonebook entry. This means you can dial a number very easily whenever you want simply by pressing the associated number.

1. Menu→Phonebook→Normal Phonebook→Add new contact→Phonebook settings→Speed dial
2. Select Status: either On or Off
3. Set numbers – Scroll down to the name of the contact you want to assign. The name is automatically filled, do not edit.
4. Press OK to save the speed dial **contact**.

Dialling a Speed Dial Number

Press and hold the desired speed dial number (3, 4, 5, 6, 7, 8, 9) to dial out the corresponding number.

CALL RECORD

Information about all calls is stored on this telephone in the Call Record. These calls include:

- Missed calls
- Calls dialled
- Calls received

Display Missed Calls

When you have a missed call, a message **n MISSED CALLS** will appear on the display e.g. **3 MISSED CALLS**. Press **VIEW** soft key to review the details or press **CANCEL** to exit. You can also review missed calls via the menu as follows:

1. Menu → Call Centre → Call History → Missed Calls
2. Use ▼ and ▲ to scroll through the list until you find the desired contact
3. Press the soft key **OPTIONS**, the following will be available to perform on that call record entry:

**View
Call
Send Text Message
Send Multimedia message
Save to Phonebook
Add to block list
Delete**

CALL RECORD

Display Dialed Calls

1. Menu → Call Centre → Call History → Dialed Calls
2. Use ▼ and ▲ to scroll through the list until you find the desired contact
3. Press the soft key **OPTIONS**, the following will be available to perform on that call record entry:

**View
Call
Send Text Message
Send Multimedia message
Save to Phonebook
Add to block list
Delete**

Display Received Calls

1. Menu → Call Centre → Call History → Received Calls
2. Use ▼ and ▲ to scroll through the list until you find the desired contact
3. Press the soft key **OPTIONS**, the following will be available to perform on that call record entry:

**View
Call
Send Text Message
Send Multimedia message
Save to Phonebook
Add to block list
Delete**

CALL RECORD

Delete Call Logs

1. Menu → Call Centre → Call History → Delete Call Logs
2. Select either Dialed calls, Missed calls, Received Calls or All Calls to set to zero.

Call Settings

Within Call Settings there is SIM Call Settings and Advance Settings.

You can access **SIM Call Settings** as follows:

Menu--->Call Centre--->Call Settings--->SIM Call Settings

There are many settings available:

Caller ID: - You can choose whether this is set by network, hidden or shown

Call waiting: This can be activated or deactivated. Please check that this service is available from your service provider. You can **QUERY STATUS** to find out if your service provider offers this service.

CALL RECORD

Call Divert: Incoming calls can be diverted to a specified telephone number (usually a voicemail number). There are 5 options available with this function:

- **Divert all voice Calls:** Call divert is applied to all incoming calls
- **Divert if Unreachable:** Call divert is applied to all incoming calls if your phone is switched off or you are not in a service area
- **If No Answer:** Call divert is applied to all incoming calls if you do not answer the call
- **If Busy:** Call divert is applied to all incoming calls if your line is busy
- **Divert All Data Calls**
- **Cancel all diverts**

Call Barring: Incoming and outgoing calls to and from your phone can be limited. There are 4 options available with this function:

- **Outgoing Calls:** No outgoing calls can be made
- **All Incoming Calls:** No incoming calls can be received
- **Cancel all**
- **Change barring password**

CALL RECORD

Line Switching: To select the line 1 or 2

You can access Advance Settings as follows:

Menu--->Call Centre--->Call Settings--->Advance Settings

There are many settings available:

Block List: The ability to Reject and blacklist numbers

Auto Redial: If this setting is activated, when you make a call but cannot get through as the other line is engaged, your telephone will automatically redial this number after a certain amount of time. This will take place provided you have not cancelled the call.

Call time Display

Call Time Reminder: customise if you want a reminder of how long you have been on the phone

Auto quick end: To automatically end a call after a specified number of seconds has elapsed:

CALL RECORD

1. Menu→Call Centre→Call Settings→Advance Settings→Auto Quick End
2. Press # to change the setting between **On** and **Off**
3. Time – enter the number of seconds you allow the call to last before the auto quick end (1-9999 seconds)
4. Options – ▼ and ▲ to Save or Cancel

Answer mode:

- **Any key:** If this setting is activated, when there is an incoming call you can press any key to answer it.
- **Auto answer** when on Headset mode

HANDSET SETTINGS

I.C.E In Case of Emergency

You can add 4 Names and Numbers of people who could be contacted in an emergency.

To specify the emergency contacts:

Menu → Settings → ICE → Contacts

To input all of the phone owner's information:

Menu → Settings → ICE → Owner info

You can enter the following essential information about the phone owner:

- Name
- Address
- Disease
- Allergy
- Blood group
- Doctor

Profiles

There are 4 types of profile available:

- **General** (you can: activate, customize or reset)
- **Silent** (you can: activate. To deactivate, you must choose a different profile)

HANDSET SETTINGS

- **Meeting** (you can: activate, customize or reset)
- **Outdoor** (you can: activate, customize or reset)

Menu → Settings → Profiles

To customize the details of the profile selected, you can change the following settings:

- Alert type
- Ring Type
- SIM 1 Ringtone
- SIM 2 Ringtone
- Ringtone Volume
- SIM 1 Message
- SIM 2 Message
- Message Volume
- Keypad (sound type, for example human voice))
- Key tone Volume
- Power On tone
- Power Off tone
- System alert

Boost Settings

Whenever you make or receive a call, the amplify feature can be set to On as a default.

Menu → Settings → Boost Settings

HANDSET SETTINGS

Tone control

You have the possibility to set the receiving response choice from the following three:

Normal frequency

Low frequency: increase the low frequencies

High frequency: increase the high frequencies

Phone Settings

Within Phone Settings you can adjust the following functions:

Time and date:

- Set home city
- Set the time and date
- Set format (12hr or 24hr and DD MM YYYY or MM DD YYYY or YYYY MM DD)

Scheduled Power On or Off

This function enables setting times when the phone will automatically switch itself on and off, enabling the user to enjoy uninterrupted rest time and activity time.

Two times can be set for each:

Schedule power on/off → (on/off) 1 or 2

Enable/Disable → Set time

HANDSET SETTINGS

Language: There are 13 languages available for displaying the phone menus, including English, French, Spanish, Dutch, German and others.

Preferred input methods: Capitals, lower case or numeric

Display Settings: You can set:

- Wallpaper
- Power on display
- Power off display

Dedicated keys: You can set the phone so as you only need to press one navigation key to enter the desired menu on the telephone.

Flight mode: Switching this mode on disables some of the phone's functions. This is useful if you want to keep the phone on during a flight without fear of interfering with the aircraft flight systems. The other setting here is: **Normal** mode.

Backlight Settings: Brightness and Time (the length of time before the phone display fades off)

Network Settings

SIM and GPRS settings can be changed

HANDSET SETTINGS

Security Settings

This mobile telephone allows you to set up passwords to help protect your telephone against unauthorized use.

The PIN and PIN2 codes are supplied with your SIM card. The PIN code helps to protect the SIM card against unauthorized use. The PIN2 code is required to access certain services.

Screen auto lock: enables setting the time before the display locks and can only be re-opened by entering a password.

The possible settings are: Off / 15 sec / 30 sec / 1 min and 5 min.

Phone security:

- Phone lock: activates or cancels the auto lock function.
- Change password: enter the old PIN code, then enter the new lock code.

Restore Default

You can undo all the changes you have made to the telephone settings and restore to the factory settings. The default password is 1122.

SOS

SOS Function

In an emergency, you can sound an alarm by pressing the **SOS** button (on the rear of the handset) for 3 seconds. An audible alarm will sound and alarm messages (which you can define) will be sent to recipients you have specified under this function.

This function includes the following functions, which you must use to configure your SOS function:

- **SOS**

1. **SOS Mode Setting** – choose whether your SOS message will go out to phone numbers you select (see Set SOS Number below). You can configure up to 5 phone numbers. You can alternatively set a call centre number which will be contacted, or you can turn this function OFF.
2. **Set SOS Number** - you can configure up to 5 phone numbers which will be contacted in case you press the SOS button. The phone will dial numbers on this SOS list automatically one by one. If a busy tone is detected or a call is aborted by user, the next number will be dialled immediately. The phone will dial these numbers until the handset is powered off.

SOS

3. **Call Centre number** – enter the number here.

4. **Set outgoing voice MSG** – you can choose the voice message that will go out to the destinations you have chosen (the default message or the custom message)

- **Record SOS Message** – pressing this button starts a 20-second-long recording. You can record your SOS message here and it will be sent if you press the SOS button.

~~If you have preset an SOS text message and set the SMS RECEIVER (generally another mobile phone), once you press the SOS button~~

If you want to quit the SOS mode press the **SOS** button again for 3 seconds.

Note: When SOS is switched ON, you cannot turn the telephone OFF. You must switch the SOS mode OFF before turning the phone off.

SOS

SOS Number Settings

You can set up to 5 SOS numbers or set a number for a call centre.

1. Menu → SOS → SOS → Set SOS number → Set up to 5 Numbers
Or (depending on whom you would like to call at a time of emergency) → Set Call centre.
2. Menu → SOS → SOS → Set SOS Number → Edit → Either add from Phonebook or Enter Number
or
3. Menu → SOS → Call Centre Number → Enter the call centre number using the numeric keypad

SOS Message Record

Record an informative message that will assist your helpers in time of emergency. For example, "This is Jane Smith calling, I have hurt myself. Please come to my house and help me."

Menu → SOS → Record SOS MSG → Recite your message clearly → Press Stop on completion (the message can be up to 20 seconds long).

TOOLS


Tools

There are many useful functions within organizer.

Calendar - You can review the calendar, move to a certain date quickly and add events (with an alarm) if required.

Use the * key to move left and the # key to move right. To move up or down, use the ▼ and ▲ keys.

Tasks - You can set up a prioritised To Do list (with alarm reminders if required).

Alarm - An alarm can also be set to sound at specific times if required. The alarm can be set to go off only once or repeatedly on a weekly schedule. Five different alarm times can be set up. Press any key to stop the alarm sound. The alarm will keep ringing every 5 minutes until you actually turn the alarm setting to Off or press .

The alarm still works when the telephone is switched off.

TOOLS

Ensure the phone ringing tones are not set to silent, otherwise you will not hear the alarm!

Bluetooth - The CL8360 supports bluetooth. Other bluetooth devices can be searched for and likewise the CL8360 can be found. The bluetooth password is 0000. You can connect with a bluetooth headset or perhaps with another phone. This would enable file transfer via bluetooth – for example, photo transfer, MP3 and MP4 files.

You can also stop the bluetooth function so that other devices will not find it.

Calculator - Press **Up** (▲) or **Down** (▼) to move cyclically through the mathematical functions: **+** **-** **x** **/**(÷)

~~Press the hash (“#”) key to get the result (“=”)~~

Press the **Up** (▲) or **DOWN** (▼) or **TALK** () key to get the result.

MULTIMEDIA

Multimedia

There is superb multimedia options available on the CL8360:

- Camera
- Gallery
- Audio Player
- Sound Recorder
- FM Radio

Camera :

Press 5 to take photo

▼ and ▲ to ZOOM

Press 2 to set image quality

Press 1 to set image size

Press 4 to set white balance

Press 6 to set delay timer

FM Radio

Press 0 ON / OFF


- * key to search (skip)
- # key to search (backward)

Press 1- 0 to select 10 x channels.

Press and hold 1 (from 0-9) to store a channel in the phone memory. You can store up to 10 channels.

MULTIMEDIA

Torch

Press and hold the torch key  to turn ON the torch. Press and hold the torch key until the torch Turn OFF.

File Manager

All the files used in the many applications on the phone can be found within File Manager. There is a folder for each of the following:

- Answer Machine
- Audio
- Download
- My Music
- Photos
- Picture Phone book

You can do standard file manipulation for each of the files within the folder: View, Rename, Delete, Sort, Copy, Move, Details, Send

TROUBLESHOOTING

Telephone cannot be switched on

- Check battery is inserted and check that it is inserted correctly

Nothing appears on the display

- Check the handset is switched on
- Check the battery and SIM are inserted correctly

Display is locked when the telephone is switched on

- Enter the PUK to unlock the SIM

No signal icon is displayed

- There is no network connection. Move around to try and get to an area where there may be coverage
- Contact your service provider

Message to say that a function is not possible

- Your service provider might not support the function in question or you may need to subscribe to that service. Contact the service provider.

No display during the charging process

- The battery charge is very low. Wait a few minutes.

“Insert Sim” or “Limited Service” message is displayed

- Ensure the SIM is inserted correctly

The battery is discharged quickly or cannot be charged at all.

TROUBLESHOOTING

- Charge the battery for 4 hours
- Place the phone correctly in the charging unit or connect the charging unit properly. Clean the contact surfaces on the mobile phone and charging unit with a soft, dry cloth.
- Try a new battery

Unable to Charge the phone

- Check the adaptor connections
- If temperature is below -10°C or higher than 55°C move to a place without such extremes of temperature
- Try a new battery

Failure to link to the network

- The signal is too weak, or there may be some radio interference
- Is the SIM card installed incorrectly or damaged? If the SIM card is damaged, please ask your service provider for a replacement.

Cannot make a Call

- Check that mobile fees have been paid
- Check that the SIM card is valid
- Check if fixed dialling is set
- Ensure you have pressed the green dial button
- Is the SIM card registered to the network?

TROUBLESHOOTING

- Is the Bar Outgoing Calls feature enabled?
- There may be a problem with the network, call your service provider
- Check the service provider number, local area number or NMC number (see Handset Settings)

Cannot answer a call:

- Check that mobile fees have been paid
- Check that the SIM card is valid
- Check if fixed dialling is set
- Is the bar incoming calls feature enabled
- Is the call diverting function enabled

The keys appear to be locked

- Power the phone off and then on

Caller Number is not displayed

- Ensure you have subscribed to the Caller ID service. Contact your service provider
- The caller may have withheld their details
- Let the phone ring a few times as there may be a delay in receiving the Caller ID information

Any problems not referred to above

- Check through the User Guide
- Power off and then on again. Check to see if the problem persists

SAFETY INFORMATION

General

Only use the power supply included with the product.

Only use the approved rechargeable battery supplied.

Do not open the handset (except to replace the handset batteries or SIM) or base. Contact the helpline for all repairs.

Never dispose of batteries in a fire. There is a serious risk of explosion and/ or the release of toxic chemicals.

If you are sure you are not going to use the telephone for over a month, remove the battery

Cleaning

Clean the telephone with a soft cloth. Keep the base and handset charging contacts clean. Never use polishes or cleaning agents - they could damage the finish or the electrics inside.

Environmental

Do not expose to direct sunlight.

Always ensure there is a free flow of air over the surfaces of the telephone.

Do not place any part of your product in water and do not use it in damp or humid conditions e.g. bathrooms.

SAFETY INFORMATION

Do not expose your product to fire or other hazardous conditions.

The telephone is designed for working within a temperature range of -10°C to 55°C .

Usage

In summary, read these simple guidelines. Not following them may be dangerous or illegal.

SWITCH ON SAFELY

Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.

ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

INTERFERENCE

All wireless devices may be susceptible to interference. This could affect performance.

SWITCH OFF IN HOSPITALS

Follow any restrictions. Switch the device off near medical equipment.

SAFETY INFORMATION

SWITCH OFF IN AIRCRAFT

Follow any restrictions. Wireless devices can cause interference in aircraft.

SWITCH OFF WHEN REFUELLING

Do not use the device at a refuelling point. Do not use near fuel or chemicals.

SWITCH OFF NEAR BLASTING

Follow any restrictions. Do not use the device where blasting is in progress.

USE SENSIBLY

Use only in the normal position as explained in the product documentation.

BACK-UP COPIES

Remember to make back-up copies or keep a written record of all-important information.

CHARGING

Do not use the telephone during charging.

HEARING AID INFORMATION

Some phones are measured for compatibility with hearing aids. If the box for your particular model has “Rated for Hearing Aids” printed on it, the following explanation applies. When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate. The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box. The ratings are not guarantees. Results will vary depending on the user’s hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

NETWORK SERVICES

To use the phone you must have service from a wireless service provider. Many of the features in this device depend on features in the wireless network to function. These network services may not be available on all networks or you may have to make specific arrangements with your service provider before you can utilize network services. Your service provider may need to give you additional instructions for their use and explain what charges will apply. Some networks may have limitations that affect how you can use network services. For instance, some networks may not support all language-dependent characters and services.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, they will not appear on your device menu. Your device may also have been specially configured. This configuration may include changes in menu names, menu order and icons. Contact your service provider for more information.

GUARANTEE

From the moment your Geemarc product is purchased, Geemarc guarantee it for the period of two years. During this time, all repairs or replacements (at our discretion) are free of charge. Should you experience a problem then contact our help line or visit our website at www.geemarc.com. The guarantee does not cover accidents, negligence or breakages to any parts. The product must not be tampered with or taken apart by anyone who is not an authorized Geemarc representative. The Geemarc guarantee in no way limits your legal rights.

IMPORTANT: YOUR RECEIPT IS PART OF YOUR GUARANTEE AND MUST BE RETAINED AND PRODUCED IN THE EVENT OF AWARRANTY CLAIM.

Please note: The guarantee applies to the United Kingdom only

DECLARATION: Geemarc Telecom SA hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive

GUARANTEE

2014/53/UE and in particular article 3 section 1a, 1b and section 2. The telephone does not operate if the line current is lower than 18 mA.

Electrical connection: The apparatus is designed to operate from a 230V 50Hz supply only. (Classified as 'hazardous voltage' according to EN60950 standard). The apparatus does not incorporate an integral power on/off switch. To disconnect the power, either switch off supply at the mains power socket or unplug the AC adaptor. When installing the apparatus, ensure that the mains power socket is readily accessible.



RECYCLING DIRECTIVES

The WEEE (Waste Electrical and Electronic Equipment) has been put in place for the products at the end of their useful life are recycled in the best way.

When this product is finished with, please do not put it in your domestic waste bin.

Please use one of the following disposal options:

- Remove the batteries and deposit them in an appropriate WEEE skip. Deposit the product in an appropriate WEEE skip.
- Or, hand the old product to the retailer. If you purchase a new one, they should accept it.

Thus if you respect these instructions you ensure human health and environmental protection.



For product support and help visit our website at

www.geemarc.com

Telephone 01707 384438

Or fax 01707 372529



UGCL8360_En_v1.1

geemarc™ UNITED KINGDOM
Telecom SA

5B Swallow Court
Swallowfields
Welwyn Garden City
Hertfordshire, AL7 1SB
For product support:
01707 384438

www.geemarc.com