



FILLING TIRES WITH AIR


GO TRAX GXL




Locate air cap on tire.




Remove the air cap turning it counter-clockwise




You will now see a nozzle connected to the inner tube.




You can use any air pump that connects to our air-pump extender




Connect this air-pump nozzle to one of the ends of the air pump extender.




Locate the air-pump extender. This will connect to the air-pump.



Connect both ends together and then lock the air pump if applicable.



This is how it will look after you lock it.



Attach air-pump extender to the tire nozzle and rotate it clockwise to lock it. Begin pumping air.



Remember: Recommended tire pressure is 50 PSI.