

**READ CAREFULLY BEFORE USE.
KEEP FOR FUTURE REFERENCE.**

If you have any questions, email us at info@foodiebooster.com or give us a call at +1 (310) 974-1961.

PLEASE NOTE: An adult caregiver is responsible for the safety of the child using the Foodie Booster. Operate only as directed by these instructions.

UNPACKAGING: The Foodie Booster comes preassembled. Carefully remove all packaging materials including the small piece of protective plastic covering the lap bar. Be sure not to damage the fabric restraint system if removing packaging materials with something sharp.

OPERATION: To unfold, hold the Foodie Booster by the backrest or lap bar. The backrest should be closest to you. Rest the back legs on the floor and place one hand on the backrest and another hand on the lap bar. Push the lap bar away from you until you hear both safety pins engage. With one hand still on the backrest, give the lap bar a light tug towards you to ensure that the safety pins have engaged. Make sure the restraint system straps remain on top of the seat and do not get stuck in any parts when unfolding.

Place the unfolded Foodie Booster on a clean level surface at the location that it will be used. Unbuckle the restraint system by pressing on the plastic button in the center of the quick-release buckle. Place one leg through each opening under the lap bar. Strap the child in using the restraint system and adjust the straps to fit snugly.

To fold, remove the child from the Foodie Booster. Rebuckle the restraint system and tighten to ensure straps do not interfere with moving parts. Stand behind the Foodie Booster and press down on both plastic buttons located on either side of the front legs. While holding down on the buttons, lean the Foodie Booster back so that it is resting on its back legs and push the front legs towards the back legs.

INSPECTION: Prior to each use, inspect to make sure that the Foodie Booster is clean and that all parts appear to be undamaged and working properly. Make sure the restraint system straps are intact and not fraying and that the warning label is undamaged and fully legible.

STORAGE: Individual Foodie Boosters store vertically against any vertical wall. Make sure the backrest with the warning label is facing out and the lap bar is against the wall. If you do not wish to store it against a wall, lay it flat on an elevated surface. Please note that the Foodie Booster is unable to stand vertically on its own when folded.

CLEANING: To clean, wipe down with a wet cloth.

To order new labels or replacement straps, email us at info@foodiebooster.com or give us a call at +1 (310) 974-1961.

⚠ WARNING:

FALL HAZARD: Children have suffered severe head injuries including skull fractures when falling from high chairs. Falls can happen suddenly if child is not restrained properly. Lap bar is not designed to hold child in chair.

- Prevent serious injury or death from falls or sliding out.
- The lap bar is not designed to hold child in chair.
- Always use the restraint system. Adjust to fit snugly.
- It is recommended that the high chair be used only by children capable of sitting upright unassisted.
- Stay near and watch child during use.