

WIFI IP CAMERA **USER MANUAL**





Parts Guide

Whats-in-the Box?












Description




	Power	DC5V±10%
	Status light	Solid Red light on: the camera network is abnormal Blinking red light: awaiting WIFI connection Solid Blue light on: camera running correctly Blinking blue light: currently connecting
	Microphone	Captures sounds for your video
	SD card slot	Supports local SD Card storage (Max.128G)
	Reset	Press and hold the 'reset' for 5 seconds to reset the device (if you have modified settings, they will return to factory defaults) Pressing for 1 second will


activate manual WiFi setup mode)

1. Stick the adhesive at the bottom of the camera, middle portion

Install optionally



2. Mount the Camera on a clean, flat surface.



Plug in

Plug the camera into an outlet. An audible sound will play when the system is ready for operation.

Set-Up



Addina

Download our eco4life app by scanning the QR code below or searching from your app store. Follow our prompts to finish setup.







QR Code Configuration

MODEL NO: SC-RIPC-8C

Important reminders before adding the device:

- 1. This camera only supports 2.4GHZ wifi router, please make sure you are using a 2.4GHZ wifi router.
- 2. Please follow the instructions and make sure the password is entered correctly.
- 3. Only one camera and one registered account is allowed by the App. If a Registered Account added the camera through the App, another user can no longer add and register an account.
- 4. You must delete the first Registered Account from the App, then another User may add the device and register an account

How to Add the Device:


Step 1. Open the eco4life App, click "+", select "All devices", then select "Smart Camera".





QR Code Configuration

Step 2. Make sure that the Indicator Light is rapidly blinking. Click "Otherwise", then select "QR code net-pairing", click "next step".



Step 3. Enter your WiFi password and click "Confirm", scan the QR Code using the camera.





QR Code Configuration

Step 4 Click "I heard the beep" once you hear 'donging' sounds. Configuration should be completed around 30 seconds.



Support

For more troubleshooting help, please visit www.sonicgracehome.com FAQ or send us an email at **CS@sonicgracehome.com**

Flip your video stream vertically anytime for maximum flexibility.

Features

Video flip

Turn on sleep mode when monitoring is not needed, and resume monitoring when you are away

Motion detection

Motion sensors will notify you when movement is detected.

Record

Record every moment using high capacity SD card storage.

Day & Night

Powerful night vision means no interruptions, even in complete darkness.







Night

Q: In the network process, the progress bar is always not 100%, is this Failure?

FAQ

- A: This camera only supports 2.4GHZ WIFI router, please make sure you are using a 2.4GHZ WIFI router. It doesn't support WEP safe mode. Please switch the Wi-Fi WEP safe mode to a different mode.
- Q: Repeated additions is this Failure?
- A: After adding, and it fails,, it is recommended to restart the device or power off, and then try to add again
- Q: The device cannot be previewed properly
- A: Check whether the network is normal. Place the camera close to the router. If this still does not work, t is recommended to reset the device and add it again
- Q: Why is it still in the list of devices after resetting?
- A: The reset device only resets the network configuration of the camera. It does not change the configuration on the App. Remove the camera by deleting it from the App.
- Q: How do I move the camera network to another router?
- A: First remove and reset the device on the APP and then configure the device again through the APP.
- Q: Why isn't the device identifying the SD Card?
- A: It is recommended to plug in the SD card while the power is off. Confirm that the SD Card is not corrupted and that it is FAT32 Format. TF Cards cannot be identified when the internet connection is not stable.
- Q: Why am I not getting App notifications on my phone?
- A: Make sure that the App is On. Check to make sure that you turn the following features ON: Reminder Function, Message Notification and Authority Confirmation.