



CORDLESS TOP DOWN BOTTOM UP CELLULAR SHADES INSTRUCTIONS




PREPARATION

1 Check the Hardware



2 Prepare Tools




INSTALLATION

1 Installing the Brackets


OUTSIDE MOUNT:

Position brackets **A** above window opening. Remember to leave the brackets few inches away from each side of your window. Spread them out evenly by having same distance from each side of the window. Make sure brackets are aligned. "L" shape opening should be facing down, with shorter side against the wall.



INSIDE MOUNT:


Position brackets **A** along the top of the window opening in the desired location. Remember to leave few inches away from each side of your window. Make sure both brackets are aligned. "L" shape opening should be facing down, with longer side against top of the window opening.



NOTE:


Insert 1 hex-head screws into oval opening, between 2 springs, and fasten.

DO NOT use hex-head screws for holes on the back of the bracket for inside mount. It will prevent your shade from clicking in place. These holes can be operated with 2 flat-head screws (Flat-head screws are not included in the package).




2 Prepping the Shade

Remove the wrap and install the headrail endcaps **D**, middlerail endcaps **F** and bottomrail endcaps **E** on each end.




3 Mount Shade on Brackets

Install the headrail by hooking the front of the bracket **A** and push shade towards back of brackets, in a rolling motion, until clicks place.




4 Installing the Handles

To insure proper usage of cordless shades, be sure to extend and retract shade steadily assuring the cord to stack evenly.



Install midrail handle **B**.



Install bottomrail handle **C**.


Quick How-to-use Guide

Procedure of Operation

1. When the blind is lowered, please first down the bottom rail, then move the middle rail to the desired position.
2. When the blind is raised, please first move the middle rail upwards, then move the bottom rail up to the desired position.

Please allow 24 hours for your shade to drop to its actual height when first installed due to the nature of the fabric.

For cordless cellular shade, it is recommended to operate every 5 to 7 days because if the fabric is in long-term stationary position, that will cause the operation to not function smoothly (raising and lowering), especially for opaque fabrics.



WARNING/ADVERTENCIA

Window blind cord can STRANGLE your child.
To prevent strangulation, purchase cordless products or products with inaccessible cords.

La cuerda de la persiana puede ESTRANGULAR a su niño.
Para evitar el estrangulamiento, compre alternativas cuerda o productos con cuerdas inaccesibles.

Questions

EMAIL
support@chicology.com

HOW - TO
www.chicology.com/how-to



PHONE
866 - 999 - 6188

HARDWARE
www.chicology.com/missing-hardware

Chicology "3-3-3" Limited Lifetime Warranty

• Roller Shade • Panel System • Roman Shade • Vertical Blinds • Wood & Faux Wood Blinds • Cellular Shades •

Type of Damage	>	Length of Warranty
Manufacturing Defects	>	Lifetime
Cords	>	3 years
Vertical vanes	>	3 years
Fabric	>	3 years

COVERED :

All shades and blinds are warranted against manufacturer defects in materials or workmanship, provided :

1. You are the original purchaser of the products.
2. The product was properly installed according to instructions.
3. The product was made or assembled exclusively from Chicology's materials and components.

Components and brackets.

Repairs and/or replacements will be made with similar or like parts.

NOT COVERED :

1. Chicology does not cover consumer damages caused by accidents, alterations, misuse, and abuse of the products, or damages from pets or insects.
2. Damages resulted from removal and reinstallation in the same or any other window applications.
3. Damages caused during measurement, installation, cleaning, and/or maintenance of your blinds and shades.
4. Any incorrect measurements will not covered by the warranty and non-refundable.
5. Any yellowing or cracking of plastic parts due to normal wear and tear.
6. All fabrics can lose their original intensity due to prolonged exposure to these elements: direct sunlight, wind, water/moisture, salt air, high humidity.
7. Some natural fabrics have variations in color, grain and texture. These variations should in no way be considered flaws or defects, as they are part of the natural beauty of the fabric. Fraying is considered normal wear and tear, and is not covered by the warranty.
8. High humidity may cause wood slats to warp.
9. Colors may vary from lot to lot and replacements may not match exactly to previous shades.
10. All cords will eventually wear out.

TO REPORT SHIPPING DAMAGES

If damage occurred during shipping, we are required to collect photo documentation of damaged packaging and merchandise for all claims.

Immediately report damages within 14 calendar days by phone to 866.999.6188 or else your claim for damages may be denied.

OBLIGATIONS TO THE CONSUMER

The obligations of Chicology are limited to the repair or replacements of parts or products found to be defective. Chicology will determine if the product is defective or not and may replace the product.

Any defective customized products can be exchanged but are non-refundable if still under warranty.

Chicology is not responsible for shipping or labor costs (such as measuring, installing, reinstalling, and taking down the above stated products).

CHICOLOGY SHALL HAVE NO LIABILITY WHATSOEVER FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you.