

24w Bollard Light Installation Instructions





Product Specifications				
Model No.	HCP-262330	HCP-262340	HCP-262430	HCP-262440
Material	Aluminium			
Colour	Black			
IP Rating	IP65			
Input Voltage	240v AC			
Protection Class	1 (Earth required)			
Lamp Base	Built in LED			
Lamp Wattage	1x 24w			
Colour Temp	TRI Colour - 3000K, 4000K, 5500K			
Lumens	1290lm, 1500lm, 1430lm	1290lm, 1500lm, 1430lm	1290lm, 1500lm, 1430lm	1290lm, 1500lm, 1430lm
CRI	80+			
Dimmable	No			
Warranty	5 Years Replacement*			











Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Commercial does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- All electrical connections must be watertight, If a watertight connection is not done, Warranty will be voided.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- When installing surface mounted bollards, base plate must be installed on concrete or concrete pad, Fitting should not be installed under ground level, all holes including cable entry must be silliconed to prevent any water penetration into fitting, silicone must also be applied around fitting at ground level. Failure to do this will void warranty
- All o-rings and seals must be in place correctly to maintain warranty.
- These instructions may be updated at any time due to product improvements, Please visit website for most current installation instructions.

- Make sure that the electrical circuit is free of voltage (master switch off).
- Remove baseplate from fitting by removeing 4x allens screws on side of fitting and set aside.
- Install baseplate in desired location using appropriate screws for application. The screws supplied are mild steel which must be replaced with higher grade if there is any chance of them being affected by water. The location of baseplate must be installed on either concrete or concrete base and cannot be installed under ground level
- Seal all holes in the base plate including cable entry and screw holes.
- Locate IP rated junction box within fitting. Undo screws from junction box and remove cover.
- Insert cable through cable gland on junction box. If your cable is not circular you must fix entry of your cable to maintain IP rating. Failure to do so will void
- Connect the cable using wire with earth. Connect earth first, then live and neutral wires.
- Reattach cover to IP rated junction box making sure screws are tight and seals are still in place.
- Affix the bollard to the baseplate by reattaching the 4 allen screws removed earlier making sure these are tight to reduce any movement in bollard.
- Colour temperature is set to 3000K. To change, remove top from fitting by loosening allen screws on side of fitting. Select desired colour temperature by moving switch located on bottom of top.
- Attach cover by tightening allen screws making sure the seals are still in place to avoid any water penetration.
- All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details:

8/133 Beauchamp Road Matraville NSW 2036 Australia

Email: sales@havitcommercial.com.au Web: www.havitcommercial.com.au



www.havitcommercial.com.au

