

WHELEN AEROSPACE TECHNOLOGIES

Phone: (860) 526-9504 Internet: www.flyWAT.com

Sales/Service e-mail: info@flyWAT.com

Installation Guide/ICA:
Aviation model: 9058900
P/N: 01-0790589-00
4-Inch Taxi Light Assembly

MARNING: This product can expose you to chemicals including Methylene Chloride which is known to the State of California to cause cancer, and Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

## SPECIFICATIONS:

**AIRWORTHINESS LIMITATIONS:** The Airworthiness Limitations section is FAA approved and specifies inspections and other maintenance required under §43.16 and §91.403 of the Federal Aviation Regulations, unless an alternative program has been approved.

No airworthiness limitations are associated with the installation of the LED taxi light.


**CONTINUED AIRWORTHINESS:** The Taxi Light, Model 9058900, consists of two banks of seven LEDs, for a total of 14 LEDs. If one LED fails as a short, the other 13 will continue to operate. If an LED fails open, all seven LEDs in that bank will be off and the other bank will operate normally. There is no FAR requirement for this light. Inspect the lens. Replace if there is excessive scratching, pitting, discoloration or cracking.

For additional lens maintenance detail see SAE ARP5637.

**PERIODIC INSPECTIONS:** An annual inspection shall be performed unless the OEM specifies a shorter interval.

**INSTALLATION PROCEDURES:** The following information is to assist in the installation of a WAT LED Taxi Light.

- 1. Remove the rear cover and cable clamps.
- Engage the existing input cable with the cable clamps and secure to the rear cover as shown in Fig. 1.
- 3. Before the rear cover is installed onto the light assembly (Fig. 2), connect the taxi light inputs to the assembly according to the polarity indicated. Note: This unit is polarity sensitive and will not function if not wired properly (see Fig. 3). Connect the power lead to an appropriately sized breaker. Connections to be in accordance with FAA approved methods. Coat connections so as to prevent corrosion.
- 4. Using appropriate hardware, install light assembly and insure that all leads are clear of any obstructions and secure as required. Secure light assembly, using vibration resistant threaded fasteners. NOTE: Make sure the "UP" arrow is properly oriented.
- Check all avionics systems for interference from this installation.
- A flight check should be performed by a properly certified pilot.
- If required, update aircraft records utilizing FAA Field Approval (Form 337) or equivalent.



## Lens Replacement:

- 1. Remove the #4-40 lens retainer screws (Item 1). Remove the retainer and replace the outer lens.
- 2. When re-assembling, note the longer post on the backside of the reflector (Item 4) mates to the deeper hole of the sub-assembly (Item 5) shown at right.
- 3. To prevent damage to the lens, do not overtighten the #4-40 screws. Tighten until there is no gap between the retainer (Item 2) and sub-assembly (Item 5), then torque screws to 3-5 lb/in.

