

Vinci®

COLD BREW 360™



INSTRUCTIONS

www.vincihousewares.com | 888.735.3621 | support@vincihousewares.com

GETTING TO KNOW YOUR COLD BREW 360

Before using your Cold Brew 360 for the first time, familiarize yourself with the various parts and how it functions.

Before first use, and after subsequent uses, wash all parts with warm, soapy water. Carefully read all the instructions.




WATCH THIS
Quick Start Video

- A. Top Filter Cap
- B. Filter Basket
- C. 360 filter
- D. Bottom Filter Cap
- E. 2 Tablespoon Scoop
- F. Serving Lid / Filter Holder
- G. Durable Plastic Carafe
- H. Holding Cup
- I. Instruction Manual




HOW TO USE YOUR COLD BREW 360

1 GETTING STARTED




Before you begin using your Cold Brew 360. Remove the lid assembly and remove the Holding Cup(H).

2 FILL WATER




Fill the Carafe with fresh, clean ROOM TEMPERATURE water. Filtered water is best (or recommended). **Never fill past the Fill Line.**

3 REMOVE LID/REMOVE TOP CAP



Hold the Serving Lid(F) and twist counter clockwise to remove the Filter Basket(B). Set the lid aside and proceed to removing the Top Filter Cap(A).


4 FILL COFFEE



Using the included 2-Tablespoon Scoop(E), fill the Filter Basket(B) with approximately 9 level scoops of your preferred medium to coarse grind coffee. **NEVER overfill or compress the grounds as it will hinder the brewing process.** Re-insert the Top Filter Cap(A) and Serving Lid(F). TIP: The Filter Basket(B) is full when there is about 1 inch of free space at the top.

5 INSERT LID ASSEMBLY/STEEP


INSERT LID ASSEMBLY SLOWLY INTO CARAFE



STEEP
12-24
HOURS

Slowly place the lid assembly into the Carafe, but make sure the Filter Basket is fully submerged in the water. Let your cold brew steep for 12 – 24 hours on the counter top at room temperature. TIP: Longer steep times results in stronger cold brew. Experiment and adjust the steep time according to your preference.

6 PLACE LID ASSEMBLY IN HOLDING CUP




REMOVE LID ASSEMBLY AND PLACE INTO HOLDING CUP

Remove lid assembly and place it in the Holding Cup(H).

7 REMOVE LID / PLACE LID ON CARAFE


REMOVE SERVING LID ASSEMBLY FROM FILTER AND PLACE ON CARAFE.



Hold the Filter Basket(B) and twist the Serving Lid(F) counter clockwise to remove then place the Serving Lid(F) on the Carafe(G).

8 ROTATE LID TO SERVE/CLOSE

ROTATE OPEN TO SERVE. ROTATE CLOSED TO PRESERVE.




Rotate the Serving Lid(F) to expose the spout and pour a cup of delicious cold brew. Rotate the Serving Lid(F) back to the closed position for storage.

TIP: Cold Brew can be stored in the refrigerator for 7 – 10 days.

HOW TO CLEAN YOUR COLD BREW 360


To keep your Cold Brew 360 working and looking new, wash all parts after every use.

1 REMOVE TOP CAP AND RINSE




While in the Holding Cup(H), remove Top Filter Cap(A) and rinse off any remaining coffee grounds.

2 REMOVE BOTTOM FILTER CAP ASSEMBLY




Holding over trash or compost receptacle Flip over the Filter Basket(B) and remove the bottom filter cap assembly.

3 DISCARD COFFEE/RINSE FILTER



Tap on Filter Basket(B) to discard coffee. Rinse off any remaining coffee grounds from the Filter Basket(B).

4 REMOVE BOTTOM CAP/RINSE



Twist the Bottom Filter Cap(D) counter clockwise to unlock the 360 Filter(C) and remove the Bottom Filter Cap(D) before cleaning. Rinse both Bottom Filter Cap(D) and 360 Filter(C) from any remaining coffee grounds.

5 WASH ALL PARTS



To keep your Cold Brew 360 working like new, wash all part under warm soapy water after every use. After unit is dry, store for the next use.



WATCH THIS
How to Clean:
Quick Start Video

WARRANTY

LIMITED ONE-YEAR WARRANTY

ARM Enterprises, Inc. warrants that your appliance will be free of defects in materials or workmanship under normal home use for one year from the date of delivery. It is recommended that you register your appliance on vincihousewares.com/product-registration so that your purchase information will be stored in our system. ARM Enterprises, Inc. will, at its option, repair or replace a defective appliance without charge upon its receipt of proof of the date of purchase. If a replacement appliance is necessary to service this warranty, the replacement appliance may be new or reconditioned. Replacement appliances and parts are warranted for the remaining portion of the original warranty period. This warranty only applies to appliances operated in the United States and Canada. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state and, in the case of Canada, from province to province.

WHAT IS NOT COVERED BY THE LIMITED WARRANTY?

THIS WARRANTY DOES NOT COVER CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND DOES NOT COVER INCIDENTAL COSTS AND EXPENSES RESULTING FROM ANY BREACH OF THIS WARRANTY, EVEN IF FORESEEABLE. Some states or provinces do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you depending on the state or province of purchase. Vinci Housewares product warranty covers manufacturing defects under normal use and maintenance. Our liability is limited to the original purchase price of the unit. Incidental or consequential damages or issues due to improper use, installation, or maintenance are not covered.

OTHER LIMITATIONS

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER EXPRESS WARRANTY, WHETHER WRITTEN OR ORAL. IN ADDITION, ARM ENTERPRISES, INC. HEREBY SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES WITH RESPECT TO YOUR APPLIANCE, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Some states or provinces do not allow disclaimers of such implied warranties or limitations on how long an implied warranty lasts, so the above limitation may not apply to you depending on the state or the province of purchase.

HOW DO YOU OBTAIN WARRANTY SERVICE?

ARM Enterprises, Inc. appliances are high-quality and, with proper care, are intended to provide years of satisfying performance. However, should the need arise for warranty servicing, simply call Vinci Housewares **Customer Service at our toll free phone number 1-888-735-3621**. Please do not return your appliance for servicing without first speaking to ARM Enterprises, Inc. Customer Service to obtain a Return Authorization (RMA) number. ARM Enterprises, Inc. appliances returned without a Return Authorization number will be returned to the sender without servicing.



www.vincihousewares.com | 888.735.3621 | support@vincihousewares.com

F/N:20